

SUPPLEMENT TO

Beneath Apple ProDOS

For ProDOS 8, Versions 1.2 and 1.3

by Don D. Worth and Pieter M. Lechner



QUALITY SOFTWARE

21610 Lassen Street #7
Chatsworth, California 91311

Apple Books from Quality Software

Beneath Apple ProDOS by Don Worth & Pieter Lechner	\$19.95
Supplement to Beneath Apple ProDOS for Versions 1.0.1, 1.0.2 by Don Worth & Pieter Lechner	\$10.00
Supplement to Beneath Apple ProDOS for Version 1.1.1 by Don Worth & Pieter Lechner	\$12.50
Beneath Apple DOS by Don Worth & Pieter Lechner	\$19.95
Understanding the Apple II by Jim Sather	\$22.95
Understanding the Apple IIe by Jim Sather	\$24.95

Apple Utility Software from Quality Software

Bag of Tricks 2 (includes diskette) by Don Worth & Pieter Lechner	\$49.95
Universal File Conversion (includes diskette) by Gary Charpentier	\$34.95

See the last two pages of this book for information about how to order Quality Software products.


Illustrations by George Garcia

(c)1987 Quality Software. All rights reserved. No part of this book may be reproduced, in any way or by any means, without permission in writing from the Publisher. No liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this book, the publisher assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

"Apple" is a registered trademark of Apple Computer, Inc. This manual was not prepared nor reviewed by Apple Computer, Inc., and use of the term "Apple" should not be construed to represent any endorsement, official or otherwise, by Apple Computer, Inc.

CONTENTS

<u>PAGE</u>	<u>TOPIC</u>
5	Introduction
5	Understanding the Listings
PRODOS 8, VERSIONS 1.2 AND 1.3	
6	How ProDOS 8 is Loaded and Relocated (for both Version 1.2 and 1.3)
7	ProDOS 8 Loader (for both 1.2 and 1.3)
10	ProDOS 8 Relocator, Version 1.2 Relocation routines RAMdrive Device Driver SYSTEM File Loader
26	ProDOS 8 Relocator, Version 1.3
32	ProDOS 8 MLI (Kernel), Version 1.2
67	ProDOS 8 MLI, Version 1.3
75	ProDOS 8 System Global Page (for both 1.2, 1.3)
77	ProDOS 8 Quit Code (for both 1.2 and 1.3)
81	ProDOS 8 Disk II Device Driver, Version 1.2
88	ProDOS 8 Disk II Device Driver, Version 1.3
89	ProDOS 8 IRQ Handler (for both 1.2 and 1.3)
90	ProDOS 8 Thunderclock Code (for both 1.2, 1.3)
92	ProDOS 8 IIGS Clock Code (for both 1.2 and 1.3)
BASIC.SYSTEM, VERSION 1.1	
93	How BASIC.SYSTEM is Loaded and Relocated
94	BI Relocator
97	BASIC Interpreter (BI)
132	BI Global Page
DISK II BOOT ROM	
134	Disk II Controller ROM--Apple II/II+/IIe
136	Disk II Boot Logic--Apple IIc
139	Disk II Boot Logic--Apple IIGS
143	APPENDIX A -- Differences Between ProDOS 8 Versions
147	APPENDIX B -- Errata to Beneath Apple ProDOS



A ProDOS ATLAS

INTRODUCTION

This supplement documents the actual ProDOS 8 logic at nearly a byte by byte level. It is intended to aid experienced programmers in designing customized interfaces to ProDOS 8, and to provide implicit documentation of the ProDOS 8 functions. All assembly language programmers will find this supplement useful in learning about how an operating system works. This information is presented in the spirit of helping the user to understand ProDOS 8 better. The authors do not endorse indiscriminant modification of the ProDOS components. Whenever possible, standardized interfaces to ProDOS should be used to avoid the uncontrolled modifications which plagued Apple's previous operating system, DOS 3.3.

External system programs and utilities such as the Apple II System Utilities are not covered here, nor are disk controller ROM's covered other than the Disk II controllers available from Apple.

The information presented here is for the release of the ProDOS operating system called ProDOS 8, Versions 1.2 and 1.3. Previous supplements to Beneath Apple ProDOS documented the structure of Versions 1.0.1, 1.0.2, and 1.1.1 of ProDOS.

UNDERSTANDING THE LISTINGS

The listings which follow describe the major ProDOS 8 components in great detail. Each module is presented separately and consists of a section defining external addresses referenced by the program (such as zero page usage, I/O select addresses, and global page fields) followed by a section describing the instructions and data in the module. Divisions between major sections and subroutines are indicated with a row of asterisks (*) and additional comments.

Each detail line gives the address of the instruction or data field being described, followed by comments. Within the comments, the following notation is used to indicate references by instructions:

(address)	A store or load reference to a memory or I/O location.
>>address	A branch or jump to an address.
<address>	A call to a subroutine at the indicated address.
-->address	A pointer to an address.

Page titles give the address of the next instruction or data area in the module to be described. These may be used to quickly locate a particular area within the component.

HOW PRODOS 8 Versions 1.2 and 1.3 ARE LOADED AND RELOCATED

- ③ Copy to High RAM:
 IRQ Handler
 System Global Page
 MLI Kernel
 Disk II Device Driver

- ① PQUIT, the ProDOS Loader, or a "-" command loads the "P8" file to memory address \$2000 and jumps to the Relocator.

```

I-----I
I               I
I               I
I      "P8"      I
I  32 BLOCK FILE I
I(31 data blocks I--->
I plus one index I
I block)         I
I      L$3C7D    I
I               I
I               I
I               I
I               I
I               I
I               I
I               I
I               I
I-----I

```

- ② Copy from within Relocator to low memory:
 SYSTEM FILE LOADER
 PAGE 3 IMAGE
 80-COL CARD CHECKER

- ④ Final moves:
- | FUNCTION | FROM | TO | LENGTH |
|--------------|-------|--------|--------|
| Clock code | 5100* | D742 | 7D |
| QUIT code | 5900 | D100** | 300 |
| RAM drive... | | | |
| Caller | 2E00 | FF00 | 9A |
| Driver | 2C00 | 200*** | 200 |

```

I-----I$FFFF
I  IRQ HANDLER I
I-----I$FF9B
I  /RAM CALLER I
I-----I$FF00
I               I
I      MLI      I
I               I
I      KERNEL   I
I               I
I  (run location) I
I               I
I-----I$DE00
I  MLI DATA AREA I
I-----I$D700
I  DISK II DRIVER I
I-----I$D000
I               I
I-----I$C000
I  SYSTEM GLOBAL PAGE I
I-----I$BF00
I               I
I               I
I-----I$5C7E
I  IIGS CLOCK CODE I
I-----I$5C00
I  QUIT CODE       I
I-----I$5900
I  DISK II DRIVER  I
I-----I$5200
I  IRQ HANDLER     I
I-----I$519B
I  CLOCK CODE      I
I-----I$5100
I  SYSTEM GLOBAL PAGE I
I-----I$5000
I               I
I      MLI      I
I               I
I  (load location) I
I               I
I-----I$2F00
I               I
I  RELOCATOR      I
I-----I$2000
I               I
I               I
I               I
I-----I$96C
I  SYSTEM FILE LOADER I
I-----I$800
I               I
I-----I$400
I  PAGE 3 IMAGE      I
I-----I$3D6
I               I
I-----I$C8
I  80-COL CARD CHECKER I
I-----I$80
I-----I$0

```

*5C00 if IIGS **BANK2 ***AUX MEMORY

ProDOS Loader -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 0800

ADDR DESCRIPTION/CONTENTS

```
0800  MODULE STARTING ADDRESS
*****
* PRODOS LOADER
* THIS CODE IS LOADED FROM BLOCK 0
* INTO MEMORY AT $800.
* ITS PURPOSE IS TO LOAD THE "PRODOS"
* FILE INTO $2000 AND JUMP TO IT.
* (PRODOS RELOCATOR IS AT $2000)
*
* VERSION 1.2 -- 6 SEP 86
* VERSION 1.3 -- 2 DEC 86
* (THE LOADER IS STILL THE SAME AS IT
* WAS IN VERSION 1.0.1)
*****
```

*** EXTERNAL ADDRESSES ***

```
0027  ROM BOOT SUBRTN BUFFER PAGE ADDR
002B  ROM BOOT SUBRTN SLOT * 16
003D  ROM BOOT SUBRTN SECTOR TO READ
0040  ROM BOOT SUBRTN CURRENT TRACK
0041  ROM BOOT SUBRTN TRACK TO READ
      -- BLOCK READ PARAMETER LIST --
0042  COMMAND NUMBER (1 = READ)
0043  SLOT * 16
0044  I/O BUFFER ADDRESS ($44/$45)
0045  BLOCK TO READ ($46/$47)
0047
-----
0048  POINTER TO BLOCK READ ROUTINE
0049
004A  VOL DIR ENTRY POINTER/FIRST INDEX PAGE
004B
004C  ADDR OF SECOND PAGE OF INDEX BLOCK
004D
004E  INDEX INTO INDEX BLOCK PAGES
0050  TRACK SEEK PHASE-ON INDEX
0051  TRACK PHASE WANTED
0052  BLOCK READER RETRY COUNT
0053  CURRENT TRACK PHASE/PHASE-OFF INDEX
0054
0060  BUFFER POINTER
0061
05AE  SCREEN CENTER LINE
2000  LOAD POINT FOR RELOCATOR
C080  DISK ARM PHASE0
C088  TURN DISK DRIVE OFF
C089  TURN DISK DRIVE ON
```

ProDOS Loader -- V1.2 -- 6 SEP 86

ADDR DESCRIPTION/CONTENTS

```
C08C  SHIFT DATA REGISTER
FC58  HOME CURSOR/CLEAR SCREEN
*****
0800  SIGNATURE BYTE ($01 MEANS BOOT ROUTINE FOLLOWS)
      (A $03 IS STORED HERE DURING A 5.25" FLOPPY BOOT)
      -- APPLE /// BOOTING --
      THIS CODE (BLOCK 0) IS LOADED AT $A000 WHEN
      BOOTED ON AN APPLE ///. THE APPLE /// BOOT
      ROM JUMPS TO $A000. WHAT IS SHOWN HERE AS
      $800 ON AN APPLE II IS $A000 ON AN APPLE ///.
      THUS AN APPLE /// EXECUTES A HARMLESS
      INSTRUCTION (ORA $38,X), THEN DOES NOT BRANCH
      ON CARRY, AND JUMPS TO $A132 ($932 ON AN
      APPLE II). MANY THANKS TO DAV HOLLE FOR
      PROVIDING US WITH THIS APPLE /// INFORMATION.
```

```
0801  ***** MAIN ENTRY *****
      ON ENTRY, X = SLOT*16
      A = SECTOR NUMBER
```

```
0801  ENTRY POINT FOR APPLE II
0802  ALWAYS TAKEN (APPLE II) >>0807
0804  JUMP TO APPLE /// LOGIC >>A132
0807  SAVE SLOT*16
0809  READING SECTOR 3 NEXT?
080B  REMEMBER THIS...
080D  MAKE $CX FROM SLOT*16
0815  AND SAVE AT $49
0819  $48/49 --> $CFF IN ROM BOOT
081C  CHECK $CFF
081D  BOOT ROM FOR DISK II?
081F  NO, NOT A 5.25" FLOPPY >>085B
0821  GOT BOTH SECTORS OF LOADER? >>0831
0823  NO, STOP AT SECTOR 3
0825  STORE ON PARM (0800)
0828  SKIP SECTOR 1 (GET SEC 2)
082A  DUMMY UP $CX5C AS RETURN ADDRESS
0830  AND CALL ROM SECTOR READ SUBRTN

***** LOAD PRODOS *****
      (ENTIRE LOADER IN MEMORY NOW)
```

```
0831  CURRENT TRACK IS ZERO
0833  $48/49 --> $CX00
0837  COPY A PORTION OF DISKETTE BOOT ROM
0839  TO MY BLOCK READER SUBROUTINE (0994)
083D  FROM $9F7 TO $A7E
0843  MODIFY SOME BRANCHES IN THE COPIED CODE (091D)
0846  TO SUIT MY ERROR HANDLING TASTES (0924)
```

ProDOS Loader -- VI.2 -- 6 SEP 86 NEXT OBJECT ADDR: 084C

ADDR DESCRIPTION/CONTENTS

```

084C AND COPY SECTOR READ SUBROUTINE EXIT CODE (092B)
084F TO $A7F TO $A85 (0A7F)
0855 $48/49 --> DISKETTE BLOCK READER SUBRTN
0859 AT $0986
---
085B LEGAL DISK ROM?
085D NO, ERROR >>0890
085F STORE LSB OF BLOCK READER
0861 STORE ZEROS IN SEVERAL THINGS
0863 COMMAND = 1 (READ BLOCK)
086E BLOCK NUMBER = 2 (VOL DIRECTORY)
0871 $60/61 --> $C00 (BUFFER)
0875 $4A/4B --> $C00 (FIRST ENTRY)
0877 READ VOLUME DIRECTORY BLOCKS <0912>
0879 ERROR? >>08E6
087C MOVE UP TWO PAGES IN MEMORY
087E NEXT BLOCK NUMBER
0882 NOW AT BLOCK 6?
0886 NO, GO READ NEXT ONE >>0879
0888 YES, CHECK LINK FOR VALIDITY (0C30)
088D IT SHOULD BE ZERO FOR VOL DIR (0C01)
0890 BAD VOLUME DIR IF NOT ZERO >>08FF
0892 NO, INDEX PAST LINK AND VOL HDR
0894 AND BEGIN >>0898
0896 IF ALREADY PROCESSING, USE ENTRY LSB
0898 ---
0899 ADD ENTRY LENGTH TO FIND NEXT ENTRY (0C23)
089D STILL IN SAME PAGE? >>08AC
089F NO, BUMP ENTRY MSB
08A3 IS IT ODD? (SECOND PAGE OF A BLOCK?)
08A4 YES... >>08AC
08A6 NO, JUST FINISHED LAST BLOCK?
08A8 YES, ERROR -- FILE NOT FOUND >>08FF
08AA ELSE, START JUST PAST LINKS
08AC UPDATE LSB OF ENTRY POINTER
08AE GET NAME LENGTH (0902)
08B1 MASK OFF STORAGE TYPE
08B4 COMPARE NAME WITH "PRODOS"
08B9 NOT A MATCH? >>0896
08BE IF NAME MATCHES, IS IT A SAPLING FILE?
08C2 IF NOT, I CAN'T HANDLE IT >>08FF
08C6 GET FILE TYPE
08C8 SHOULD BE A PRODOS SYS FILE
08CA IF NOT, I GIVE UP >>08FF
08CD ALL IS WELL, COPY KEY BLOCK NUMBER
08CF TO $46/47
08D6 $4A/4B AND $60/61 --> $1E00
08D8 (BUFFER TO HOLD KEY BLOCK)
08E1 $4C/4D --> $1F00 (SECOND PAGE)
08E3 READ A BLOCK <0912>
08E6 ERROR? >>08FF

```

ProDOS Loader -- VI.2 -- 6 SEP 86 NEXT OBJECT ADDR: 08EA

ADDR DESCRIPTION/CONTENTS

```

08EA BUMP TO NEXT BLOCK BUFFER
08EE $4E = OFFSET INTO INDEX BLOCK
08F0 GET NEXT BLOCK NUMBER FROM INDEX BLOCK
08F8 BLOCK NUMBER = 0? (END OF FILE)
08FA NOT YET, READ A BLOCK >>08E3
08FC ELSE, JUMP TO RELOCATOR AT $2000 >>2000
08FF ERROR JUMP >>093F
0902 ***** KERNEL NAME *****
0902 LENGTH OF KERNEL'S NAME
0903 'PRODOS', "PRODOS" (KERNEL NAME)
0912 ***** COPY BLOCK READ BUFFER PTR *****
0912 COPY $60/61 --> $44/45
0914 (BLOCK READ BUFFER POINTER)
091A THEN GO TO BLOCK I/O ROUTINE >>0048
091D ***** ROM SECTOR READ OFFSETS *****
      OFFSETS INTO ROM SECTOR READ SUBROUTINE
      TO BRANCH DISPLACEMENTS WHICH NEED TO
      BE CHANGED FOR LOADER'S PURPOSES
091D *****
***** NEW BRANCH OFFSETS FOR ABOVE ***
0924 ---
092B ***** SECTOR READ EXIT CODE *****
      COPIED TO END OF DISKETTE SECTOR READ CODE
092B GET SLOT*16
092D AND EXIT NORMALLY
092E RETURN
092F RESTART BLOCK READ OPERATION >>09BC
0932 ***** APPLE /// BOOT CODE *****
A132 THIS IS $A132 WHEN BOOTED ON APPLE ///
0932 MAKE IT LOOK LIKE A JSR FROM $A000
0938 LOAD IN BLOCK 1 (WE WANT SOS, NOT PRODOS)
093C GO TO APPLE /// BLOCK READ ROUTINE >>F479

```


ProDOS Loader -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 093F

ADDR DESCRIPTION/CONTENTS

093F ***** ERROR HANDLER *****

093F HOME CURSOR/CLEAR SCREEN <FC58>
0944 COPY "UNABLE TO LOAD PRODOS" MESSAGE (0950)
0947 TO SCREEN (05AE)
094D THEN GO TO SLEEP FOREVER >>094D

0950 ---
0950 '*** UNABLE TO LOAD PRODOS ***'

096D ***** MOVE ARM TO NEXT PHASE *****

096D GET CURRENT PHASE
096F CONVERT TO NEXT ARM PHASE
0972 ADD SLOT*16
0975 SELECT NEXT ARM PHASE THIS DRIVE (C080)
097A ---
097C DELAY LONG ENOUGH FOR ARM TO MOVE
0983 WHEN FINISHED, RETURN WITH X = SLOT*16
0985 RETURN

0986 ***** DISKETTE BLOCK READ ROUTINE *****
\$44/\$45 --> BUFFER
\$46/\$47 = BLOCK NO.

0986 GET BLOCK NO. LSB
0988 ISOLATE SECTOR REMAINDER
098C SKEW SECTOR BY 2
0992 AND STORE SECTOR WANTED
0994 GET MSB
0996 AND HIGH BIT OF TRACK
0999 MERGE WITH LOW PART OF TRACK
099C STORE TRACK WANTED
099F TRACK*2 IS PHASE WANTED
09A3 SET PAGE ADDRESS OF BUFFER
09A7 TURN DRIVE MOTOR ON (C089)
09AA READ SECTOR <09BC>
09AD NEXT PAGE
09B1 SKEW TO NEXT SECTOR
09B5 READ SECOND SECTOR OF BLOCK <09BC>
09B8 THEN TURN MOTOR OFF AND EXIT (C083)
09BB RETURN

***** DISKETTE SECTOR READ ROUTINE ***

09BC GET CURRENT TRACK
09BF CONVERT TO PHASE
09C5 GET CURRENT PHASE
09C7 STORE FOR PHASE OFF
09CA SUBTRACT PHASE WANTED TO DETERMINE....
09CC DIRECTION -- ON CORRECT TRACK NOW? >>09E2

ProDOS Loader -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 09D0

ADDR DESCRIPTION/CONTENTS

09D0 NO, ADJUST PHASE UP....
09D4 OR DOWN AND...

09D6 ---
09D7 SEEK ARM ONE PHASE... <096D>
09DD IN PROPER DIRECTION <096F>
09E0 UNTIL WE ARE THERE >>09C5
09E2 ---
09E4 RETRY COUNT OF 127
09E7 ---
09E9 LOWER RETRY COUNT
09EB RETRIES EXHAUSTED? >>09BB
09EF RETRIES FOR A \$D5 HEADER
09F2 CHECK DATA REGISTER (C08C)
09F5 LOOP UNTIL DATA IS VALID >>09F2

***** SECTOR READ ROUTINES *****

09F7 BEGINNING OF COPIED ROUTINES
(SEE \$C65E IN BOOT FIRMWARE DESCRIPTIONS)
(\$CX63-\$CXA IS COPIED TO \$9F7-\$A7E)

0A7F EXIT CODE FOR READ ROUTINES
(COPIED HERE FROM \$92B-\$930)

0A86 ***** \$A86-\$BFF NOT USED *****
0A86 NOT USED

0C00 ***** VOLUME DIRECTORY BUFFER *****

0C00 START OF VOLUME DIRECTORY BUFFER
0C23 OFFSET TO ENTRY LENGTH FIELD

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2000
 ADDR DESCRIPTION/CONTENTS

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2000
 ADDR DESCRIPTION/CONTENTS

2000 MODULE STARTING ADDRESS

 *
 * PRODOS RELOCATOR
 * LOADED AS THE FIRST
 * PORTION OF THE PRODOS
 * IMAGE AT \$2000.
 *
 * VERSION 1.2 -- 6 SEP 86
 *

***** ZERO PAGE ADDRESSES *****

000A AUTOSTART ROM CHECKSUM POINTER
 000B
 000C CONFIGURATION BYTE (MACHID TO BE)
 0010 GENERAL PURPOSE POINTER
 0011
 0012 DISK TYPE (0=DISK II, 4=PROFILE)
 0013 AND INPUT RELOC RANGE POINTER
 0014 VOL DIR ENTRY POINTER FOR RELOCATOR
 0015 AND OUTPUT RANGE PTR
 0016 LENGTH OF RELOCATION RANGE
 0017
 0018 INPUT RELOCATION RANGE POINTER
 0019
 001A END OF INPUT RANGE
 001B
 003C GENERAL PURPOSE POINTER
 003D
 003E GENERAL PURPOSE POINTER
 003F
 0040 RAMDRIVE OUTPUT POINTER
 0041
 0042 VARIOUS USES: PARM TO AUXMOVE,
 0043 UNIT/SLOT PASSED TO RELOCATOR
 0046 BLOCK NUMBER TO RAMDRIVE
 0047

***** EXTERNAL ADDRESSES *****

0080 MACHID BUILD SUBRTN FOR 128K
 0101 SAVE AUX STACK POINTER (IN AUX STACK)
 0280 GENERAL PURPOSE BUFFER
 0281 BUFFER+1

***** SCREEN LINE ADDRESSES *****

04B8 SCREEN BUFFER ROW 10
 05A9 SCREEN BUFFER ROW 12
 05AD SCREEN BUFFER ROW 12
 06B6 SCREEN BUFFER ROW 14
 07A8 SCREEN BUFFER ROW 16
 07AD SCREEN BUFFER ROW 16
 07D0 SCREEN BUFFER ROW 24

***** MISCELLANEOUS ADDRESSES *****

0800 ENTRY OF INTERP LOADER
 0C00 VOLUME DIRECTORY BUFFER
 0C23 ENTRY LENGTH
 -- RAMDRIVE VOLUME DIRECTORY --
 0E04 VOLUME HDR, VOLUME NAME
 0E22 VOLUME HDR, ACCESS-TOTAL BLOCKS
 2000 START OF SYSTEM PROGRAMS
 2C00 RAMDRIVE DEVICE DRIVER LOAD ADDRESS
 2A00 DIFFERENCE OF RAMDRIVE LOAD AND RUN LOCATIONS
 BFFF TOP OF 48K RAM

***** SYSTEM GLOBAL PAGE *****

BF00 ENTRY POINT FOR MLI
 BF03 QUIT VECTOR
 BF06 DATE/TIME
 BF10 DEVICE HANDLER TABLES
 BF30 LAST DEVICE USED
 BF31 NUMBER OF ACTIVE DISK DEVICES
 BF32 ACTIVE DISKS SEARCH LIST
 BF98 MACHINE TYPE FLAGS
 BF99 SLOT WHICH CONTAIN CARDS WITH ROM
 BFFF MLI VERSION NUMBER

***** I/O PORT ADDRESSES *****

C000 80 STORE OFF
 C001 80 STORE ON
 C002 READ MAIN RAM
 C003 READ AUX RAM
 C004 WRITE MAIN RAM
 C005 WRITE AUX RAM
 C008 MAIN STACK/ZERO PAGE
 C009 ALTERNATE STACK/ZERO PAGE
 C00A INTERNAL SLOT 3 ROM
 C00B PERIPHERAL SLOT 3 ROM
 C00C 80 COLUMN DISPLAY OFF
 C018 READ 80STORE SWITCH

ProDOS Relocator -- VI.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2000

ADDR DESCRIPTION/CONTENTS

C030 SPEAKER
C054 USE MAIN MEMORY PART OF 80-COL CARD
C055 USE AUX MEMORY PART OF 80-COL CARD
C068 IIGS STATEREQ STATUS BYTE
C081 WRITE-ENABLE HIGH RAM
C082 MOTHERBOARD ROM READ ENABLE
C083 READ/WRITE RAM 2ND 4K BANK
C08B READ/WRITE RAM 1ST 4K BANK

***** INTERNAL C3ROM ADDRESSES *****

C311 MOVE TO/FROM AUXMEM SUBROUTINE
C314 TRANSFER TO/FROM AUXMEM SUBROUTINE

***** SLOT ROM ADDRESSES *****

C305 SLOT3 I.D. BYTE
C307 SLOT3 I.D. BYTE
C30B SLOT3 I.D. BYTE
C30C SLOT3 I.D. BYTE
C3FA SLOT3 I.D. BYTE
C3FF RESET I/O CARD ROMS

***** PRODOS ADDRESSES *****

D000 START OF QUITCODE MEMORY AREA (BANK2)
DFB1 ENHANCED ROM FLAG
F0B8 VERSION NUMBER (FOR SUBDIRECTORIES)
FEFF GS VIDEO FLAG
FF00 RAMDRIVE CALLER ADDRESS

***** MONITOR ROM *****

FB1E PADDLE READ SUBROUTINE
FB2F MONITOR INIT ROUTINE
FBB3 ROM VERSION BYTE
FBC0 SECONDARY VERSION BYTE (0-3)
FC58 CLEAR SCREEN
FELF THIS ROUTINE CHECKS FOR IIGS
FE84 SET NORMAL VIDEO
FE89 IN#0
FE93 PR#0

2000 ***** PRODOS RELOCATOR MAIN ENTRY *****

2000 JUMP OVER PQUIT ENTRY >>2006
2003 SET FLAG INDICATING PQUIT ENTRY (IIGS) (21DI)
2006 STORE SLOT IN MLI ONLINE PARMS
200B PRINT "APPLE II PRODOS..." <25BI>
200E SET UP FOR COMMON MOVES (226E)
2014 RELOCATE SOME ROUTINES & DATA TO LOW MEMORY <28B0>

ProDOS Relocator -- VI.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2017

ADDR DESCRIPTION/CONTENTS

2017 RELOCATION ERROR >>203C
201D BE SURE 48K OF MAIN MEMORY EXISTS (BFFF)
2024 IF NOT, ERROR >>204E
2029 MAKE DOUBLY SURE (BFFF)
202C ERROR THIS TIME >>204E
202E SELECT MOTHERBOARD ROMS (C082)
2031 DETERMINE MACHINE TYPE <251F>
2036 PICK UP CONFIGURATION BYTE
2038 64K OR MORE MEMORY?
203A YES, WE HAVE 64K RAM >>203F
203C ERROR. MUST HAVE 64K OR MORE!! >>2227

***** RELOCATE PRODOS *****

203F SET UP FOR MLI MOVE (2270)
2045 COPY/RELOCATE PRODOS ITSELF <28B0>
2048 GET PRODOS VERSION NUMBER (BFFF)
204B AND PUT IT IN MLI DATA AREA. (FDB8)
204E RELOCATION ERROR! >>20AC
2050 ENABLE MOTHERBOARD ROMS AGAIN (C082)
2053 CHECK ROM I.D. BYTE (FBB3)
2056 APPLE //e FAMILY?
2058 NO, LEAVE I.D. BYTE AS IS >>208E
205C TEST ANOTHER ROM I.D. BYTE (FBC0)
205F SAVE BIT TEST RESULTS
2060 GET MACHID
2062 STRIP BITS THAT IDENTIFY MODEL
2067 IT'S A //e IF BITS 6 & 7 ARE HIGH >>2075
2069 ---
206A EITHER A //c OR A FUTURE SYSTEM
206C CHECK HIGH BITS OF \$FBC0 AGAIN
206D BIT 7 ON? >>2073
206F YES, FUTURE SYSTEM.
2073 IF BIT 6 ON, IT'S A FUTURE SYSTEM. >>2077
2075 ---
2077 REPLACE UPDATED MACHID
207D LOOK AT ROM. THIS A IIGS? <FELF>
2080 NO, CARRY STILL SET. >>208E
2082 YES, SET IIGS FLAG. (2278)
2085 ENTER FROM PQUIT? (21DI)
2088 YES, THIS IS NOT INITIAL BOOT. >>208E
NOW SET OS BOOT TO ZERO, INDICATING THAT PRODOS
WAS THE OPERATING SYSTEM INITIALLY BOOTED.

65816 INSTRUCTION: STA \$E100BD
208A COPY BOOT DEVICE ID TO READ BLOCK PARMS (2262)
208E AND AS LAST DEVICE USED (BF30)
2094 DETERMINE PERIPHERAL CARD CONFIGURATION <265F>
2097 BOOT DEVICE TO... (2269)
209A GLOBAL PAGE LAST DEVICE USED (BF30)
209D ENABLE READ/WRITE HIGH RAM, BANK 1 <2518>
20A0 COPY CLOCK CODE TO DEVICE DRIVER AREA <28B0>

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 20AC
 ADDR DESCRIPTION/CONTENTS

```

20AC  ERROR? >>20DA
20AE  CHECK MACHINE TYPE AGAIN (BF98)
20B1  GOT 64K OR MORE?
20B5  NO >>20DD
20B7  YES, QUIT VECTOR --> $FCA9
20C1  WRITE TO HIGH RAM (BANK2) (C083)
20CA  POINT TO QUIT CODE TABLE (2275)
20CD  MOVE QUIT CODE TO HIGH RAM <28B0>
20D2  STORE QUIT VECTOR START PAGE (D000)
20D5  ENABLE READ/WRITE HIGH RAM, BANK 1 <2518>
20DA  RELOCATION ERROR >>2227
20DD  GET MACHID YET AGAIN (BF98)
20E0  128K?
20E4  NO... >>20FC
20E6  YES, SET UP AUX RAM
20E8  SAVE STATUS REG IN ACCUM
20EA  DISABLE INTERRUPTS
20EB  PREPARE TO WRITE TO AUX STACK AREA (C009)
20EE  AUX STACK POINTER SET TO $FF (0101)
20F1  BACK TO MAIN Z-PAGE, STACK (C008)
20F4  RESTORE STATUS REG
20F9  ESTABLISH RAM DRIVE IN AUX MEM <2B00>

***** SET UP FOR IRQ (ENHANCED ROM) **

20FC  READ ROM (C081)
20FF  GET ROM'S IRQ VECTOR (FFFE)
2105  ENABLE READ/WRITE HIGH RAM, BANK 1 <2518>
2108  CARRY CLEAR IF IRQ VECTOR IN C3 ROM
210A  FLAG FOR "OLD ROM"
210C  IT'S AN OLD ROM >>2127
210E  SWITCH TO AUX STACK & HIGH RAM (C009)
2113  INITIALIZE AUX STACK POINTER TO $FF (0101)
2116  PUT IRQ VECTOR IN AUX HIGH RAM (FFFF)
211C  BACK TO MAIN HIGH RAM & Z-PAGE (C008)
211F  PUT IRQ VECTOR IN MAIN HIGH RAM (FFFF)
2125  INDICATE ENHANCED IRQ LOGIC ON BOARD
2127  STORE FLAG IN MLI DATA AREA (DFF1)

***** LOOK FOR SLOT 3 VIDEO CARD *****

---
212A  SET GS VIDEO FLAG=0 (FEFF)
212F  THIS A IIGS? (2278)
2132  NO. >>213A
2134  YES, SET GS VIDEO FLAG (IN MLI) (FEFF)
2137  AND DON'T BOTHER SEARCHING SLOT 3. >>21A5
213A  ENABLE INTERNAL VIDEO FIRMWARE (C00A)
213D  CHECK FOR ROM (BF99)
2140  IN SLOT 3.
2142  ROM EXISTS. >>2147

```

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2144
 ADDR DESCRIPTION/CONTENTS

```

2144  NO ROM. >>21AD
2147  LOOK AT THE SLOT 3 ROM (C00B)
214A  AT OFFSET +$05 (C305)
214D  THERE MUST BE A $38
2151  AND AT OFFSET +$07 (C307)
2154  THERE MUST BE AN $18
2158  AND AT OFFSET +$0B (C30B)
215B  THERE MUST BE A 1
215F  AND AT OFFSET +$0C (C30C)
2164  INDICATE AN 80-COL CARD.
2168  CHECK MACHINE TYPE (BF98)
216D  IS THIS AN APPLE III?
216F  OK, IT'S GOT 80-COL CAPABILITY >>21A5
2171  OTHER MANUFACTURERS MUST FOLLOW THE RULES! (C3FA)
2174  MUST HAVE BIT INSTRUCTION AT $C3FA
2176  GOOD BOY, YOU FOLLOWED THE RULES! >>21A5
2178  GIVE CONTROL BACK TO MOTHERBOARD ROM (C00A)
217B  TURN ON 80-COL (C001)
217E  CHECK FOR AUX MEM. (C055)
2183  PUT A BYTE AT AUX $400 (0400)
2186  THE ACCUMULATOR LEFT
2187  AND DO THE SAME WITH $400 (0400)
218A  STILL THE SAME? (0400)
218D  NO, NO 80-COL MEMORY >>2196
218F  SHIFT TO THE RIGHT
2193  STILL THE SAME? (0400)
2196  BACK TO MAIN MEMORY (C054)
2199  TURN OFF 80-COL (C000)
219C  WAS 80-COL MEMORY FOUND? >>21A5
219E  NO, SO TURN OFF 80-COL FLAG (BF98)
21A1  IN MACHINE I.D. BYTE.
21A3  ALWAYS BRANCH >>21AA
21A5  TURN ON 80-COL FLAG (BF98)
21AD  THIS A IIGS? (2278)
21B0  NO. >>21C8
21B2  YES, ENABLE IIGS CLOCK DRIVER
21B7  GET ADDRESS OF RELOCATE TABLE (2276)
21BA  FOR IIGS CLOCK CODE (2277)
21BD  AND PUT THE CODE AT $D742 <28B0>
21C0  INDICATE CLOCK EXISTS IN MACHID (BF98)
21C8  ENTER FROM PQUIT? (21D1)
21CB  NO. >>21D2
21CD  YES, ENABLE ROM FOR READ (C082)
21D0  RETURN

21D1  PQUIT FLAG. (0 = PRODOS 8 WAS INITIAL BOOT)

```

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 21D1

ADDR DESCRIPTION/CONTENTS

***** GET VOL LABEL *****

21D2 MLI: ONLINE DEVICE CALL <BF00>

21D8 ERROR? >>2227

21DD VALID VOLUME NAME?

21DF IF NOT, ERROR >>2227

21E2 ELSE, BUMP LENGTH BY ONE

21E7 AND PREFIX NAME BY A "/"

21EC MLI: SET PREFIX <BF00>

21F2 ERROR? >>2227

***** READ VOLUME DIRECTORY *****

21F4 ---

21F5 \$14/15 --> \$C00

21FB ---

2200 BLOCK = 2 (VOLUME DIRECTORY) (226C)

2206 MLI: READ BLOCK <BF00>

220C ERROR? >>2227

2210 GET NEXT BLOCK NUMBER

2216 IF ZERO, END OF VOLUME DIRECTORY >>2224

221E ADD TWO PAGES (ONE BLOCK) TO POINTER

2220 AND STOP AT \$1400 IN ANY CASE

2222 ELSE, READ NEXT BLOCK AS WELL >>21FB

2224 WHEN DONE, JUMP TO SYSTEM FILE LOADER >>0900

2227 ***** ERROR HANDLER *****

2227 ENABLE MOTHERBOARD ROMS (C082)

222A CLEAR SCREEN <FC58>

222F PRINT "RELOCATION/CONFIG ERROR" (223B)

2238 THEN SLEEP FOREVER >>2238

223B ***** DATA *****

223B ---

223B ** RELOCATION / CONFIGURATION ERROR **

2261 MLI: ONLINE PARMS

2262 SLOT*16 AND DRIVE

2263 READ THEM TO \$281

2265 MLI: SET PREFIX PARMS

2266 PREFIX IS AT \$280

2268 MLI: READ BLOCK PARMS

2269 DEVICE

226A BUFFER

226C BLOCK NUMBER

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 226C

ADDR DESCRIPTION/CONTENTS

226E ADDRESS OF COMMON MOVES RELOC TABLE

2270 ADDRESS OF PRODOS RELOC TABLE

2272 ADDRESS OF THUNDERCLOCK DRIVER RELOC TABLE

2274 ADDRESS OF QUIT CODE RELOC TABLE

2276 ADDRESS OF IIGS CLOCK DRIVER RELOC TABLE

2278 IIGS FLAG. IF NON-ZERO, THIS IS A IIGS.

2279 ***** RELOCATION TABLES *****

+0: 00 - ZERO BLOCK OF MEMORY

 01 - COPY BLOCK

 02 - RELOCATE MSB ADDRESSES

 03 - RELOCATE 2 BYTE ADDRS

 04 - RELOCATE INSTRUCTIONS

+1/2: ADDR OF OUTPUT BLOCK

+3/4: LENGTH OF BLOCK IN BYTES

+5/6: ADDR OF INPUT BLOCK (IF ANY)

+7: NUM RANGES TO CORRECT FOR (-1)

+8: START PAGES

+8+COUNT: END PAGE ADDRESSES

+8+COUNT+COUNT: ADDITIVE CORRECTION FACTOR

***** COMMON MOVES TABLE *****

2279 COPY (SYSTEM FILE LOADER)

227A TO = \$800

227C LEN = \$213

227E FRM = \$22DB

2280 COPY (PAGE 3 IMAGE)

2281 TO = \$3D6

2283 LEN = \$2A

2285 FRM = \$24EE

2287 COPY (CHECKSUM)

2288 TO = \$0A

228A LEN = \$02

228C FRM = \$14

228E COPY (CHECK FOR 80-COL CARD)

228F TO = \$80

2291 LEN = \$46

2293 FRM = \$256B

2295 END OF TABLE

***** QUIT CODE MOVE TABLE *****

2296 COPY (QUIT CODE)

2297 TO = \$D100

2299 LEN = \$300

229B FRM = \$5900

229D END OF TABLE

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 229D
 ADDR DESCRIPTION/CONTENTS

***** PRODOS RELOC TABLE *****

229E COPY (IRQ HANDLER)
 229F TO = \$FF9B
 22A1 LEN = \$65
 22A3 FRM = \$519B
 22A5 COPY (SYSTEM GLOBAL PAGE)
 22A6 TO = \$BF00
 22A8 LEN = \$100
 22AA FRM = \$5000
 22AC ZERO (PRODOS KERNEL DATA AREA)
 22AD ADR = \$D700
 22AF LEN = \$700
 22B1 COPY (PRODOS KERNEL)
 22B2 TO = \$DE00
 22B4 LEN = \$2100
 22B6 FRM = \$2F00
 22B8 COPY (DISKETTE DRIVER)
 22B9 TO = \$D000
 22BB LEN = \$700
 22BD FRM = \$5200
 22BF END OF TABLE

***** THUNDERCLOCK TABLE *****

22C0 COPY (THUNDERCLOCK CODE)
 22C1 TO = \$D742
 22C3 LEN = \$7D
 22C5 FRM = \$5100
 22C7 RELOCATE INSTRUCTIONS
 22C8 TO = \$D742
 22CA LEN = \$69
 22CC FRM = \$D742
 22CE FOR ADRES = \$CLXX-\$CLXX
 22D1 ADJUST BY = \$S0
 22D2 END OF TABLE

***** IIGS CLOCK TABLE *****

22D3 COPY (IIGS CLOCK CODE)
 22D4 TO = \$D742
 22D6 LEN = \$7D
 22D8 FRM = \$5C00
 22DA END OF TABLE

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 22DB
 ADDR DESCRIPTION/CONTENTS

22DB ***** SYSTEM FILE LOADER *****
 (COPIED TO AND RUN AT \$800)

22DB MLI: GET.FILE.INFO CALL <BF00>
 22DF FIRST SEE IF THERE IS AN A "ATINT" FILE
 22E1 NO ERRORS >>22EA
 22E3 IS ERROR "FILE NOT FOUND"?
 22E5 YES, THAT'S OK. >>232C
 22E7 NO, OTHER ERROR >>232F
 22EA GET FILE TYPE OF FILE FOUND (088D)
 22ED IS IT "ATINIT" FILE?
 22EF NO, ERROR >>232F
 22F1 MLI: OPEN CALL <BF00>
 22F7 FILE DOESN'T OPEN >>232F
 22F9 MLI: GET EOF CALL <BF00>
 22FF CAN'T FIND EOF >>232F
 2301 HIGH BYTE OF EOF (0A01)
 2304 FILE TOO BIG >>232F
 2306 MEDIUM BYTE OF EOF (0A00)
 2309 MAX FILE SIZE IS \$9800
 230B FILE TOO BIG >>232F
 230D PUT IN READ PARMS (0A07)
 2310 GET LOW BYTE OF EOF (09FF)
 2313 PUT IN READ PARMS (0A06)
 2316 MLI: READ CALL <BF00>
 231C READ ERROR >>232F
 231E MLI: CLOSE CALL <BF00>
 2324 CLOSE ERROR >>232F
 2326 READ ROM (C082)
 2329 GO TO APPLICATION <2000>
 232C NOW LOOK FOR SYSTEM FILE >>08A8
 232F PRINT ERROR MESSAGE: (233D)
 2332 "UNABLE TO LOAD ATINIT FILE" (233D)
 233B SLEEP FOREVER >>233B
 233D MSG LENGTH
 233E "*** UNABLE TO LOAD ATINIT FILE ***"
 2364 GET FILE INFO PARMS (FOR ATINIT FILE)
 (LOCATED AT \$889 WHEN EXECUTED)
 2365 PATHNAME ADDRESS
 2368 FILE TYPE
 2376 OPEN PARMS FOR ATINT FILE
 (AT \$89B WHEN EXECUTED)
 2377 PATHNAME ADDRESS
 2379 I/O BUFFER AT \$1400
 237B REFNUM=1

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 237B

ADDR DESCRIPTION/CONTENTS

```

237C ---
237D "ATINIT"

2383 ***** LOOK FOR NORMAL SYSTEM FILE *****
      (THIS CODE EXECUTES AT $8A8)

2383 $10/11 --> VOLUME DIRECTORY ENTRIES
2385 INITIALLY AT $C00
2387 OFFSET BEYOND LINKS (+4)
2389 JUMP OVER NEXT INSTRUCTION >>238D

      ***** SCAN DIRECTORY FOR SYSTEM FILE *

238B PICK UP LSB
238D ---
238E BUMP BY ENTRY LENGTH (0C23)
2391 UPDATE LSB
2393 PAGE OVERFLOW? >>23A7
2395 NO, ROOM FOR ONE MORE ENTRY? (0C23)
239A NO, CHECK MSB
239D START OF A BLOCK? >>23A9
239F NO, AT END OF DIRECTORY?
23A1 YES, FILE NOT FOUND IN DIRECTORY >>23C1
23A3 NO, START NEW BLOCK AT +4
23A5 AND UPDATE LSB
23A7 BUMP MSB
23A9 ---
23AD "SYSTEM" FILE TYPE?
23AF NO, TRY ANOTHER. >>238B
23B2 INACTIVE ENTRY?
23B4 IF SO, SKIP IT >>238B
23B8 SAVE NAME LENGTH AT $280 (0280)
23BD MUST BE AT LEAST 8 CHARS LONG >>238B
23BF JUMP AROUND ERROR CODE >>23C3
23C1 ERROR - SYSTEM FILE NOT FOUND >>2430

23C3 ---
23C6 IS THIS ".SYSTEM"?
23C8 (SEE $24E7) (0A0C)
23CC NO, SKIP ENTRY >>238B
23D0 CHECK ALL CHARACTERS IN NAME >>23C6

      ***** LOAD SYSTEM FILE AT $2000 *****

23D2 ---
23D4 ---
23D5 COPY NAME TO $281
23DC AND TO "UNABLE TO LOAD" MSG (09E2)
23E4 ADD BLANK AT END OF NAME
23E6 IN MESSAGE (09E3)

```

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 23EA

ADDR DESCRIPTION/CONTENTS

```

23EA NAMELEN + ERRORMSGLEN
23EC SAVE AT $24D1 (09F6)
23EF MLI: OPEN .SYSTEM FILE <BF00>
23F5 OPEN ERROR >>243D
23F7 MLI: GET EOF <BF00>
23FD CAN'T GET EOF >>243D
23FF GET HIGH BYTE (0A01)
2402 FILE TOO BIG! >>2457
2404 GET MEDIUM BYTE (0A00)
2407 MUST BE LESS THAN $9800 BYTES
2409 TOO BIG. >>2457
240B STORE LENGTH IN MLI READ PARMS (0A07)
240E GET LOW BYTE (09FF)
2411 AND STORE IN READ PARMS. (0A06)
2414 MLI: READ SYSTEM FILE INTO $2000 <BF00>
241A NO READ ERRORS >>2422
241C ERROR, BAD BUFFER?
241E YES, FILE WAS TOO LARGE >>2457
2420 ELSE, "UNABLE TO LOAD ..." >>243D
2422 MLI: CLOSE SYSTEM FILE <BF00>
2428 CLOSE ERROR >>243D
242A ENABLE MOTHERBOARD ROM (C082)
242D AND JUMP TO BEGINNING OF FILE >>2000

2430 ***** ERROR HANDLERS *****
2430 ---
2432 PRINT "UNABLE TO FIND A .SYSTEM FILE" (0989)
243B THEN GO TO SLEEP >>2462

243D GET NAME LENGTH (09F6)
2440 LINE LENGTH
2443 LESS NAME LENGTH (09F6)
2446 DIVIDED BY 2
2447 GIVES OFFSET TO CENTER THE LINE (09F6)
244B PRINT "UNABLE TO LOAD ..." (09D1)
2455 GO TO SLEEP FOREVER >>2462

2457 ---
2459 PRINT "SYSTEM PROGRAM TOO LARGE" (09B1)
2462 GO TO SLEEP FOREVER >>2462

2464 ***** DATA AREA *****
2464 '** UNABLE TO FIND A ".SYSTEM" FILE **
248C '** SYSTEM PROGRAM TOO LARGE **
24AC '** UNABLE TO LOAD X.SYSTEM *****
24D1 NAME LEN +13H (LEN OF MSG)

```

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 24D1

 ADDR DESCRIPTION/CONTENTS

24D2 MLI: OPEN PARM LIST (AT \$9F7 WHEN EXECUTING)
 24D3 PATHNAME IS AT \$280
 24D5 I/O BUFFER AT \$1400
 24D7 REFNUM=1

24D8 MLI: GET EOF PARM LIST (AT \$9FD)
 24D9 REFNUM=1
 24DA EOF MARK POSITION

24DD MLI: READ LIST (AT \$A02)
 24DE REFNUM=1
 24DF READ INTO \$2000
 24E1 LENGTH (FROM EOF MARK)
 24E3 ACTUAL LENGTH READ

24E5 MLI: CLOSE LIST (AT \$A0A)
 24E6 REFNUM=0, CLOSE ALL FILES

24E7 '.SYSTEM'

24EE ***** END OF SYSTEM FILE LOADER *****

24EE ***** PAGE 3 VECTOR IMAGE *****

(INCLUDES A ROUTINE AT \$3D6 THAT IS USED
 TO CALL A DEVICE DRIVER IN AUX HIGH RAM)

24EE FROM MAIN Z-PAGE, (C008)
 24F1 GET X+1 VALUES STARTING AT \$42
 24F3 AND PUT IN AUX Z-PAGE (C009)
 24F6 AT SAME LOCATION.

THE NEXT THREE BYTES (AT \$3E3) ARE PATCHED
 WITH A JUMP TO A DEVICE DRIVER IN AUX
 HIGH RAM WHEN THE DRIVER IS INSTALLED.
 "NO DEVICE CONNECTED" ERROR (IF NOT INSTALLED)
 BACK TO MAIN Z-PAGE (C008)
 2501 RETURN

2502 ADDRESS OF MLI ROUTINE THAT CALLS
 THE RAM-BASED DEVICE DRIVER. THIS
 ADDRESS IS USED AS THE INSTALLED
 DRIVER'S ADDRESS IN THE GLOBAL PAGE.

2508 BRK HANDLER AT \$FA59

250A RESET AT \$FF59

250C POWER UP BYTE

250D & VECTOR TO \$FF59 >>FF59

2510 CTL-Y VECTOR TO \$FF59 >>FF59

2513 NMI VECTOR TO \$FF59 >>FF59

2516 IRQ HANDLER AT \$8FEB (GLOBAL PAGE)

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2518

 ADDR DESCRIPTION/CONTENTS

2518 ***** SET HIGH RAM FOR READ/WRITE *****
 2518 TWO READS OF \$C08B (C08B)
 251E RETURN

251F ***** DETERMINE MACHINE ID *****
 \$0C=00..0... APPLE II
 01..0... APPLE II+
 10..0... APPLE Iie or IIGS
 10..1... APPLE IIC
 11..0... APPLE /// EMULAT.
 ..01.... 48K RAM
 ..10.... 64K RAM
 ..11.... 128K RAM
 1.. 80 COL CARD
 1..1 COMPATIBLE CLOCK

251F ASSUME NOTHING AT FIRST
 2523 GET A ROM BYTE (FBB3)

2526 APPLE II?

2528 YES, SET BIT >>254B

252A NO,

252C APPLE IIE OR IIGS?

252E YES, SET BIT >>254B

2530 NO,

2532 APPLE II+?

2534 NO, STRANGE ROW! >>2545

2539 REALLY A II+?

253B YES >>254B

253F /// EMULATION MODE?

2543 ---

2544 RETURN

2545 OTHERWISE, UNKNOWN MACHINE

2547 CREATE INVALID INSTR AT \$80

2549 AND GO THERE >>2568

254B UPDATE MACHID

254D READ/WRITE ENABLE HIGH RAM (BANK1) <2518>

2552 SEE IF HIGH RAM EXISTS (D000)

2564 IF PRESENT, MARK IN MACHID

256B ***** LOOK FOR AUXILIARY RAM *****
 (CODE MOVED TO \$80 TO ALLOW BANK SWITCH)
 (ENTERED WITH MACHID IN ACCUMULATOR)

256B UPDATE MACHID

256D IF PLUS, IS II OR II+ >>25A4

256F IT'S A Iie OR LATER. CHECK FOR 128K.

2571 BANK TO AUX MEMORY (C005)

2577 STORE A PATTERN AT \$C00 (0C00)

257A AND AT \$800 (0800)

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2580

ADDR DESCRIPTION/CONTENTS

```

2580 MAKE SURE PATTERN STAYS THERE
2582 IT DIDN'T! >>2592
2584 NOW SHIFT $C00 TO THE LEFT (0C00)
2587 AND SHIFT THE ACCUM TO THE LEFT
2588 ARE THEY STILL THE SAME? (0C00)
258B NO, AUX RAM NOT THERE. >>2592
258D DID $0800 MOVE TOO? (0800)
2590 NO, SO WE HAVE FULL 128K! >>2595
2592 DON'T HAVE 128K
2595 ---
2596 BANK BACK TO MAIN MEMORY (C004)
259C ONLY 64K >>25A4
25A0 NO, INDICATE 128K
25A2 IN MACHID
25A4 SET UP $A/B --> "APPLE II"
25A6 IN MOTHERBOARD ROM AT $FB09
25A9 $B NOW $FB
25AB SOMETHING WRONG >>25AF
25AD $A NOW $09
25AF ---
25B0 RETURN TO CALLER

25B1 ***** DISPLAY LOAD MESSAGE *****
25B1 CLICK SPEAKER (C030)
25B4 STORE IN MAIN MEMORY (C00C)
25B7 80 COL DISPLAY OFF (C000)
25BA SET NORMAL VIDEO <FE84>
25BD CALL MONITOR INITIALIZATION <FB2F>
25C0 SET VIDEO PR#0 <FE93>
25C3 SET KEYBD IN#0 <FE89>
25C6 OUT OF DECIMAL MODE
25C7 CLEAR SCREEN <FC58>
25CC PRINT "APPLE //" (25FA)
25D7 PRINT "PRODOS 8 " ETC. ON ROW 12 (2602)
25E2 PRINT 12 BLANKS ON ROW 14 (2620)
25ED PRINT "COPYRIGHT" ETC. ON ROW 24 (262C)
25F6 CLICK SPEAKER AGAIN (C030)
25F9 DONE

25FA ***** DATA AREA *****
25FA 'APPLE //'
2602 'PRODOS 8 V1.2 06-SEP-86'
2620 '
262C 'COPYRIGHT APPLE COMPUTER, INC., 1983-86'

```

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2650

ADDR DESCRIPTION/CONTENTS

```

2653 8 BYTES FOR SMARTPORT STATUS CALL
265B DRIVER ADDRESS
265D SPACES LEFT ON DEVICE LIST
265E SLOT 2 FLAG (0 = PRODOS STORAGE DEVICE IN SLOT 2)

```

265F ***** DETERMINE SLOT CONFIGURATION *****

```

265F ---
2661 ZERO SOME THINGS
2663 DEVCNT=$FF (NO DEVICES YET) (BF31)
266B ALL 14 DEVICES ARE UNASSIGNED
2670 FIRST CHECK SLOT 2
2674 IS A STORAGE DEVICE IN SLOT 2? <2898>
2677 IF NOT, SET A FLAG (265E)
267A NOW POINT TO SLOT 7
267E STORAGE DEVICE IN SLOT? <2898>
2681 NO. >>26DF
2683 GET $CSFF BYTE
2685 LOOKS LIKE 16 SECTOR DISK II. >>26AC
2687 LOOK LIKE 13 SECTOR DISK II?
2689 YES, DON'T USE IT. >>26DF

```

***** NON-DISK II STORAGE DEVICE *****

```

268B $CSFF BYTE = LOW BYTE OF DEVICE ADDRESS (265B)
268E CHECK BYTE AT OFFSET 7
2690 TO SEE IF IT'S A SMARTPORT
2692 NOT A SMARTPORT INTERFACE >>2697
2694 GO DO SMARTPORT STUFF >>2844
2697 ---
2699 GET $CSFE (STATUS BYTE)
269B CAN WE AT LEAST READ STATUS AND DATA?
269F ANTICIPATE FAILURE
26A0 CAN'T READ IT. NO SENSE USING IT. >>26DF
26A2 PUT LEFT NIBBLE OF STATUS BYTE IN $12 <288D>
26A6 PUSH CLC, INDICATING ONE DRIVE
26A7 CARRY SET IF 2 OR 4 DRIVES
26A8 GET HIGH BYTE OF SLOT ROW
26AA ALWAYS BRANCH INTO DISK II PROCESSING >>26B9

```

***** LOOKS LIKE A DISK II *****

```

26AC $12 = 0 FOR DISK II
26AF PUSH SEC ON STACK (DISK II HAS 2 DRIVES)
26B0 GET LOW BYTE OF DISK II DRIVER ($00) (27D8)
26B3 SAVE IT IN RELOC DATA AREA (265B)
26B6 GET HIGH BYTE OF DISK II DRIVER ($D0) (27D9)

```

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 26B6
 ADDR DESCRIPTION/CONTENTS

***** COMMON PROCESSING *****

26B9 SAVE DEVICE ADDRESS HIGH BYTE (265C)
 26BC ESTABLISH DEVICE DRIVER IN GLOBAL PAGE <2814>
 26BF ONLY ONE DRIVE?
 26C0 YES, GO TO NEXT SLOT >>26DE
 IF TWO DRIVES WERE ASSIGNED, MOVE THEM TO
 THE BOTTOM OF THE LIST IN REVERSE ORDER

26DE

 CARRY IS NOW CLEAR IF A PRODOS STORAGE DEVICE
 WAS FOUND IN THIS SLOT. OTHERWISE, CARRY IS SET.
 GO MARK SLTBYT TO SHOW ROMS IN SLOT <2768>

26E2 MOVE DOWN ONE SLOT
 26E8 WE'VE DONE ALL SLOTS >>26ED
 26EA CHECK NEXT SLOT >>267E
 26F3 STASHED ANY DEVICES AT BOTTOM OF LIST? (265D)
 26F6 NO. >>271A
 26F8 YES, MOVE THEM BACK
 2700 IN REVERSE ORDER.
 2715 DONE WHEN X=Y (265D)

271A

 271C START AT BOTTOM OF SEARCH LIST (BF31)
 271F GET A DEVICE FROM LIST (BF32)
 2722 PUT IT ON THE STACK
 2725 IS IT THE CURRENT SLOT? (BF30)
 2729 NO, KEEP LOOKING >>272D
 272B YES, TAKE IT OFF THE STACK
 272C INDICATE CURRENT SLOT FOUND

272D

 272E MORE TO CHECK >>271F
 2730 GET DEVICE COUNT (BF31)
 2734 CURRENT SLOT NOT FOUND! >>274A
 2736 PUT CURRENT DRIVE AT (BF30)
 2739 BOTTOM OF SEARCH LIST (BF32)
 273D ONLY ONE DEVICE ON LIST >>2751
 2740 ONLY ONE DRIVE ON BOOT SLOT >>274A
 2742 CHANGE DRIVE NUMBER
 2744 STORE OTHER DRIVE NEXT TO LAST (BF32)
 2748 CURRENT SLOT ONLY SLOT ON LINE >>2751
 274A GET OTHER DEVICES
 274B MOVE THEM AHEAD OF CURRENT DRIVE (BF32)
 274F STILL MORE TO DO >>274A

2751 DO CHECKSUM ON ROM <27EA>
 2754 DOESN'T SAY "APPLE II"! >>275A
 2756 WE'RE HAPPY, STORE FINISHED MACHID (BF98)
 2759 AND LEAVE
 275A UNKNOWN MACHINE, SO DIE HORRIBLY! >>2545

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 275A
 ADDR DESCRIPTION/CONTENTS

***** PUT A DEVICE ON DEVICE LIST *****

275D
 275D COMBINE DSSS with I111
 2762 BUMP DEVICE COUNT BY ONE
 2763 AND ADD DRIVE TO SYSTEM SEARCH LIST (BF32)
 2766 ROLL LEFT ANTICIPATING ROLL RIGHT
 2767 RETURN

***** IDENTIFY I/O CARD *****

2768
 2768 WE ALREADY FOUND ROM IN THIS SLOT >>27C9
 276C CHECK SIGNATURE ON CARD FOR THUNDERCLOCK
 2771 NOT IT >>278D
 2777 THUNDERCLOCK, WHICH SLOT?
 2779 SAVE SLOT NUMBER (LESS 1)
 277B IN CLOCK CODE RELOCATION TABLE (22D1)
 2780 ENABLE CLOCK/CALENDAR JUMP IN GLOBALS (BF06)
 2785 NO MACHID! >>2751
 2787 INDICATE THAT A CLOCK IS PRESENT
 2789 AND UPDATE MACHID
 278B GO MARK ROM IN THIS SLOT >>27C9
 CHECK FOR PASCAL 1.1 PROTOCOL

278D

 2791 \$Cs05 = \$38?
 2793 DOESN'T GET TO FIRST BASE >>27B8
 2799 \$Cs07 = \$18?
 279B NO. >>27B8
 27A1 \$Cs0B = \$01?
 27A3 NO, BAD SIGNATURE >>27B8
 27A8 YES, GET LEFT NIBBLE
 27AA 80 COLUMN CARD?
 27AC NO, UNKNOWN CARD >>27B8
 27B0 NO MACHID! >>2751
 27B2 MARK 80 COLUMN CARD PRESENT
 27B4 AND UPDATE MACHID
 27B6 GO MARK ROM IN THIS SLOT >>27C9

27B8 UNKNOWN CARD, CHECK ROM TO
 27BC SEE IF IT WILL HOLD A VALUE
 27C2 FOR SOME TIME.

27C9 WE FOUND ROM IN THIS SLOT
 27CB CONVERT SLOT NUMBER
 27CE TO A BIT POSITION (27E2)
 27D1 AND OR INTO SLTBYT (BF99)
 27D7 RETURN TO CALLER

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 27D7

ADDR DESCRIPTION/CONTENTS

27D8 ***** DATA AREA *****

27D8 DISK II DEVICE DRIVER ENTRY POINT

27DA DEVICE SIGNATURE FOR:

27DC +0,+2,+4,+6 = THUNDERCLOCK

27DE +1,+3,+5,+7 = DISK

27E0 (+7 NOT CHECKED)

27E2 BIT POSITION TABLE FOR SLOTS

27E5 (ALSO USED IN CHECKSUM CALCS)

27EA ***** COMPUTE AUTOSTART ROM CHECKSUM *****

27EA ---

27EB GET ZERO IN INDEX REGISTER (27E2)

27EE POINT TO \$FB09 ("APPLE II" IN ROM)

27F0 MAKE SURE UPPER CASE

27F5 UPDATE CHECKSUM (27E2)

27F8 PUT HIGH BIT IN CARRY (27E2)

27FC DO 8 BYTES IN ALL (27E5)

2801 ACCUM = \$08

2805 ACCUM = \$80

2807 TURN ON HIGH BIT (27E2)

280A ADD A FUDGE FACTOR

280C OH NO! A CLONE! >>2811

280E PASSED THE TEST...RETURN WITH MACHID

2810 RETURN

2811 ELSE, RETURN WITH ZERO MACHID

2813 RETURN

2814 ***DEVICE DRIVER IN GLOBAL PAGE *****

2814 SAVE CARRY (NUMBER OF DRIVES)

2815 GET HIGH BYTE OF SLOT ADDRESS

2817 MAKE IT SLOT NUMBER

2819 TIMES 2

281A USE LATER IN Y-REG

281B NOW GET SLOT*16 IN ACCUM

281D NOW HAVE 0SS0000 (DRIVE 1)

281E PUT DEVICE ID ON DEVICE LIST <275D>

2821 GET BACK CARRY (NUMBER OF DRIVES)

2822 ROLL CARRY INTO ACCUM

2823 ONLY ONE DRIVE. >>2829

2825 TWO DRIVES. BUMP DEVICE COUNT

2826 AND PUT SECOND DRIVE ON SEARCH LIST (BF32)

2829 STORE FINAL DEVICE COUNT (BF31)

282C SHIFT DRIVE INDICATOR BACK TO CARRY

282D GET LOW BYTE OF DEVICE DRIVER ADDRESS (265B)

2830 PUT IN GLOBAL PAGE FOR DRIVE 1 (BF10)

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2833

ADDR DESCRIPTION/CONTENTS

2833 ONLY ONE DRIVE >>2838

2835 PUT IN GLOBAL PAGE FOR DRIVE 2 (BF20)

2838 GET HIGH BYTE OF DEVICE DRIVER ADDRESS (265C)

283B PUT IN GLOBAL PAGE FOR DRIVE 1 (BF11)

283E ONLY ONE DRIVE >>2843

2840 PUT IN GLOBAL PAGE FOR DRIVE 2 (BF21)

2843 RETURN

2844 ***** HANDLE SMART PORT *****

2844 PUT LEFT NIBBLE OF STATUS BYTE IN \$12 <288D>

2847 GET HIGH BYTE OF SLOT ROM ADDRESS

2849 STORE IT IN RELOC DATA AREA (265C)

284C GET PRODOS ENTRY, LOW BYTE (265B)

2850 ADD THREE TO GET SMARTPORT ENTRY

2852 POKE INTO SMARTPORT CALL (285C)

2858 POKE THE HIGH BYTE, TOO. (285D)

285B SELF MODIFIED TO CALL THE SMARTPORT <0000>

285E WITH A STATUS COMMAND.

285F PARMLIST AT \$28AB

2861 GET NUMBER OF DEVICES ON LINE (2653)

2864 NONE ON LINE! >>288A

2866 INDICATE IF DRIVE 2 EXISTS.

2868 PUT DRIVER ADDRESS IN GLOBAL PAGE <2814>

286D IS THIS SLOT 5?

286F NO. >>288A

2871 SLOT 2 BEING USED BY STORAGE DEVICE? (265E)

2874 YES, TWO DRIVES IS ALL YOU GET! >>288A

2876 GET NUMBER OF DEVICES AGAIN (2653)

2879 MORE THAN TWO DRIVES?

287B NO. >>288A

287D SET CARRY IF DRIVE 4 EXISTS.

287F PUT THEM IN SLOT 2

2883 PUT DRIVER ADDRESS IN GLOBAL PAGE <2814>

288A GO PROCESS NEXT SLOT >>26DE

288D ***** CONVERT STATUS FOR ID BYTE *****

288D GET STATUS BYTE

2891 SHIFT LEFT NIBBLE TO RIGHT NIBBLE

2895 PUT IT IN \$12

2897 RETURN

2898 ***** CHECK FOR PRODOS STORAGE DEVICE *****

2898 RESET I/O CARD ROMS (CFFF)

289D CHECK 3 BYTES ON CONTROLLER ROM

28A2 ANTICIPATE FAILURE

28A3 NOT A PRODOS STORAGE DEVICE >>28AA

28A9 SUCCESS--THIS IS A PRODOS STORAGE DEVICE.

28AA RETURN

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 28AA
 ADDR DESCRIPTION/CONTENTS

28AB ***** COMMAND LIST FOR SMARTPORT CALL *****

28AB 3 PARAMETERS
 28AC OVERALL STATUS CALL
 28AD PUT STATUS DATA AT \$2653
 28AF STATUS CODE IS \$00

28B0 ***** RELOCATION ROUTINE *****
 (X/Y REGS CONTAIN TABLE ADDR)

28B0 SAVE PASSED TABLE ADDRESS
 28B4 ACCESS IIGS STATEREGBYTE TO (C068)
 28B7 TURN OFF SLOT ROM, ENSURE ROM BANK 0
 28BC ---
 28BE GET OPERATION CODE
 28C0 VALID OPERATION? (4 OR LESS)
 28C2 NO, ERROR >>2936
 28C6 \$14/15 --> OUTPUT BLOCK
 28D0 \$16/17 --> LENGTH
 28D9 NEGATIVE LENGTH? >>2938
 28DB CHECK OPERATION CODE
 28DC ZERO BLOCK? >>2941
 28DF NO, \$12/13 = \$18/19 --> INPUT BLOCK
 28E9 \$1A/1B --> END OF INPUT BLOCK
 28F6 COPY BLOCK ONLY? >>2965
 28F8 SAVE RELOCATION OPERATION CODE (2A8F)
 28FE SAVE NUMBER OF RANGES TO CHECK (2A90)
 2902 ---
 2903 COPY START PAGES TO TABLE
 290E ---
 290F AND END PAGES
 291A ---
 291B AND FINALLY, RELOCATION FACTORS
 2923 BUMP TO NEXT TABLE ENTRY <296B>
 2926 RESTORE OPERATION CODE (2A8F)
 292B RELOCATE INSTRUCTIONS? >>293B

292D ***** 2/3 - RELOCATE ADDRESSES *****

292D NO, RELOCATE ADDRESS <29CD>
 2930 COPY BLOCK <2976>
 2933 AND CONTINUE IF ALL WENT WELL >>28BC
 2936 NORMAL EXIT
 2937 RETURN
 2938 JUMP TO ERROR EXIT >>2A03

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2938
 ADDR DESCRIPTION/CONTENTS

293B ***** 4 - RELOCATE INSTRUCTIONS *****

293B RELOCATE INSTRUCTIONS <29DF>
 293E AND THEN COPY BLOCK >>2930

2941 ***** 0 - ZERO BLOCK *****

2941 BUMP TABLE POINTER TO NEXT ENTRY <296B>
 2946 GET NUMBER OF PAGES TO DO
 2948 NO FULL PAGES? >>2956
 294B ZERO AN ENTIRE PAGE
 2950 BUMP PAGE POINTER
 2952 AND DECREMENT LENGTH
 2956 GET LENGTH OF PARTIAL LAST PAGE
 2958 NO PARTIAL PAGE? >>2962
 295B ZERO PARTIAL PAGE TOO
 2962 DONE, GET NEXT TABLE ENTRY >>28BC

2965 ***** I - COPY BLOCK *****

2965 BUMP TABLE POINTER <296B>
 2968 AND GO COPY BLOCK >>2930

296B ***** ADVANCE TABLE POINTER *****

296B ADD FINAL ENTRY INDEX..
 296F TO TABLE ENTRY ADDRESS
 2975 RETURN

2976 ***** COPY BLOCK *****

2976 ---
 297A INPTR < OUTPTR? >>2987
 297C NO, GREATER? >>29AA
 297E MSB'S ARE EQUAL, CHECK LSB'S ALSO
 2986 EXIT IF EQUAL
 2987 INPTR < OUTPTR, COPY LAST PAGES FIRST
 298B BUMP BOTH INPTR AND OUTPTR BY...
 298D LENGTH-1 TO POINT AT LAST BYTE
 2995 START WITH SHORT LAST PAGE LENGTH
 2999 ---
 299A COPY BYTES BACKWARDS THROUGH MEMORY
 29A1 DROP ADDRESSES AND LENGTH BY 256
 29A7 AND CONTINUE UNTIL FINISHED >>2999
 29A9 RETURN

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 29A9

ADDR DESCRIPTION/CONTENTS

```

29AA INPTR > OUTPTR, COPY PAGES FORWARD
29AC HOW MANY FULL PAGES LEFT?
29AE NONE? >>29BF
29B0 COPY A FULL PAGE
29B7 AND BUMP ADDRESSES
29BB DECREMENT LENGTH BY 256
29BD AND DO ALL PAGES >>29B0
29BF GET LENGTH OF LAST PAGE
29C1 EVEN PAGE BOUNDARY? >>29CC
29C3 NO, COPY SHORT LAST PAGE
29CC RETURN

```

29CD ***** ADDR/PAGE RELOCATE *****

```

29CD GET TABLE ENTRY TYPE (2A8F)
29D1 GET PAGE TO RELOCATE
29D3 RELOCATE A SINGLE ADDRESS <2A0B>
29D6 BUMP BY 1 OR 2 BYTES (2A8F)
29D9 ADVANCE POINTER <2A27>
29DC AND CONTINUE UNTIL COMPLETE >>29CD
29DE RETURN

```

29DF ***** INSTRUCTIONS RELOCATE *****

```

29DF ---
29E1 GET 6502 OPCODE
29E3 COMPUTE INSTRUCTION LENGTH <2A3A>
29E6 INVALID OPCODE? >>29F9
29E8 3 BYTE INSTRUCTIONS?
29EA NO >>29F3
29EC YES, 3 BYTE ADDRESS TO CORRECT
29EE RELOCATE ADDRESS <2A0B>
29F1 AND ADVANCE BY 3 BYTES
29F3 NEXT INSTRUCTION <2A27>
29F6 CONTINUE UNTIL FINISHED >>29DF
29F8 RETURN

```

***** INVALID OPCODE *****

```

29F9 POP THE STACK
29FB RETURN WITH POINTER TO BAD INSTRUC.
29FF DIE HORRIBLY
2A02 RETURN

```

2A03 ***** ERROR RETURN *****

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2A03

ADDR DESCRIPTION/CONTENTS

```

2A03 RETURN WITH POINTER
2A07 EXIT WITH ERROR CODE
2A0A RETURN

```

2A0B ***** RELOCATE ABSOLUTE ADDRESS *****

```

2A0B GET PAGE NUMBER TO CHECK
2A0D GET NUMBER OF RANGES (LESS ONE) (2A90)
2A10 IS IT PRIOR TO START OF THIS RANGE? (2A91)
2A13 YES? >>2A1C
2A15 NO, IS IS AFTER END OF RANGE? (2A99)
2A18 NO? >>2A20
2A1C ---
2A1D CHECK EACH RANGE >>2A10
2A1F RETURN

```

```

2A20 ---
2A21 ADD FUDGE FACTOR TO ADDRESS (2AA1)
2A24 AND UPDATE IT
2A26 RETURN

```

2A27 ***** BUMP POINTER TO NEXT ADDR *****

```

2A27 ---
2A28 ADD LENGTH TO POINTER
2A2F CHECK TO SEE IF WE ARE DONE
2A35 ---
2A39 RETURN

```

2A3A ***** COMPUTE INSTRUCTION LENGTH *****

```

2A3A A-REG CONTAINS OPCODE
2A3B ISOLATE LAST TWO BITS FOR LATER
2A40 USE LAST 6 BITS AS TABLE INDEX
2A42 GET BYTE WITH 4 LENGTHS IN IT (2A4F)
2A45 ---
2A46 USING TOP TWO BITS AS INDEX... >>2A4C
2A48 SHIFT DOWN THE PROPER LENGTH
2A4C AND ISOLATE IT IN A-REG
2A4E RETURN

```

2A4F ***** 6502 OP LENGTH TABLE *****
EACH BYTE CONTAINS FOUR 2 BIT LENGTHS

2A4F ---

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2A8B

 ADDR DESCRIPTION/CONTENTS

2A8F ***** RELOCATION DATA *****

2A8F RELOCATION CODE (3,2,1)
 2A90 NUMBER OF RANGES
 2A91 START OF RANGE PAGES
 2A99 END OF RANGE PAGES +1
 2AA1 ADDITIVE FACTORS

2AA9 ***** 2AA9-2AFF NOT USED *****

2AA9 NOT USED
 2AEC

2B00 ***** SET UP RAMDRIVE IN AUXMEM *****
 (THIS ROUTINE PUTS THE RAMDRIVE DEVICE DRIVER
 IN MEMORY, PUTS THE ADDRESS OF THE DRIVER
 IN THE DEVICE DRIVER ADDRESS LIST, AND
 ADDS THE RAMDRIVE TO THE ONLINE DEVICE LIST.)

2B00 ---
 2B02 RELOCATE RAMDRIVE CALLER NOW AT.. (2E00)
 2B05 TO HIGH RAM AT.. (FF00)
 2B0D NOW PREPARE TO MOVE
 2B0F RAMDRIVE DEVICE DRIVER
 2B11 INTO AUX RAM AT \$200.
 2B14 \$3C/\$3D --> \$2C00
 2B18 \$3E/\$3F --> \$2DEF
 2B1D \$42/43 --> \$200
 2B23 COPY MAIN MEM TO AUX MEM
 2B24 USE AUXMOVE TO COPY IT <C311>
 2B29 SLOT 3, DRIVE 2 DEVICE DRIVER.. (BF26)
 2B2C IS AT \$FF00
 2B31 BUMP DEVICE COUNT {BF31}
 2B37 ADD DEVICE TO ONLINE DEVICE LIST
 2B3C RETURN

2B3D ***** 2B3D-2BFF NOT USED *****

2B3D ---
 2B7D

2C00 ***** RAMDRIVE (/RAM) DEVICE DRIVER *****
 (COPIED TO AND RUN AT \$200 IN AUX RAM)
 (THIS IS THE MAIN PART OF THE DEVICE DRIVER.
 IT IS CALLED BY THE RAMDRIVE CALLER
 WHICH IS LOCATED AT \$FF00 IN MAIN MEMORY.)

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2C00

 ADDR DESCRIPTION/CONTENTS

2C00 SAVE THE 80STORE SETTING (C018)
 2C04 FORCE RAM READ/WRITE (C000)
 2C09 COPY INPUT PARAMETERS
 2C0B TO AUX PAGE 3. (03BD)
 2C11 FIRST TIME IN OR FORMAT COMMAND? (03BC)
 2C14 NO, SKIP FORMAT LOGIC >>2C4F

***** FORMAT RAMDRIVE *****

2C16 YES, SAVE BLOCK WANTED
 2C18 PAGES \$E AND \$F ARE ACTUAL DIRECTORY
 2C1A ZERO THE DIRECTORY BLOCK <0333>
 2C1F COPY VOLUME NAME (\$F3,"RAM") (03D2)
 2C22 TO VOLUME DIRECTORY BLOCK (0E04)
 2C28 LAST BYTE IN VOLUME BITMAP
 2C2A IS AN \$FE (03D1)
 2C2D \$FF TO ACCUM.
 2C30 14 \$FF'S TO BITMAP (03C2)
 2C36 SET FIRST BITMAP BYTE TO ZERO (03C2)
 2C39 COPY 8 BYTES
 2C3B OF DIRECTORY DATA (03D6)
 2C3E TO VOLUME DIRECTORY BLOCK (0E22)
 2C44 WAS THIS A FORMAT COMMAND? (03BC)
 2C47 YES, DONE. >>2CAA
 2C49 NO, SET FLAG & CONTINUE WITH READ/WRITE (03BC)
 2C4C RESTORE BLOCK NUMBER (03C1)

***** READ/WRITE RAMDRIVE BLOCK *****

2C4F CONVERT BLOCK NUMBER TO PAGE NUMBER (03C1)
 2C55 THIS PAGE IN HIGH RAM?
 2C57 YES >>2C63
 2C59 NO, IS IT BLOCK 3? (VOLUME BIT MAP)
 2C5B NO >>2C60
 2C5D YES, DUMMY UP A PHONY BITMAP BLOCK >>038C
 2C60 ELSE, NORMAL READ/WRITE >>0342

***** READ/WRITE IN AUX HIGH RAM *****

2C63 SAVE PAGE NUMBER
 2C64 FIND IT IN MEMORY <02E5>
 2C67 REMEMBER READ/WRITE STATUS
 2C68 WRITING? >>2CB8
 2C6A GET SAVED PAGE NUMBER
 2C6B DOES OPERATION INVOLVE BANK1?
 2C6D NO, USE BANK2 >>2C73
 2C6F YES, FORCE IT TO SDXXX
 2C71 AND USE BANK1 OF AUX HIGH RAM >>2C79
 2C73 USE BANK2 OF AUX HIGH RAM (C083)
 2C76 AND WRITE ENABLE IT (C083)

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2C79

ADDR DESCRIPTION/CONTENTS

```

2C79 SAVE PAGE NUMBER IN BLOCK (03C1)
2C7C PRESERVE HIS BUFFER ADDR (03C0)
2C80 DURING THE FOLLOWING TRANSFER... (03BF)
2C83 SELECT AUX HIGH RAM (C009)
2C88 USE RAMDRIVE BUFFER AS AN "IN BETWEEN" (03C0)
2C8B AREA WHEN TRANSFERING TO/FROM AUX HIGH RAM.
2C8D PRETEND THAT WAS CALLER'S BUFFER (03BF)
2C90 AND SET UP POINTERS AGAIN <02E5>
2C94 COPY BLOCK TO OR FROM RAMDRIVE BUFFER
2C9F THEN BACK TO MAIN ZERO PAGE (C008)
2CA2 RESTORE CALLER'S BUFFER ADDRESS (03BF)
2CA9 READING OR WRITING?
2CAA IF WRITING, DONE >>2CB5
2CAC IF READING, WRITE ENABLE HIGH RAM (BANK1) (C08B)
2CB2 AND COPY RAMDRIVE BUFFER TO HIS BUFFER <02BE>
2CB5 THEN EXIT >>03DE
2CB8 IF WRITING, COPY HIS BLOCK TO RAMDRIVE BUFFER <02BE>
2CBB THEN COPY RAMDRIVE BUFFER TO AUX HIGH RAM >>026A

2CBE ***** COPY BLOCK IN MAIN 48K *****
2CBE THIS ENTRY IS FOR THE RAMDRIVE BUFFER
2CC0 THIS ENTRY ASSUMES AUX MEM PAGE NUMBER IN ACCUM (03C1)
2CC3 THIS ENTRY ASSUMES PAGE NUMBER ALREADY SET <02E5>
2CC6 WRITING TO RAMDISK? >>2CDB
2CC8 NO, WRITE TO MAIN 48K RAM (C004)
2CCC COPY BLOCK AUX MEM --> MAIN MEM
2CD7 WRITE TO AUX MEM AGAIN (C005)
2CDA DONE (RETURN HERE AFTER FOLLOWING JUMP)
2CDB ---
2CDD GO BACK TO MAIN MEM PART OF DRIVER (03ED)
2CE0 TO COPY MAIN MEM --> AUX MEM

2CE5 ***** SET BUFFER AND BLOCK ADDRESSES *****
2CE5 GET COMMAND (03BD)
2CE8 READ OR WRITE?
2CE9 WRITE? >>2D08
2CEB NO, GET HIGH BYTE OF BUFFER TO BE READ (03C0)
2CF2 AND LOW BYTE OF BUFF ADDRESS (03BF)
2CF5 $42/43 --> FIRST PAGE OF BUFFER
2CF7 $40/41 --> SECOND PAGE OF BUFFER
2CF9 GET PAGE NUMBER (03C1)
2CFE $3C/3D --> BLOCK IN RAMDRIVE
2D00 $3E/3F --> SECOND PAGE OF SAME
2D06 ALWAYS BRANCH AROUND WRITE CODE >>2D23

```

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2D06

ADDR DESCRIPTION/CONTENTS

```

2D08 WRITE, (03C0)
2D0F $3C/3D --> MAIN MEMORY ADDRESS OF BUFFER TO BE WRITTEN (03BF)
2D12 $3E/3F --> SECOND PAGE OF SAME
2D19 $42/43 --> BLOCK IN RAMDRIVE
2D1B $40/41 --> SECOND PAGE OF SAME
2D23 SET SECOND PAGE ADDRESSES
2D27 EXIT

2D28 ***** SEND HIM A DUMMY BLOCK OF ZEROES *****
2D28 ZERO RAMDRIVE BUFFER IN CASE READING <0331>
2D2B COPY BETWEEN RAMDRIVE BUFFER AND HIS BUFFER <02C3>
2D2E AND EXIT >>03DE

2D31 ***** ZERO BLOCK BUFFER *****
2D31 ZERO RAMDRIVE BUFFER
2D33 ZERO BLOCK INDICATED BY ACCUM. (03C1)
2D36 SET UP BUFFER POINTERS <02E5>
2D3A ZERO BOTH PAGES OF BLOCK
2D41 AND EXIT

2D42 ***** READ/WRITE IN LOW 48K *****
2D42 BLOCK 2 (VOLUME DIRECTORY)?
2D44 NO >>2D4A
2D46 YES, CONVERT IT BLOCK 7
2D48 AND GO DO I/O NOW >>2D58
2D4A ELSE, LESS THAN BLOCK 8?
2D4C YES, RETURN WITH DUMMY ZERO BLOCK. >>2D28
2D4E START MSB AT ZERO
2D50 GET ORIGINAL BLOCK NUMBER
2D52 BLOCK $5D THROUGH $5F?
2D54 NO >>2D5B
2D56 YES, ADJUST TO $D THROUGH $F
2D58 AND USE $1A00 THRU $1FFF IN RAMDRIVE. >>0385
2D5B ELSE, FOR BLOCKS $8 THRU $5C
2D5C SUBTRACT 8
2D5E AND DIVIDE BY 17 ($11)
2D64 XREG IS QUOTIENT
2D65 HAS TO BRANCH11 >>2D5E
2D68 AND AREG IS REMAINDER
2D69 REMAINDER OF 1?
2D6B NO >>2D73
2D6D YES, EVERY 17TH BLOCK GOES
2D6E IN $1000-$1BFF AREA
2D6F BY ADDING 8 TO QUOTIENT
2D71 AND GO DO IT >>2D85
2D73 BUMP QUOTIENT (START AT $2XXX)
2D75 SHIFT IT TO TOP NIBBLE OF BYTE

```

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2D7D

 ADDR DESCRIPTION/CONTENTS

2D7D GOT A REMAINDER? >>2D81
 2D7F IF SO, DECREMENT IT (NOT USING 1)
 2D81 THEN ADD INTO TOP NIBBLE
 2D82 TO FORM \$10 THRU \$5F (03C1)
 2D85 BLOCK*2 FOR PAGE NUMBER
 2D86 COPY THE BLOCK <02C0>
 2D89 THEN EXIT >>03DE

2D8C ***** READ/WRITE BITMAP BLOCK *****

2D8C USE RAMDRIVE BUFFER (NO ACTUAL BITMAP BLOCK)
 2D91 SET UP BUFFER POINTERS <02E5>
 2D94 WRITING? >>2DA9
 2D96 NO, READING - ZERO THE RAMDRIVE BUFFER <0336>
 2D9B COPY BITMAP IMAGE TO RAMDRIVE BUFFER (03C2)
 2DA3 COPY BLOCK BACK TO CALLER'S BUFFER <02C3>
 2DA6 THEN EXIT >>03DE

2DA9 WRITING, COPY HIS BUFFER TO RAMDRIVE BUFFER <02C3>
 2DAC SET UP BUFFER POINTERS <02E5>
 2DB1 COPY 16 BITMAP BYTES FROM RAMDRIVE BUFFER
 2DB3 INTO PAGE 3 BITMAP IMAGE (03C2)
 2DB9 THEN EXIT >>03DE

2DBC ***** RAM DRIVE DATA (AT \$3BC) *****

2DBC FIRST TIME ENTRY FLAG
 2DBD COMMAND FROM PARM LIST
 2DBE UNIT NUMBER FROM PARM LIST
 2DBF BUFFER ADDRESS FROM PARM LIST
 2DC1 BLOCK NUMBER FROM PARM LIST

2DC2 BIT MAP IMAGE FOR RAM DRIVE

2DD2 RAMDRIVE VOLUME NAME
 2DD3 'RAM'
 2DD6 ACCESS, ENTRY LENGTH
 2DD8 NUMBER OF ENTRIES
 2DD9 FILE COUNT
 2DDB BIT MAP BLOCK POINTER
 2DDD BLOCKS ON DISK

2DDE ***** EXIT TO MAIN MEMORY *****

2DDE WRITE ENABLE HIGH RAM (BANK1) (C08B)
 2DE5 RESTORE \$0STORE STATUS >>2DEA
 2DE7 \$0STORE WAS ON (C001)
 2DEA GO AROUND MEMORY USED BY XFER >>03EF
 2DED LOW-ORDER BYTE AND
 2DEE HIGH-ORDER BYTE USED BY XFER ROUTINE
 2DEF RETURN TO \$FF44 (NORMAL EXIT)

ProDOS Relocator -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 2DFB

 ADDR DESCRIPTION/CONTENTS

2DFB USE ROM XFER ROUTINE TO DO IT >>C314
 2DFE TWO BYTES NOT USED

2E00 ***** RAMDRIVE CALLER (RUNS AT \$FF00) *****
 (USED TO CALL MAIN PART OF RAMDRIVE DEVICE
 DRIVER WHICH IS AT \$200 IN AUX MEMORY.
 ROUTINE AT \$FF65 IS USED TO TRANSFER DATA
 FROM MAIN TO AUX MEM.)

2E00 ---
 2E03 SAVE ZPAGE STUFF I WILL CLOBBER
 2E05 FROM \$3C THRU \$47 (FF84)
 2E0D SAVE \$3ED/E THAT XFER ROUTINE WILL CLOBBER (03ED)
 2E16 COMMAND = STATUS?

2E18 IF SO, SIMPLE EXIT WILL DO >>2E44
 2E1A ELSE, TOO BIG A COMMAND NUM?

2E1C IF SO, ERROR >>2E3B
 2E1E ELSE, INVERT BITS OF CMD
 2E20 AND SAVE IT

2E22 FORMAT? >>2E2C

2E24 NO, CHECK BLOCK NUMBER

2E28 MUST BE <128 FOR RAMDRIVE

2E2C GOING TO \$200 IN AUX MEMORY

FF33

2E38 USE XFER ROUTINE TO GET THERE >>C314

2E3B I/O ERROR RETURN CODE

2E3D EXIT >>2E41

2E3F WRITE PROTECTED RETURN CODE

2E41

2E42 ERROR EXIT >>2E47

2E44 NORMAL EXIT, RETURN CODE IS 0

2E47

2E4B RESTORE ZERO PAGE (FF84)

2E53 AND \$3ED/E (FF82)

2E56 HARMLESS INSTRUCTION MAKES SURE \$FF58 IS AN RTS (0060)

NOTE: THERE ARE ONLY THREE SURE THINGS IN LIFE:
 DEATH, TAXES, AND AN RTS AT \$FF58.

2E64 AND EXIT TO CALLER WHEN THRU

2E65 ***** COPY MAIN TO AUX BLOCK *****
 (CALLED FROM AUX MEM HANDLER)

FF65

2E65 WRITE IN AUX 48K (C005)

2E6A COPY BOTH PAGES OF BLOCK

2E75 WRITE IN MAIN 48K AGAIN (C004)

2E7A GO TO \$2DA IN AUX MEMORY TO RETURN (03ED)

2E7F RETURN TO AUX MEM HANDLER AGAIN >>FF33


```
ProDOS Relocator -- V1.2 -- 6 SEP 86          NEXT OBJECT ADDR: 2E7F
-----
ADDR  DESCRIPTION/CONTENTS
-----
2E82 ***** DATA AREA *****
FF82
2E82  SAVE $3ED,$3EE
FF83
FF84
2E84  ZERO PAGE SAVE AREA
2E90 ***** $2E90-$2EFF NOT USED *****
      (NOTE: THE AREA FROM $FF90-$FF99 IS RESERVED
      FOR THE /RAM CALLER. FROM $FF9B TO $FFFF
      IS RESERVED FOR THE IRQ HANDLER.)
2E90  NOT USED
2F00 ***** START OF MLI LOAD IMAGE *****
2F00  MLI LOAD IMAGE AT $2F00
```

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 2000
 ADDR DESCRIPTION/CONTENTS

2000 MODULE STARTING ADDRESS

```
*****
*
* PRODOS RELOCATOR
*   LOADED AS THE FIRST
*   PORTION OF THE PRODOS
*   IMAGE AT $2000.
*
*   VERSION 1.3 -- 2 DEC 86
*
*****
```

THE 1.3 VERSION OF THE PRODOS RELOCATOR IS
 INSTRUCTION FOR INSTRUCTION THE SAME FROM
 \$2000 TO \$25F5 AND FROM \$2B00 TO \$2EFF.
 SOME ADDRESSES IN THESE AREAS CHANGE BECAUSE
 THEY ARE ADDRESSES WITHIN THE MODIFIED PORTION
 OF THE RELOCATOR OR THE MLI.

ONLY THE MODIFIED PORTION OF THE RELOCATOR
 (\$25B1 TO \$2AFF) IS DOCUMENTED HERE FOR VERSION 1.3.
 REFER TO THE 1.2 VERSION IN OTHER PARTS OF
 THE RELOCATOR.

25B1 ---

25B1 ***** DISPLAY LOAD MESSAGE *****

```
25B1 CLICK SPEAKER (C030)
25B4 STORE IN MAIN MEMORY (C00C)
25B7 80 COL DISPLAY OFF (C000)
25BA SET NORMAL VIDEO <FE84>
25BD CALL MONITOR INITIALIZATION <FB2F>
25C0 SET VIDEO PR#0 <FE93>
25C3 SET KEYBD IN#0 <FE89>
25C6 OUT OF DECIMAL MODE
25C7 CLEAR SCREEN <FC58>
25CC PRINT "APPLE //" (2605)
25D7 PRINT "PRODOS 8 " ETC. ON ROW 12 (260D)
25E2 PRINT 12 BLANKS ON ROW 14 (262B)
25ED PRINT "COPYRIGHT" ETC. ON ROW 23 (2637)
25F8 PRINT "ALL RIGHTS RESERVED" ON ROW 24 (265E)
2601 CLICK SPEAKER AGAIN (C030)
2604 DONE
```

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 2605
 ADDR DESCRIPTION/CONTENTS

2605 ***** DATA AREA *****

```
2605 'APPLE II'
260D 'PRODOS 8 V1.3      2-DEC-86'
262B '
2637 'COPYRIGHT APPLE COMPUTER, INC., 1983-86'
265E 'ALL RIGHTS RESERVED.'

2672 8 BYTES FOR SMARTPORT STATUS CALL
267A DRIVER ADDRESS
267C SPACES LEFT ON DEVICE LIST
267D SLOT 2 FLAG (0 = PRODOS STORAGE DEVICE IN SLOT 2)
```

267E ***** DETERMINE SLOT CONFIGURATION *****

```
267E ---
2680 ZERO SOME THINGS
2687 DEVCNT=$FF (NO DEVICES YET) (BF31)
268A ALL 14 DEVICES ARE UNASSIGNED
268F FIRST CHECK SLOT 2
2693 IS A STORAGE DEVICE IN SLOT 2? <28D4>
2696 IF NOT, SET A FLAG (267D)
2699 NOW POINT TO SLOT 7
269D STORAGE DEVICE IN SLOT? <28D4>
26A0 NO. >>26FE
26A2 GET $CSFF BYTE
26A4 LOOKS LIKE 16 SECTOR DISK II. >>26CB
26A6 LOOK LIKE 13 SECTOR DISK II?
26A8 YES, DON'T USE IT. >>26FE
```

***** NON-DISK II STORAGE DEVICE *****

```
26AA CSFF BYTE = LOW BYTE OF DEVICE ADDRESS (267A)
26AD CHECK BYTE AT OFFSET 7
26AF TO SEE IF IT'S A SMARTPORT
26B1 NOT A SMARTPORT INTERFACE >>26B6
26B3 GO DO SMARTPORT STUFF >>2863
26B6 ---
26B8 GET $CSFE (STATUS BYTE)
26BA CAN WE AT LEAST READ STATUS AND DATA?
26BE ANTICIPATE FAILURE
26BF CAN'T READ IT. NO SENSE USING IT. >>26FE
26C1 PUT LEFT NIBBLE OF STATUS BYTE IN $12 <28C9>
26C5 PUSH CLC, INDICATING ONE DRIVE
26C6 CARRY SET IF 2 OR 4 DRIVES
26C7 GET HIGH BYTE OF SLOT ROM
26C9 ALWAYS BRANCH INTO DISK II PROCESSING >>26D8
```

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 26C9

ADDR DESCRIPTION/CONTENTS

***** LOOKS LIKE A DISK II *****

26CB \$12 = 0 FOR DISK II
 26CE PUSH SEC ON STACK (DISK II HAS 2 DRIVES)
 26CF GET LOW BYTE OF DISK II DRIVER (\$00) (27F7)
 26D2 SAVE IT IN RELOC DATA AREA (267A)
 26D5 GET HIGH BYTE OF DISK II DRIVER (\$D0) (27F8)

***** COMMON PROCESSING *****

26D8 SAVE DEVICE ADDRESS HIGH BYTE (267B)
 26DB ESTABLISH DEVICE DRIVER IN GLOBAL PAGE <2833>
 26DE ONLY ONE DRIVE?
 26DF YES, GO TO NEXT SLOT >>26FD
 IF TWO DRIVES WERE ASSIGNED, MOVE THEM TO
 THE BOTTOM OF THE LIST IN REVERSE ORDER

26FD

 CARRY IS NOW CLEAR IF A PRODOS STORAGE DEVICE
 WAS FOUND IN THIS SLOT. OTHERWISE, CARRY IS SET.
 GO MARK SLBTT TO SHOW ROMS IN SLOT <2787>

2701 MOVE DOWN ONE SLOT

2707 WE'VE DONE ALL SLOTS >>270C

2709 CHECK NEXT SLOT >>269D

2712 STASHED ANY DEVICES AT BOTTOM OF LIST? (267C)
 2715 NO. >>2739

2717 YES, MOVE THEM BACK

271F IN REVERSE ORDER.

2734 DONE WHEN X=Y (267C)

2739

 START AT BOTTOM OF SEARCH LIST (BF31)

273B GET A DEVICE FROM LIST (BF32)

2741 PUT IT ON THE STACK

2744 IS IT THE CURRENT SLOT? (BF30)

2748 NO, KEEP LOOKING >>274C

274A YES, TAKE IT OFF THE STACK

274B INDICATE CURRENT SLOT FOUND

274C

 MORE TO CHECK >>273E

274D GET DEVICE COUNT (BF31)

2753 CURRENT SLOT NOT FOUND! >>2769

2755 PUT CURRENT DRIVE AT (BF30)

2758 BOTTOM OF SEARCH LIST (BF32)

275C ONLY ONE DEVICE ON LIST >>2770

275F ONLY ONE DRIVE ON BOOT SLOT >>2769

2761 CHANGE DRIVE NUMBER

2763 STORE OTHER DRIVE NEXT TO LAST (BF32)

2767 CURRENT SLOT ONLY SLOT ON LINE >>2770

2769 GET OTHER DEVICES

276A MOVE THEM AHEAD OF CURRENT DRIVE (BF32)

276E STILL MORE TO DO >>2769

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 276E

ADDR DESCRIPTION/CONTENTS

2770 DO CHECKSUM ON ROM <2809>
 2773 DOESN'T SAY "APPLE II"! >>2779
 2775 WE'RE HAPPY, STORE FINISHED MACHID (BF98)
 2778 AND LEAVE
 2779 UNKNOWN MACHINE, SO DIE HORRIBLY! >>2545

277C ***** PUT A DEVICE ON DEVICE LIST *****

277C COMBINE DSSS with IIII
 2781 BUMP DEVICE COUNT BY ONE
 2782 AND ADD DRIVE TO SYSTEM SEARCH LIST (BF32)
 2785 ROLL LEFT ANTICIPATING ROLL RIGHT
 2786 RETURN

2787 ***** IDENTIFY I/O CARD *****

2787 WE ALREADY FOUND ROM IN THIS SLOT >>27E8
 278B CHECK SIGNATURE ON CARD FOR THUNDERCLOCK
 2790 NOT IT >>27AC
 2796 THUNDERCLOCK, WHICH SLOT?
 2798 SAVE SLOT NUMBER (LESS 1)
 279A IN CLOCK CODE RELOCATION TABLE (22D1)
 279F ENABLE CLOCK/CALENDAR JUMP IN GLOBALS (BF06)
 27A4 NO MACHID! >>2770

27A6 INDICATE THAT A CLOCK IS PRESENT

27A8 AND UPDATE MACHID

27AA GO MARK ROM IN THIS SLOT >>27E8

 CHECK FOR PASCAL 1.1 PROTOCOL

27AC

27B0 \$CS05 = \$38?

27B2 DOESN'T GET TO FIRST BASE >>27D7

27B8 \$CS07 = \$18?

27BA NO. >>27D7

27C0 \$CS0B = \$01?

27C2 NO, BAD SIGNATURE >>27D7

27C7 YES, GET LEFT NIBBLE

27C9 80 COLUMN CARD?

27CB NO, UNKNOWN CARD >>27D7

27CF NO MACHID! >>2770

27D1 MARK 80 COLUMN CARD PRESENT

27D3 AND UPDATE MACHID

27D5 GO MARK ROM IN THIS SLOT >>27E8

27D7 UNKNOWN CARD, CHECK ROM TO

27DB SEE IF IT WILL HOLD A VALUE

27E1 FOR SOME TIME.

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 27E6
 ADDR DESCRIPTION/CONTENTS

27E8 WE FOUND ROM IN THIS SLOT
 27EA CONVERT SLOT NUMBER
 27ED TO A BIT POSITION (2801)
 27F0 AND OR INTO SLBXT (BF99)
 27F6 RETURN TO CALLER

27F7 ***** DATA AREA *****

27F7 DISK II DEVICE DRIVER ENTRY POINT

27F9 DEVICE SIGNATURE FOR:
 27FB +0,+2,+4,+6 = THUNDERCLOCK
 27FD +1,+3,+5,+7 = DISK
 27FF (+7 NOT CHECKED)

2801 BIT POSITION TABLE FOR SLOTS
 2804 (ALSO USED IN CHECKSUM CALCS)

2809 ***** COMPUTE AUTOSTART ROM CHECKSUM *****

2809 ---
 280A GET ZERO IN INDEX REGISTER (2801)
 280D POINT TO \$FB09 ("APPLE II" IN ROM)
 280F MAKE SURE UPPER CASE
 2814 UPDATE CHECKSUM (2801)
 2817 PUT HIGH BIT IN CARRY (2801)
 281B DO 8 BYTES IN ALL (2804)
 2820 ACCUM = \$08
 2824 ACCUM = \$80
 2826 TURN ON HIGH BIT (2801)
 2829 ADD A FUDGE FACTOR
 282B OH NO! A CLONE! >>2830
 282D PASSED THE TEST...RETURN WITH MACHID
 282F RETURN
 2830 ELSE, RETURN WITH ZERO MACHID
 2832 RETURN

2833 ***DEVICE DRIVER IN GLOBAL PAGE *****

2833 SAVE CARRY (NUMBER OF DRIVES)
 2834 GET HIGH BYTE OF SLOT ADDRESS
 2836 MAKE IT SLOT NUMBER
 2838 TIMES 2
 2839 USE LATER IN Y-REG
 283A NOW GET SLOT*16 IN ACCUM
 283C NOW HAVE 05550000 (DRIVE 1)
 283D PUT DEVICE ID ON DEVICE LIST <277C>
 2840 GET BACK CARRY (NUMBER OF DRIVES)
 2841 ROLL CARRY INTO ACCUM
 2842 ONLY ONE DRIVE. >>2848

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 2844
 ADDR DESCRIPTION/CONTENTS

2844 TWO DRIVES. BUMP DEVICE COUNT
 2845 AND PUT SECOND DRIVE ON SEARCH LIST (BF32)
 2848 STORE FINAL DEVICE COUNT (BF31)
 284B SHIFT DRIVE INDICATOR BACK TO CARRY
 284C GET LOW BYTE OF DEVICE DRIVER ADDRESS (267A)
 284F PUT IN GLOBAL PAGE FOR DRIVE 1 (BF10)
 2852 ONLY ONE DRIVE >>2857
 2854 PUT IN GLOBAL PAGE FOR DRIVE 2 (BF20)
 2857 GET HIGH BYTE OF DEVICE DRIVER ADDRESS (267B)
 285A PUT IN GLOBAL PAGE FOR DRIVE 1 (BF11)
 285D ONLY ONE DRIVE >>2862
 285F PUT IN GLOBAL PAGE FOR DRIVE 2 (BF21)
 2862 RETURN

2863 ***** HANDLE SMART PORT *****

2863 PUT LEFT NIBBLE OF STATUS BYTE IN \$12 <28C9>
 2866 GET HIGH BYTE OF SLOT ROM ADDRESS
 2868 STORE IT IN RELOC DATA AREA (267B)
 286B GET PRODOS ENTRY, LOW BYTE (267A)
 286E POKE INTO PRODOS CALL (2895)
 2872 ADD THREE TO GET SMARTPORT ENTRY
 2874 POKE INTO SMARTPORT CALL (2898)
 287A POKE IN HIGH BYTE TO SMARTPORT CALL (2899)
 287D AND TO PRODOS CALL (2896)
 2880 CONVERT HIGH BYTE TO UNIT NUMBER
 2884 STORE UNIT NUMBER
 2886 PRODOS STATUS CALL
 2888 STORE AS COMMAND CODE
 288C ALSO ZERO BLOCK NUMBER
 2890 SET BUFFER ADDRESS SET TO \$1000
 2892 JUST IN CASE IT'S NEEDED.
 2894 SELF-MODIFIED TO CALL PRODOS DEVICE DRIVER. <0000>
 2897 SELF-MODIFIED TO CALL THE SMARTPORT <0000>
 289A WITH A STATUS COMMAND.
 289B PARMLIST AT \$28AB
 289D GET NUMBER OF DEVICES ON LINE (2672)
 28A0 NONE ON LINE! >>28C6
 28A2 INDICATE IF DRIVE 2 EXISTS.
 28A4 PUT DRIVER ADDRESS IN GLOBAL PAGE <2833>
 28A9 IS THIS SLOT 5?
 28AB NO. >>28C6
 28AD SLOT 2 BEING USED BY A STORAGE DEVICE? (267D)
 28B0 YES, TWO DRIVES IS ALL YOU GET! >>28C6
 28B2 GET NUMBER OF DEVICES AGAIN (2672)
 28B5 MORE THAN TWO DRIVES?
 28B7 NO. >>28C6
 28B9 SET CARRY IF DRIVE 4 EXISTS.
 28BB PUT THEM IN SLOT 2
 28BF PUT DRIVER ADDRESS IN GLOBAL PAGE <2833>
 28C6 GO PROCESS NEXT SLOT >>26FD

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 28C6

ADDR DESCRIPTION/CONTENTS

28C9 ***** CONVERT STATUS FOR ID BYTE *****

28C9 GET STATUS BYTE
28CD SHIFT LEFT NIBBLE TO RIGHT NIBBLE
28D1 PUT IT IN \$12
28D3 RETURN

28D4 ***** CHECK FOR PRODOS STORAGE DEVICE *****

28D4 RESET I/O CARD ROMS (CFFF)
28D9 CHECK 3 BYTES ON CONTROLLER ROM
28DE ANTICIPATE FAILURE
28DF NOT A PRODOS STORAGE DEVICE >>28E6
28E5 SUCCESS--THIS IS A PRODOS STORAGE DEVICE.
28E6 RETURN

28E7 ***** COMMAND LIST FOR SMARTPORT CALL *****

28E7 3 PARAMETERS
28E8 OVERALL STATUS CALL
28E9 PUT STATUS DATA AT \$2653
28EB STATUS CODE IS \$00

28EC ***** RELOCATION ROUTINE *****
(X/Y REGS CONTAIN TABLE ADDR)

28EC SAVE PASSED TABLE ADDRESS
28F0 ACCESS IIGS STATEREGBYTE TO (C068)
28F3 TURN OFF SLOT ROM, ENSURE ROM BANK 0
28F8 ---
28FA GET OPERATION CODE
28FC VALID OPERATION? (4 OR LESS)
28FE NO, ERROR >>2972
2902 \$14/15 --> OUTPUT BLOCK
290C \$16/17 --> LENGTH
2915 NEGATIVE LENGTH? >>2974
2917 CHECK OPERATION CODE
2918 ZERO BLOCK? >>297D
2925 \$1A/1B --> END OF INPUT BLOCK
2932 COPY BLOCK ONLY? >>29A1
2934 SAVE RELOCATION OPERATION CODE (2ACB)
293A SAVE NUMBER OF RANGES TO CHECK (2ACC)
293E ---
293F COPY START PAGES TO TABLE
294A ---
294B AND END PAGES
2956 ---
2957 AND FINALLY, RELOCATION FACTORS
295F BUMP TO NEXT TABLE ENTRY <29A7>

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 2962

ADDR DESCRIPTION/CONTENTS

2962 RESTORE OPERATION CODE (2ACB)
2967 RELOCATE INSTRUCTIONS? >>2977

2969 ***** 2/3 - RELOCATE ADDRESSES *****

2969 NO, RELOCATE ADDRESS <2A09>
296C COPY BLOCK <29B2>
296F AND CONTINUE IF ALL WENT WELL >>28F8
2972 NORMAL EXIT
2973 RETURN
2974 JUMP TO ERROR EXIT >>2A3F

2977 ***** 4 - RELOCATE INSTRUCTIONS *****

2977 RELOCATE INSTRUCTIONS <2A1B>
297A AND THEN COPY BLOCK >>296C

297D ***** 0 - ZERO BLOCK *****

297D BUMP TABLE POINTER TO NEXT ENTRY <29A7>
2982 GET NUMBER OF PAGES TO DO
2984 NO FULL PAGES? >>2992
2987 ZERO AN ENTIRE PAGE
298C BUMP PAGE POINTER
298E AND DECREMENT LENGTH
2992 GET LENGTH OF PARTIAL LAST PAGE
2994 NO PARTIAL PAGE? >>299E
2997 ZERO PARTIAL PAGE TOO
299E DONE, GET NEXT TABLE ENTRY >>28F8

29A1 ***** 1 - COPY BLOCK *****

29A1 BUMP TABLE POINTER <29A7>
29A4 AND GO COPY BLOCK >>296C

29A7 ***** ADVANCE TABLE POINTER *****

29A7 ADD FINAL ENTRY INDEX..
29AB TO TABLE ENTRY ADDRESS
29B1 RETURN

29B2 ***** COPY BLOCK *****

29B2 ---
29B6 INPTR < OUTPTR? >>29C3
29B8 NO, GREATER? >>29E6
29BA MSB'S ARE EQUAL, CHECK LSB'S ALSO
29C2 EXIT IF EQUAL
29C3 INPTR < OUTPTR, COPY LAST PAGES FIRST
29C7 BUMP BOTH INPTR AND OUTPTR BY..
29C9 LENGTH-1 TO POINT AT LAST BYTE

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 29D1
 ADDR DESCRIPTION/CONTENTS

29D1 START WITH SHORT LAST PAGE LENGTH
 29D5 ---
 29D6 COPY BYTES BACKWARDS THROUGH MEMORY
 29DD DROP ADDRESSES AND LENGTH BY 256
 29E3 AND CONTINUE UNTIL FINISHED >>29D5
 29E5 RETURN
 29E6 INPTR > OUTPTR, COPY PAGES FORWARD
 29E8 HOW MANY FULL PAGES LEFT?
 29EA NONE? >>29FB
 29EC COPY A FULL PAGE
 29F3 AND BUMP ADDRESSES
 29F7 DECREMENT LENGTH BY 256
 29F9 AND DO ALL PAGES >>29EC
 29FB GET LENGTH OF LAST PAGE
 29FD EVEN PAGE BOUNDARY? >>2A08
 29FE NO, COPY SHORT LAST PAGE
 2A0B RETURN

2A09 ***** ADDR/PAGE RELOCATE *****
 2A09 GET TABLE ENTRY TYPE (2ACB)
 2A0D GET PAGE TO RELOCATE
 2A0F RELOCATE A SINGLE ADDRESS <2A47>
 2A12 BUMP BY 1 OR 2 BYTES (2ACB)
 2A15 ADVANCE POINTER <2A63>
 2A18 AND CONTINUE UNTIL COMPLETE >>2A09
 2A1A RETURN

2A1B ***** INSTRUCTIONS RELOCATE *****

 2A1D GET 6502 OPCODE
 2A1F COMPUTE INSTRUCTION LENGTH <2A76>
 2A22 INVALID OPCODE? >>2A35
 2A24 3 BYTE INSTRUCTIONS?
 2A26 NO >>2A2F
 2A28 YES, 3 BYTE ADDRESS TO CORRECT
 2A2A RELOCATE ADDRESS <2A47>
 2A2D AND ADVANCE BY 3 BYTES
 2A2F NEXT INSTRUCTION <2A63>
 2A32 CONTINUE UNTIL FINISHED >>2A1B
 2A34 RETURN

***** INVALID OPCODE *****
 2A35 POP THE STACK
 2A37 RETURN WITH POINTER TO BAD INSTRU.
 2A3B DIE HORRIBLY
 2A3E RETURN

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 2A3E
 ADDR DESCRIPTION/CONTENTS

2A3F ***** ERROR RETURN *****
 2A3F RETURN WITH POINTER
 2A43 EXIT WITH ERROR CODE
 2A46 RETURN

2A47 ***** RELOCATE ABSOLUTE ADDRESS *****
 2A47 GET PAGE NUMBER TO CHECK
 2A49 GET NUMBER OF RANGES (LESS ONE) (2ACC)
 2A4C IS IT PRIOR TO START OF THIS RANGE? (2ACD)
 2A4F YES? >>2A58
 2A51 NO, IS IS AFTER END OF RANGE? (2AD5)
 2A54 NO? >>2A5C
 2A58 ---
 2A59 CHECK EACH RANGE >>2A4C
 2A5B RETURN

 2A5C ---
 2A5D ADD FUDGE FACTOR TO ADDRESS (2ADD)
 2A60 AND UPDATE IT
 2A62 RETURN

2A63 ***** BUMP POINTER TO NEXT ADDR *****
 2A63 ---
 2A64 ADD LENGTH TO POINTER
 2A6B CHECK TO SEE IF WE ARE DONE
 2A71 ---
 2A75 RETURN

2A76 ***** COMPUTE INSTRUCTION LENGTH *****
 2A76 A-REG CONTAINS OPCODE
 2A77 ISOLATE LAST TWO BITS FOR LATER
 2A7C USE LAST 6 BITS AS TABLE INDEX
 2A7E GET BYTE WITH 4 LENGTHS IN IT (2A8B)
 2A81 ---
 2A82 USING TOP TWO BITS AS INDEX... >>2A88
 2A84 SHIFT DOWN THE PROPER LENGTH
 2A88 AND ISOLATE IT IN A-REG
 2A8A RETURN

2A8B ***** 6502 OP LENGTH TABLE *****
 EACH BYTE CONTAINS FOUR 2 BIT LENGTHS

ProDOS Relocator -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: 2A8B

ADDR DESCRIPTION/CONTENTS

2A8B ---

2ACB ***** RELOCATION DATA *****

2ACB RELOCATION CODE (3,2,1)
2ACC NUMBER OF RANGES
2ACD START OF RANGE PAGES
2AD0
2AD5 END OF RANGE PAGES +1
2ADD ADDITIVE FACTORS

2AE5 ***** 2AE5-2AFF NOT USED *****

2AE5 NOT USED

THE REST OF THE RELOCATOR IS IDENTICAL
TO VERSION 1.2

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D700

ADDR DESCRIPTION/CONTENTS

D700 MODULE STARTING ADDRESS

```
*****
*
* PRODOS MACHINE LANGUAGE INTERFACE
* THIS CODE IS MOVED INTO HIGH
* RAM ($DE00-$FEFF) BY THE
* PRODOS RELOCATOR.
* IT PERFORMS ALL FILE MANAGEMENT
* AND OTHER SYSTEM FUNCTIONS AND
* SUPPORTS THE HARDWARE IN A
* DEVICE INDEPENDENT WAY.
*
* VERSION 1.2 -- 6 SEP 86
*****
```

D700 ***** ZERO PAGE USAGE *****

0040 Pointer to caller's parmlist

0041 -- device driver parmlist --

0042 Command

0043 Unit Number

0044 Buffer Pointer

0045 Block Number

0046

0047

```
-----
I/O Pointer - Index Block or..
pointer into $F600 work buffer or..
caller's pathname buffer pointer
```

0049 I/O Pointer - Data Block

004A I/O Pointer - Data Block

004B I/O Pointer - Data Block

004C I/O Pointer - Data Block

```
004D I/O Pointer - Caller's Data or..
004E buffer pointer passed in parmlist or..
004F old I/O buffer
```

D700 ***** MLI ERROR CODES *****

0000 No Error

0001 Bad call type

0004 Bad parameter count

0025 Interrupt Table full

0027 I/O Error

0028 No device connected

002B Write protected

ProDOS MLI -- V1.2 -- 6 SEP 86

ADDR DESCRIPTION/CONTENTS

```
002E Volume switched
0040 Invalid pathname syntax
0042 Too many files open
0043 Invalid REF NUM
0044 Nonexistent path
0045 Volume not mounted
0046 File not found
0047 Duplicate file name
0048 Disk full
0049 Volume Directory full
004A Incompatible ProDOS version
004B Unsupported storage type
004C End of file
004D Position past EOF
004E Access error
0050 File already open
0051 File count bad
0052 Not a ProDOS disk
0053 Bad parameter
0055 VCB overflow
0056 Bad buffer address
0057 Duplicate volume mounted
005A Bad volume bit map
```

D700 ***** SCREEN LOCATIONS *****

0750 For direct movement of text to screen

07D0

07F1

07F2

07F3

07F4

07F5

07F6

07F7

07F8

Slot in use

***** RELOCATOR VARIABLE *****

2278 Flag=1 when running on a IIGS

D700 ***** SYSTEM GLOBAL PAGE EQUATES *****

BF00 Jump to MLI entry point

BF03 JSPARE (Jump to \$EECF, QUIT code)

BF06 DATETIME vector

BF09 Jump to System Error

BF0C Jump to System Death Handler

BF0F System Error number

BF10 Device Driver address table

BF30 Slot/Drive last device

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D700

ADDR DESCRIPTION/CONTENTS

BF31 Count (-1) active devices
 BF32 List of active devices by DEVID
 BF38 Memory BITMAP for low 48K
 BF70 Open file 1 buffer address
 BF7E Open file 8 buffer address
 BF80 Interrupt handler 1
 BF82 Interrupt handler 2
 BF84 Interrupt handler 3
 BF86 Interrupt handler 4
 BF88 A reg save during interrupt
 BF89 X reg save during interrupt
 BF8A Y reg save during interrupt
 BF8B S reg save during interrupt
 BF8C P reg save during interrupt
 BF8E Interrupt return address
 BF90 Date/Time
 BF94 File open LEVEL
 BF95 Backup bit
 BF96 Temporary storage
 BF9A Prefix flag (0 = no prefix)
 BF9B MLI active flag
 BF9C Last MLI call return address
 BF9E MLI X reg savearea
 BF9F MLI Y reg savearea
 BFA0 HIGH RAM entry/exit routines
 BFD0 Interrupt entry/exit routines
 BFF4 Bank switch saved state (\$E000 byte)

D700 ***** SOFT SWITCHES *****

C00C Reset 80 column mode
 C029 IIGS NEWVIDEO register
 C051 Set TEXT mode
 C053 Set Mixed text/graphics
 C054 Display Primary page
 C056 Set LORES graphics mode
 C083 Read/Write RAM 2nd 4K Bank
 C08B Read/Write RAM 1st 4K Bank
 CFFF Reset alternate I/O ROMs

D700 ***** PATHNAME - DATA AREA *****

| L1 | NAME1 | L2 | NAME2 | .. | 00

Prefix is at top of buffer such that a negative index may be used to use it, wrapping around to the pathname again.

ProDOS MLI -- V1.2 -- 6 SEP 86

ADDR DESCRIPTION/CONTENTS

D700 pathname buffer

D800 ***** FILE CONTROL BLOCKS *****

D800 File Control Block (FCB0) starts here..

D800 Reference Number

THE FOLLOWING 6 BYTES ARE THE FILE ID

D801 Device Number

D802 Dir Block HDR for Dir describing this File

D804 Dir Block containing entry itself

D806 File entry # in this Directory

D807 Storage Type

Flags

1XXX XXXX Index Block Buffer Changed

XLXX XXXX Data Block Buffer Changed

XX1X XXXX Unused

XXX1 XXXX Directory entry needs update

XXXX 1XXX Storage Type Changed

XXXX X1XX Allocate new Master Index Block

XXXX XX1X Allocate new Sub Index Block

XXXX XXX1 Allocate new Data Block

D808 Access Byte

D809 Newline Character

D80A Buffer Number (REF NUM * 2)

D80C Master Index/Key Block Number

D80E Current Index Block

D810 Current Data Block

D812 Mark

D815 End of File

D818 Blocks Used

D81A not used

D81B Level

D81C Flag - Write occurred if MSB on

D81D not used

D81F Newline Enable Mask

D820 FCB1 through FCB7

D900 ***** VOLUME CONTROL BLOCKS *****

Volume Control Block (VCB0) starts here..

D900 Length (00001LLL)

D901 File Name (Max 15)

D910 Unit Number

D911 Files Open Flag (if \$FF)

D912 Total Blocks

D914 Blocks Free

D916 Block Number of Vol Dir Key Block

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D918
 ADDR DESCRIPTION/CONTENTS

D918 not used
 D919 not used
 D91A Bit Map Pointer
 Block offset into multi-block bitmap of
 D91C next free bit.
 D91E Count of open files

D920 VCB1 through VCB7

DA00 ***** BITMAP BUFFER *****

DA00 Buffer 1st half

DB00 Buffer 2nd half

DC00 ***** PRIMARY BUFFER *****
 (Used for several things. DIRECTORY block offsets are
 mapped into it below)

DC00 Pointer Fields

*** DIRECTORY HEADER ***

DC04 Type/Length (TTTTLLLL)

DC05 Volume Name (Max 15)

DC14 Reserved

DC1C Creation Datetime

DC20 Version

DC21 Min Version

DC22 Access Byte

DC23 Entry Length

DC24 Entries per Block

DC25 File Count

DC27 Bitmap Pointer

DC29 Entry number within parent's block

DC29 Total Blocks

DC2A Length of entries in parent

DC2B (remainder of first page of block)

DD00 (second page of block)

DE00 ***** MLI MAIN ENTRY POINT *****

DE00 Clear decimal mode
 DE01 Retrieve status byte from stack
 DE02 and store it in global page. (BF96)
 DE05 Save Registers (BF9F)
 DE0B Set (\$40) -> Address of function code -1
 DE0F Set CMDADR -> True return address
 DE1C Retrieve status byte, (BF96)
 DE1F push it onto the stack,
 DE20 and pull it into status register.
 DE24 Init Global Page System error to 0 (BF0F)
 DE28 Get Function Code

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: DE2B
 ADDR DESCRIPTION/CONTENTS

DE2B Build hash index into Command Table (X reg)
 DE34 Is this function code valid?
 DE39 No >>DEB1
 DE3C Set (\$40) -> Parameter list
 DE49 Get parameter count required (FD4D)
 DE4C None? >>DE6A
 DE4E Is parameter count correct?
 DE50 No >>DEB5
 DE52 Check class of function (FD2D)
 DE55 Quit?
 DE57 Yes >>DE67
 DE59 no,
 DE5A \$8X - Calls to I/O Drivers >>DE70
 DE5C \$CX/DX - Non System calls >>DE7B
 DE5E Else, \$4X - Interrupt support
 DE5F Isolate type (\$=ALLOC, 1=DEALLOC, 2=SPECIAL)
 DE61 Call Interrupt Support <DEFD>
 DE64 Then Exit to Caller >>DE82
 DE67 Go to quit code via global page >>BE03

DE6A *****
 ***** MLI GET TIME CALL *****

DE6A Call Date/time driver <BF06>
 DE6D and exit to caller >>DE82

DE70 *****
 ***** MLI READ BLOCK CALL *****
 ***** MLI WRITE BLOCK CALL *****

 \$80 - Read Block
 \$81 - Write Block

DE70 ---
 DE71 Set \$42 -> 1 for READ, 2 for WRITE
 DE75 Do Block I/O <DEBC>
 DE78 Then Exit to Caller >>DE82

DE7B ***** \$CX and \$DX CALLS *****

DE7B ---
 DE7C Isolate function Index
 DE7F Perform function and exit to caller <E03E>

DE82 ***** EXIT TO CALLER *****

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: DE82

ADDR DESCRIPTION/CONTENTS

```

DE82 Clear Backup
DE8A Error occurred?
DE8D Save test results
DE8E Disable interrupts
DEBF Roll out most recent "active" bit (BF9B)
DE92 Get test results back
DE93 Store in X reg
DE94 Set up Return Address on stack (BF9D)
DE9C Put test results on stack
DE9E Put error code in A reg
DE9F Restore X reg (BF9E)
DEA2 Restore Y reg (BF9F)
DEA5 Put error code on stack
DEA6 Get RAM/ROM orientation (BFF4)
DEA9 Exit via RAM Global Page >>BFA0

```

DEAC ***** NO DEVICE CONNECTED *****

DEAC ---

DEAE Call System Error Handler (Global Page) <BF09>

DEB1 ***** BAD SYSTEM CALL NUMBER *****

DEB1 ---

DEB3 Branch always taken >>DEB7

DEB5 ***** BAD PARAMETER COUNT *****

DEB5 ---

DEB7 Call System Error Handler <DEE1>

DEBA Exit to Caller >>DE82

DEBC ***** BLOCK I/O SETUP *****

DEBC ---

```

DEBE Save Old Processor Flags
DEBF Disable Interrupts
DEC0 Copy Parameters to $43-$47
DEC8 Save Starting Buffer Page in $4F
DECD Find last page + 1
DED0 Round up if Buffer not page aligned >>DED3
DED3 Is this Memory already in use? <FC63>
DED6 Yes, then exit with error >>DEE0
DED8 No, do Block I/O <DEE4>
DEDB Error? >>DEE0
DEDD No, then exit normally
DEDF RETURN
DEE0 Error Exit
DEE1 Call System Error Handler <BF09>

```

ProDOS MLI -- V1.2 -- 6 SEP 86

NEXT OBJECT ADDR: DEE1

ADDR DESCRIPTION/CONTENTS

DEE4 ***** Block I/O *****

DEE4 ---

```

DEE6 Force off unused UNIT bits
DEED Put Drive number in X reg
DEF1 Put Device Handler Address in Jump Vector (FEBD)
DEFA Exit through Device Handler >>FEBD

```

DEFD ***** Interrupt Handler *****

ALLOC/DEALLOC

```

DEFD Save Call Type
DEFF Install unclaimed interrupt handler?
DF01 NO, normal ALLOC/DEALLOC >>DF09
DF03 Yes, install a handler for unclaimed interrupts. <FD23>
DF06 Error? >>DF35
DF08 NO, done.
DF09 Test bit 0
DF0A 1=DEALLOC >>DF38

```

ALLOC

DF0C ---

```

DF0E Look for empty slot (BF7E)
DF15 His Address better be non-zero
DF19 Store Address of His routine in Global Page (BF7E)
DF22 And return the position number we used
DF28 Exit
DF29 Skip this Vector
DF2B Last one?
DF2D NO, check another >>DF0E
DF2F Yes, Table Full Error
DF31 Always taken >>DF35
DF33 Bad Parameter Error
DF35 Call System Error Handler <BF09>

```

DEALLOC

DF38 ---

```

DF3A Get Position Number
DF3C Can't be zero >>DF33
DF40 Or greater than 4 >>DF33
DF43 Make Index into Table from it
DF46 And zero His Vector (BF7E)
DF4D Then Exit

```

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: DF4D
 ADDR DESCRIPTION/CONTENTS

DF4E ***** IRQ Handler *****
 DF50 ---
 DF53 Save A reg from Monitor (BF88)
 DF53 And X,Y,S and P (BF89)
 DF5D Is this ROM enhanced? (DFF1)
 DF60 Yes, skip three pulls >>DF6E
 DF67 And RTI Address (BF8E)
 DF6E Replace stack to original condition
 DF72 Save active slot index (DFE7)
 DF75 In bottom half of stack?
 DF78 Yes, pop off 16 bytes and save them
 DF7A ---
 DF81 Save \$FA - \$FF (top of zero page)
 DF83 ---
 DF8B Is there a User Vector #1 (BF81)
 DF8E No >>DF95
 DF90 Yes, call it <DFE3>
 DF93 His interrupt? >>DFBD
 DF95 Is there a User Vector #2 (BF83)
 DF98 No >>DF9F
 DF9A Yes, call it <DFE6>
 DF9D His interrupt? >>DFBD
 DF9F Is there a User Vector #3 (BF85)
 DFA2 No >>DFA9
 DFA4 Yes, call it <DFE9>
 DFA7 His interrupt? >>DFBD
 DFA9 Is there a User Vector #4 (BF87)
 DFAC No, didn't find service routine. >>DFB3
 DFAE Yes, call it <DFEC>
 DFB1 His interrupt? >>DFBD
 DFB3 Allow 256 tries, (DFF2)
 DFB8 then indicate error type 1 and
 DFBA call System Death Handler. <BF0C>
 DFBF Interrupt Serviced
 DFC7 Restore zero page (FDBD)
 DFC7 And stack (BF8B)
 DFD7 Is this enhanced ROM? (DFF1)
 DFDA Yes, skip some stuff we used to have to do >>DFEE
 DFDC Reload X and Y (BF8A)
 DFE2 Disable I/O ROMS (CFFF)
 DFE5 Replace active slot number (C100)
 DFE6 Exit from Interrupt >>BFD0
 DFF1 ENHANCE FLAG. Set to 1 by RELOCATOR if new type ROM found.
 (That is, if ROM IRQ Vector jumps below \$D000)
 DFF2 Unclaimed IRQ Count. Incremented when an interrupt
 is unclaimed (256 tries are allowed).

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: DFF3
 ADDR DESCRIPTION/CONTENTS

DFF3 User Interrupt Handler #1 >>BF80
 DFF6 User Interrupt Handler #2 >>BF82
 DFF9 User Interrupt Handler #3 >>BF84
 DFFC User Interrupt Handler #4 >>BF86
 DFFF ***** SYSTEM ERROR HANDLER *****
 DFFF Save Error Code (BF0F)
 E003 Pop out of subroutine
 E004 Exit to caller with Error Code (BF0F)
 E008 RETURN
 E009 ***** SYSTEM DEATH HANDLER *****
 E009 Save Error number in X-REG
 E00A Turn off 80 column card (C00C)
 E00D Select standard Text display (C051)
 E010 Are we running on a IIGS? (2278)
 E013 No. >>E01A
 E015 Yes, initialize IIGS video
 E017 by clearing NEWVIDEO. (C029)
 E01F ---
 E021 Blank next to last row of screen and (0750)
 E024 print "INSERT SYSTEM DISK AND RESTART" (FDE6)
 E027 on bottom row of screen. (07D0)
 E02D Get error number back
 E02E Expect errors in range 00 to 0F
 E030 Make it ASCII
 E038 Put error number on screen (07F7)
 E03B Infinite loop >>E03B
 E03E ***** PERFORM FILING OR *****
 ***** HOUSEKEEPING FUNCTIONS *****
 E03E Save function index (FE7F)
 E041 Get INFO flags for this command (FD95)
 E044 Times 2
 E045 Store Command Number times 2 (FE7B)
 E04A And use it to index into Address Table
 E04E Set up Jump Vector with this function's (FEBD)
 E051 ..handler address (FD6E)
 E057 Signal Backup required after call
 E05C PATHNAME not required? >>E063
 E05E Required - parse and validity check <E081>
 E061 Bad Name? >>E07A
 E063 Reference Number in list? (FE7B)
 E066 No >>E06D
 E068 Yes - check it out <E1C7>
 E06B Bad Number? >>E07A
 E06D Date/Time in list? (FE7B)

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E070

ADDR DESCRIPTION/CONTENTS

E070 No >>E075
 E072 Yes - set System date just in case <BF06>
 E075 Call Function Handler <E07E>
 E078 If no errors then exit >>E07D
 E07A Else - call System error handler <BF09>
 E07D Return to caller
 E07E Indirect JUMP to Handler >>FEED

E081 ***** CHECK CALLER'S PATHNAME *****
 ***** COPY TO MY AREA *****

E081 Set (\$48) -> Pathname
 E08C ---
 E090 Assume partial Pathname (FE84)
 E093 No Pathname in my area yet (D700)
 E096 Check length of caller's Pathname
 E098 Zero is no good >>E0F2
 E09C Nor is 65 or more >>E0F2
 E09E Save length (FE66)
 E0A1 Length + 1 (FE66)
 E0A5 Get first character of his name
 E0A9 Is it "/"?
 E0AB No >>E0B1
 E0AD Yes - indicate fully qualified name (FE84)
 E0B0 Bump past "/"
 E0B1 ---
 E0B3 Length of Index level is -1 initially (D700)
 E0B6 First character of Index level (counter) (FE80)
 E0B9 Start of upcoming Index level in name (FE82)
 E0BC At end of name yet? (FE66)
 E0BF Yes >>E0F6
 E0C1 No - get next character in his name
 E0C7 Is it "/"?
 E0C9 Yes >>E10B
 E0CB No - lower case?
 E0CD No >>E0D1
 E0CF Yes - force upper case
 E0D1 Copy to my Pathname buffer (D700)
 E0D4 Increment Index level counter (FE80)
 E0D7 Subsequent characters may be A-Z,0-9 or . >>E0DE
 E0D9 Increment Index level counter (FE80)
 E0DC First character must be alphabetic >>E0EA
 E0DE Is it "."?
 E0E0 Yes - get next character >>E0BC
 E0E2 No - is it special or control character
 E0E4 Yes - Bad Pathname then >>E0F2
 E0E6 Is it numeric?
 E0E8 Yes - get next character >>E0BC
 E0EA Is it Alphabetic?
 E0FA If so get next character >>E0BC
 E0F2 Else

ProDOS MLI -- V1.2 -- 6 SEP 86

NEXT OBJECT ADDR: E0F3

ADDR DESCRIPTION/CONTENTS

E0F3 Bad Pathname
 E0F5 RETURN
 E0F6 ---
 E0F8 Any characters in last Index level? (FE80)
 E0FB Yes >>E101
 E0FD No, zero characters in it (FE80)
 E100 And toss out last "/"
 E101 ---
 E102 Mark end of name with \$00 (D700)
 E105 Name too long? >>E0F2
 E107 No - save final length (FE66)
 E10A Set X -> 0
 E10E Last Index more than 15 characters?
 E110 Yes - then no good >>E0F2
 E112 Save output Index (FE85)
 E115 Store length of previous Index level (FE82)
 E118 Just before it in buffer (D700)
 E11B Restore output index (FE85)
 E11E And continue >>E0B1
 E120 End of Name
 E121 Fully qualified name? (FE84)
 E124 Yes >>E12B
 E126 No - Got a Prefix (BF9A)
 E129 No - error >>E0F2
 E12B Else, okay to exit

E12C ***** MLI SET PREFIX CALL *****

E12C Copy Pathname <E081>
 E12F It's okay >>E13B
 E131 Check length of Volume name (D700)
 E136 If zero - no Prefix wanted (BF9A)
 E139 Exit with no error
 E13A RETURN
 E13B Get File entry for last index <E593>
 E13E Okay? >>E144
 E140 Invalid Pathname?
 E142 No - Out now! >>E182
 E144 Sub Directory file? (FE27)
 E14B No, error >>E180
 E14D Fully qualified path? (FE84)
 E150 Yes >>E155
 E152 No - use old Prefix also (BF9A)
 E155 ---
 E157 Compute new Prefix Index (FE66)
 E15A Does new Prefix exceed 64 characters?
 E15C Yes - Bad Path error >>E0F2
 E15F Store new Prefix pointer (BF9A)

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E165

ADDR DESCRIPTION/CONTENTS

```

E165 Set Device Number of Prefix Directory (FE67)
E16B Save Keyboard for Prefix Directory (FE68)
E174 Copy Prefix to top of Path buffer (D7000)
E177 (preceded by old Prefix if one exists) (D7000)
E17F Exit normally

E180 Bad File Type Error
E182 ---
E183 RETURN

E184 ***** MLI GET PREFIX CALL *****
***** MLI GET PREFIX CALL *****
*****

E184 Set ($4E) -> Data Buffer
E190 Set Length = 64 (max)
E19A Validity check buffer storage <FC46>
E19D Error? >>E182
E1A1 Get Prefix index (BF9A)
E1A5 No Prefix? - Length = 0 >>E1AB
E1A7 Complement for length
E1AB Store in first byte of buffer
E1AD If null Prefix exit >>E1C5
E1AF ---
E1B0 Copy Prefix to caller's buffer replacing (D7000)
E1B3 index level name length bytes with "/"
E1BD ---
E1C1 End it with a "/"
E1C5 ---
E1C6 Exit normally

E1C7 ***** VALIDITY CHECK REFERENCE NUMBER *****
(PASSED BY CALLER)

E1C7 Get Reference Number
E1CB If zero then no good >>E228
E1CF If > 8 then no good >>E228
E1D1 Save Reference Number
E1D2 Multiply by 32
E1D8 Result gives offset into FCB's (FE5A)
E1DC Get back Reference Number
E1DD File Control Block active this Reference? (D800)
E1E0 No - Bad Reference Number >>E223
E1E2 Get Buffer Number (D80B)
E1E5 Find Buffer address in Global Page <FC00>
E1EB No Buffer? >>E214
E1ED Buffer okay, save Page Pointer in $4B
E1F1 Second block in $49
E1F3 Set last Device used in Global Page (D801)
E1F9 Finish setting up pointers (FEA5)
E1FC ($4A) -> 1st Block of Buffer (data)

```

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E1FE

ADDR DESCRIPTION/CONTENTS

```

E1FE ($48) -> 2nd Block of Buffer (index)
E200 ---
E201 Search all Volume Control Blocks (D910)
E204 for the one which goes with requested unit (D801)
E209 ---
E20F Can't find matching Volume Control Block
E211 So die with error type $0A <BF0C>
E214 No Buffer in open File Control Block
E216 So die with error type $0B <BF0C>
E219 Is Volume mounted? (D900)
E21C No, keep looking >>E209
E21E Save Volume Control Block index (FE59)
E222 Exit normally

E223 ---
E225 This looks wrong!!!! (FE5A)
E228 Bad Reference Number error
E22B RETURN

E22C ***** MLI ONLINE CALL *****
*****

E22C Set ($4E) -> Data Buffer <FlF5>
E22F Set Length = 0
E239 Get Unit Number
E23B Do all Units? >>E244
E23D No, just one
E23F Set length = 16 (FEA2)
E242 Always taken >>E249
E244 If all Units
E246 Set Length = 256 (maximum) (FEA3)
E249 Is Buffer in main RAM? <FC46>
E24C No, then exit >>E281
E24E Yes, zero out Buffer
E253 ---
E258 Index into Data Buffer = $00 (FE32)
E25D Get Unit Number again
E25F Isolate valid bits
E261 Specific Unit requested? >>E282
E263 No, copy Device List from Global Page <E847>
E266 Save Device Count (FE85)
E269 Get last Device (FE92)
E26C Generate return data for it <E282>
E26F Bump data buffer index by 16 (FE82)
E278 Get next Device (FE85)
E27C And go do it >>E266
E27E When done, exit
E281 RETURN

```

PRODOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E281
 ADDR DESCRIPTION/CONTENTS

```

E282 Save Device Number (BF30)
E285 Scan for the Volume Control Block <E859>
E288 Error? >>E2C5
E28A No
E28E Read block 2 (Volume Directory) <E8C9>
E291 Get Volume Control Block offset (FE59)
E294 Volume Directory read OK >>E2A5
E296 Bad read, save error number
E297 Any file open? (D911)
E29A Yes >>E2A2
E29C Zero out this VCB entry (D900)
E2A2 Put error number in Accum
E2A3 Always taken >>E2C5

E2A5 Volume name exist? (D900)
E2A8 No >>E2AF
E2AA Yes, Files open? (D911)
E2AD Yes >>E2BB
E2AF No, set up Volume Control Block for new VOL <E8B4>
E2B2 Error? >>E2C5
E2B4 No
E2B6 Was a duplicate Volume Control Block found? (FE7D)
E2B9 Yes, then error >>E2C5
E2BB See if the same Volume is still there (FE59)
E2C1 If not, Disk Switch Error
E2C3 Else, all is well - continue >>E2E3

E2C5 ***** ERROR *****
      Store code in data buffer entry
      ---
E2C5 Store Device Number in entry <E2F8>
E2C6 Store error code next
E2CD Duplicate Volume error?
E2CF No - done >>E2E1
E2D2 Store Device Number for duplicate next (FE7E)
E2DA No Duplicate now
E2E1 Exit with error
E2E2 RETURN

E2E3 ***** MAKE ONLINE VOLUME ENTRY *****
E2E3 Get name length for loop index (D900)
E2EC Copy name to Buffer entry (D900)
E2F3 Done yet? (FE80)
E2F6 No, do another >>E2EC
E2F8 Yes, find current Buffer entry (FE82)
E2FB Store Device number (BF30)
E303 Return to caller

```

PRODOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E303
 ADDR DESCRIPTION/CONTENTS

```

E304 *****
      ***** MLI CREATE CALL *****
      *****
E304 Follow Path to File <E5A6>
E307 Error? - I'm expecting one >>E30D
E309 If File was found - Duplicate error
E30B ---
E30C Return to caller

E30D File not found?
E30F NO, then a real error occurred >>E30B
E311 Yes, get requested storage type
E315 Is it 00, $01, $02 or $03?
E317 Yes, carry on >>E31D
E319 Is it $0D?
E31B No, then exit with error >>E32D
E31D Get status of this device (BF30)
E323 Exit on error >>E330
E325 Is there a free Directory entry? (FE63)
E328 NO >>E331
E32A Yes - continue >>E3BF

E32D Indicate Bad Storage Type
E330 Return to caller

E331 Is this the Volume Directory? (FE0E)
E337 NO, we can extnd it >>E33D
E339 Yes, indicate Volume Directory Full error
E33C Return to caller

      * EXTEND DIRECTORY FILE *

E33D Save old current Block number
E343 Allocate a Block on Disk <EA9C>
E346 Save the number
E347 Replace BLKNUM
E34D Was there a free Block?
E34E NO, then exit >>E330
E350 Yes, set up forward pointer in old one (DC02)
E353 to point to it (DC03)
E356 and Write old Directory Block <EBD5>
E359 Error? Yes, then exit >>E330
E35D Set BLKNUM -> new Block number
E362 Back point to old Directory Block (DC02)
E368 Loop until done >>E35D
E36C Zero remainder of Block Buffer (DC02)
E36F (including forward pointer) (DD00)
E373 Loop until done >>E36C
E375 Write new Directory Block <EBD5>

```

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E378
 ADDR DESCRIPTION/CONTENTS

E378 Error? Yes, then exit >>E330
 E37A Set BLKNUM -> Parent Directory block number (FE0E)
 E380 Read Block with my entry <EBC9>
 E383 Entry number within the Parent Dir. block (FE10)
 E386 None relocatable!!
 E388 Set (\$48) -> Buffer
 E38A Skip link pointers
 E38C ---
 E38D Count entries
 E390 Skip to next (FE11)
 E399 Save LSB
 E39D Add 1 to Blocks used
 E39F and \$200 to EOF mark (FD96)
 E3A2 in entry
 E3A8 Loop until done >>E39D
 E3AA Write back Block to Parent Directory <EBD5>
 E3AD Error? then exit >>E3BE
 E3AF Start all over now that there's room >>E304

E3B2 ***** ZERO \$F600 *****

E3B2 Zero \$F600 Block Buffer
 E3BE Return to caller

E3BF ***** BUILD NEW FILE *****

E3BF Call Zero \$F600 routine <E3B2>
 E3C2 Copy Datetime (Creation)
 E3C4 to my variables
 E3D0 Loop until done >>E3C4
 E3D2 Did he give Datetime (Creation)?
 E3D3 Yes, carry on >>E3E0
 E3D5 No, then use
 E3D7 System Datetime instead (BF90)
 E3E0 If Storage type is \$00, \$01, \$02 or \$03
 E3E2 force it to \$10
 E3E8 else use a \$D0
 E3EA Find File name (FE82)
 E3ED OR Storage type to name length (D700)
 E3F0 Store Type/Length (FE27)
 E3F3 Isolate name length
 E3F7 Copy File name to File Entry Buffer (FE82)
 E405 Copy caller's Access Byte
 NOTE: This should be validity checked!!!
 and copy File type
 E40D ---
 E412 and AUX TYPE
 E413 Copy Version and Min Version (0,0) (FDB8)
 E41C constants to entry (FE43)
 E41F Indicate 1 Block used
 E428 Copy Directory Header Block number (FE22)
 E42D

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E43C
 ADDR DESCRIPTION/CONTENTS

E43C Is this a Seedling file?
 E43E Yes >>E475
 E440 No, Directory file - Build Header in \$F600
 E442 Copy completed Directory entry (FE27)
 E445 to \$F600 buffer first (DC04)
 E449 Loop until done >>E442
 E44B Make Storage type \$E in Header itself
 E450 Put "HUSTON" (Author) in Reserved area
 E458 and Version, Min Version, Access, (FDB8)
 E45B Entry-length, File count and (DC20)
 E45E Parent pointer from constants
 E45F Loop until done >>E452
 E463 EOF = \$200 (FE3D)
 E466 Copy Parent Block entry number (FE24)
 E46D Loop until done >>E466
 E46F Copy Parent entry Length (FE19)
 E475 Allocate a new disk block <EA9C>
 E478 error? >>E4B1
 E47A Store it in key pointer of entry (FE38)
 E480 and in BLKNUM for I/O
 E484 Write zeroed (or DIR HDR) key clock <EBD5>
 E487 error? >>E4B1
 E489 Bump parent's file count (FE1B)
 E491 Go update directory <E4B2>
 E494 error? >>E4B1
 E496 Checkpoint Volume Bit Map and exit >>EB76

E499 ***** POINT \$48/49 AT DIRECTORY ENTRY *****

E499 \$48/\$49 --> Entry
 E49D Skip link pointers (+4)
 E49F File entry number counter (FE26)
 E4A2 ---
 E4A3 Skip to proper entry
 E4A6 Add entry length (FE19)
 E4AB (bump MSB)
 E4AF (store LSB)
 E4B1 RETURN

E4B2 ***** UPDATE DIRECTORY(S) *****

E4B2 System date available? (BF90)
 E4B5 no, forget it >>E4C2
 E4B9 yes, copy to last modified date field (BF90)
 E4C2 turn on BUBIT (backup) if appropriate (FE45)
 E4CB set DEVNUM of parent (FE21)
 E4D1 and BLKNUM (FE24)
 E4D7 reread DIR block containing entry <EBC9>
 E4DA error? >>E4B1
 E4DC Point to proper entry in buffer <E499>
 E4E3 Copy constructed entry to buffer (FE27)

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E4EF

```

ADDR  DESCRIPTION/CONTENTS
-----
E4EE  Is this block the DIR HDR block?
E4F9  no, write this modified directory block <EBD5>
E4FC  error? >>E4B1
E504  and then read DIR HDR block <EBC9>
E507  error? >>E4B1
E509  in any case..
E50B  copy back update file count to HDR (FE1B)
E514  and ACCESS byte (with Backup) (FE18)
E51A  re-write the HDR block <EBD5>
E51D  error? >>E573
E51F  is this the VOL DIR? (DC04)
E526  yes, all done -- exit >>E591
E528  is subdirectory, get PARENT ENTRY, (DC29)
E52B  store in variable area (FE26)
E52E  Get PARENT_ENTRY_LENGTH, (DC2A)
E531  store in variable area (FE19)
E534  get parent block number (DC27)
E53A  read Parent Directory block <EBC9>
E53D  error? >>E573
E53F  find entry for this subdirectory <E499>
E542  system date available? (BF90)
E545  no >>E554
E547  yes,
E54B  copy system date/time to... (BF90)
E54E  modified date/time in entry
E554  write it back <EBD5>
E557  error? >>E573
E55B  BLKNUM = HDR block number
E564  same block we have now?
E568  yes, go back and date stamp >>E51F
E56A  no,
E56E  read HDR block <EBD9>
E571  and go back to date stamp parent DIR >>E51F
E573  error? then exit

E574  ***** NOT ProDOS VOLUME ERROR *****
E574  ---
E577  RETURN

E578  ***** IS THIS ProDOS VOLUME? *****
E578  Does previous block ptr = 0? (DC00)
E586  no, not a ProDOS volume >>E574
E588  else, (DC04)
E58D  does VOL DIR's STORAGE TYPE = $E or $F?
E58F  no, error >>E574
E591  else, ok
E592  RETURN

```

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E592

```

ADDR  DESCRIPTION/CONTENTS
-----
E593  ***** GET FILE ENTRY *****
E593  follow path to it's end <E5A6>
E596  error? >>E5A5
E59B  copy file entry
E5A3  and exit
E5A5  RETURN

E5A6  ***** FOLLOW PATH TO A FILE *****
E5A6  get base dir's data <E723>
E5A9  error? >>E5FC
E5AB  another subdirectory in the path? >>E5D4
E5AD  no, at end of path
E5AF  $48/$49 --> $F604 (HDR)
E5B7  copy part of HDR to file entry
E5C1  File type = $F (Directory) (FDB0)
E5C4  BLOCK = 2 (FE27)
E5C7  No. blocks used = 4
E5C8  EOF = $800
E5CC  TYPE = subdirectory ($D0)
E5D1  return to caller
E5D3  RETURN

      *** SCAN DIRECTORY FOR FILE ***

E5D4  indicate no free entry found as yet
E5D9  signal in HDR block
E5DA  zero count of names examined
E5DF  find name in block <E6CD>
E5E2  got it! >>E644
E5E4  not yet, how many entries expected? (FE60)
E5E7  less entry number I just searched (FE5F)
E5EC  more file entries left to search? >>E5FE
E5FA  no, directory error
E5FC  ---
E5FD  RETURN

E5FE  yes, update entries left counter (FE60)
E603  back to first buffer page ($49)
E605  check next block pointer (DC02)
E60D  if zero, directory error >>E5FA
E612  read next block of directory <EBC9>
E615  no errors, loop back for more >>E5DA
E617  exit if error

```

```
ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: E617
-----
ADDR  DESCRIPTION/CONTENTS
-----
```

*** NO MORE FILE ENTRIES ***

```
E618 free entry found in directory? (FE63)
E61B yes >>E638
E61D no, check pointers (DC02)
E620 is there another block after this one? >>E627
E625 no... >>E638
E627 yes, free entry will be.. (FE24)
E630 first in that block
E635 indicate free entry available (FE63)
E638 find next index name <E764>
E63B exiting with error
E63C no more indicies in path, file not found >>E641
E63E else, path not found
E640 RETURN
```

```
E641 file not found error
E643 RETURN
```

*** FOUND FILE ENTRY ***

```
E644 advance to next subdir in path <E75D>
E647 end -- save entry no. and exit >>E6B5
E64B get type of entry
E64F subdir?
E651 no, bad path then >>E63B
E655 copy key block no...
E657 to BLKNUM
E65A and to current DIR block no (FE22)
E664 go read key block of subdirectory <EBD9>
E667 error? >>E68D
E66C new file count (FE60)
E675 check minimum version (DC21)
E678 too new? >>E68B
E680 count bits in reserved field of DIR hdr
E681 --- >>E684
E684 ---
E687 there must be 5 bits on (normally $75)
E689 (there are) >>E68F
E68B or else, incompatible file format
E68D ---
E68E RETURN
```

```
E68F copy DIR HDR <E695>
E692 and go scan for next level >>E5D4
```

```
ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: E692
-----
ADDR  DESCRIPTION/CONTENTS
-----
```

E695 ***** COPY DIRECTORY HDR *****

```
E695 Copy:
E697 CREATION, VERSION, MIN VERS, ACCESS, (DC1C)
E69A ENTRY_LEN, ENTRIES_PER_BLK, FILE_COUNT (FE12)
E6A0 volume_directory? (DC04)
E6A7 if so, exit now >>E6B4
E6AB else, copy PARENT_POINTER, (DC27)
E6AE PARENT_ENTRY_NO., and PARENT_ENTRY_LEN (FE0E)
E6B4 RETURN
```

E6B5 ***** SAVE DIR ENTRY NO. & BLOCK *****

```
E6B5 compute entry number (FE1A)
E6BE save it (FE26)
E6C3 and the block it's in (FE24)
E6CC exit
```

E6CD ***** SEARCH ONE DIR BLOCK FOR FILE *****

```
E6CD get entries in this block (FE1A)
E6D3 $48/$49 --> first entry
E6D9 ---
E6DB skip HDR? >>E710
E6DD no, non empty entry?
E6E1 yes >>E6F0
E6E3 no, do we need one? (FE63)
E6E6 no >>E710
E6E8 yes, remember it <E6B5>
E6EB don't need another one now (FE63)
E6EE skip to next entry >>E710
E6F0 get length of name
E6F2 count it (FE5F)
E6F5 save it for loop (FE80)
E6FB same len as we are wanting? (D700)
E6FE no, skip it >>E710
E700 ---
E704 compare names (D700)
E70E we found it! exit
E70F RETURN
E710 skip to next entry (FE62)
E714 end of block? if so, exit >>E70F
E71A bump $48/$49 by entry len
E721 and go check next >>E6D9
```

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E721

ADDR DESCRIPTION/CONTENTS

E723 ***** GET DIRECTORY DATA *****

```

E723 find base directory <E77C>
E726 error? >>E77B
E72C zero out my variables (FE0E)
E732 set up device number (BF30)
E738 copy DIR HDR to my variables <E695>
E741 copy TOTAL BLOCKS from VCB (D912)
E747 copy BIT MAP Pointer from VCB (D91A)
E74D copy Block No. of this directory (0046)
E753 make second copy of file count (FE1B)
E75D advance to next subdir in path <E764>
E760 and update index (FE82)
E763 RETURN

```

E764 ***** ADVANCE TO NEXT DIR NAME *****

```

E764 get this DIR's index (FE82)
E76B add len of name to move index to next name (FE82)
E76F still in prefix portion? >>E777
E771 no, now starting caller's path suffix (BF30)
E774 save last DEVNUM accessed (FE67)
E777 return with len of next dir in path (D700)
E77B RETURN

```

E77C ***** FIND BASE DIRECTORY *****

```

E77C ---
E77E get old PFXPTR (BF9A)
E781 fully qualified pathname? (FE84)
E784 no >>E787
E786 yes, no old PFXPTR anymore
E787 save old prefix index (FE83)
E78A DEVNUM=0 (BF30)
E78D ---

```

*** SCAN VCB'S FOR A MOUNTED VOLUME ***

```

E78F scan (D900)
E792 got one >>E79F
E799 else, bump to next VCB

```

*** FIND LAST DIR IN PREFIX OR TOL DIR ***

```

E79F store name length (FE80)
E7A2 same name as in pathname? (D700)
E7A5 no -- skip it >>E794
E7B3 save VCB index (FE59)
E7B6 DEVNUM = VCB's unit no. (D910)
E7BC BLOCK = 2 (read VOLDIR if no old PFX)

```

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E7C4

ADDR DESCRIPTION/CONTENTS

```

E7C4 get old prefix index (FE83)
E7C7 ---
E7C8 accumulate a new index (FE82)
E7CB no previous prefix? >>E7DD
E7CE find last name in prefix (D700)
E7D3 read prefix directory instead of vol dir (FE68)
E7DD read block <EBD9>
E7E0 error? >>E7E7
E7E2 is this the right directory? <E881>
E7E5 Yes--exit. >>E80B

```

*** IF NOT THERE, REMOUNT ALL VOLS ***
 *** AND CHECK THEM ***

```

E7E7 open files? (FE59)
E7ED yes, give up now >>E808
E7EF else, (FE83)
E7F2 put back old prefix length (FE82)
E7F5 copy DVCLST from global page <E847>
E7FB use last device accessed first >>E80C
E7FD if none, get last in my device table (BF31)
E808 volume not found error
E80B RETURN

```

```

E80C ---
E80F search for device in device table (FE92)
E817 device not found >>E808
E819 when found, make it active device (BF30)
E81E remove it from table (FE92)
E821 find its VCB <E859>
E824 not found? >>E846
E826 volume mounted there? (FE59)
E82C no >>E833
E82E yes, open files here? (D911)
E831 yes, skip it -- get next unit >>E7FD
E833 else read block 2 (vol dir)
E837 read volume directory <EBC9>
E83A error? >>E7FD
E83C mount volume on VCB <E8A7>
E83F error? >>E7FD
E841 is this his chosen volume? <E881>
E844 no, try again >>E7FD
E846 yes, exit

```

E847 ***** COPY GBL DEVLIST TO MY TABLE *****

```

E847 start with last device (BF31)
E84A get a unit number (BF32)
E84F copy it to device table (FE92)
E855 return count of devices (BF31)
E858 RETURN

```

```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: E858
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

E859 ***** SCAN VCB'S FOR DEVICE NO. *****

```

```

E859 ---
E85D scan VCB's for a given device number
E864 not it? >>E86B
E866 is it, save VCB index (FE59)
E869 and exit normally
E86A RETURN

E86B else, volume mounted here? (D900)
E86E yes >>E874
E871 no, save VCB index to empty unit (FE59)
E874 ---
E876 bump to next VCB
E878 and go look at it >>E85D
E87A not found...
E87B any free entries? if not, error >>E87E
E87D else, all is well -- return empty VCB
E87E VCB table full error
E880 RETURN

```

```

E881 ***** COMPARE DIR NAME WITH PATH LVL *****

```

```

E881 ---
E886 check DIR type (DC04)
E889 VOL DIR or SUB DIR?
E88B neither >>E894
E88D yes..
E88F store len of its name (FE80)
E892 and go on >>E899
E894 error exit
E895 RETURN

```

```

E896 compare directory names (DC04)
E89C no match? >>E894
E8A5 they match! exit
E8A6 RETURN

```

```

E8A7 ***** MOUNT NEW VOLUME *****

```

```

E8A7 volume mounted? (FE59)
E8AD no, continue >>E8B4
E8AF yes, same one as one wanted? <E90C>
E8B2 if so exit, else fall thru >>E90B

```

```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: E8B4
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

E8B4 ***** SET UP VCB FROM VOLDIR *****

```

```

E8B4 zero out VCB
E8BF is this a ProDOS volume? <E578>
E8C2 no -- exit >>E90B
E8C4 duplicate vol in VCB's? <E930>
E8C7 yes -- exit with that one instead >>E90A
E8C9 get new volume's name length (DC04)
E8D0 add to VCB index (FE59)
E8D4 and copy to VCB name field in empty VCB (DC04)
E8DF store in VCB name len field (D900)
E8E2 copy DEVNUM to VCB unit field (BF30)
E8E8 copy total blocks to VCB (DC29)
E8F4 copy block no. of vol dir to VCB
E8FE copy bit map block no. to VCB (DC27)
E90A exit
E90B RETURN

```

```

E90C ***** COMPARE VOL NAMES TO MAKE *****
***** SURE THEY MATCH *****

```

```

E90C Get length (DC04)
E911 Same in VCB? (D900)
E914 Save VCB offset (FE58)
E917 Different from VCB >>E924
E919 Store len to use as buffer index
E91A Add length to VCB offset to get (FE58)
E91D index into VCB (last char of name)
E921 Compare names (D900)
E924 SEC if no match
E92B CLC if match
E92C Restore VCB offset to X-REG (FE58)
E92F RETURN

```

```

E930 ***** LOOK FOR DUPLICATE VOL *****

```

```

E930 start with first VCB
E932 ---
E933 this VCB has same name? <E90C>
E936 no >>E947
E938 yes, files open? (D911)
E93B yes >>E951
E93F no, mark VCB empty (NAME=0) (D900)
E942 (UNIT=0) (D910)
E945 and exit with no error >>E94F
E947 else,
E949 bump to next VCB
E94D and loop >>E932
E94F exit no errors
E950 RETURN

```

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E950
 ADDR DESCRIPTION/CONTENTS

E951 save flag (FE7D)
 E954 and VCB index of duplicate vol (FE7E)
 E957 exit with error
 E958 RETURN

E959 ***** SEE IF A QUANTITY OF FREE *****
 ***** BLOCKS IS AVAILABLE ON VOL *****

E959 any free blocks counted in VCB? (FE59)
 E962 yes >>E9B6

 *** COMPUTE VCB FREE BLOCK COUNT ***

E964 no, how many bit map blocks are there? <EA08>
 E967 save it (less 1) (FE64)
 E96C zero scratch (will count free blocks) (FE4E)
 E972 no block found yet
 E977 checkpoint bit map buffer <EB76>
 E97A error? >>E9CA
 E97F BLKNUM = bit map pointer (D91A)
 E989 read block to buffer <EBD9>
 E98C error? >>E9CA
 E98E count free blocks marked <E9CB>
 E991 drop no. remaining to do (FE64)
 E994 none left? >>E99F
 E996 some, BLKNUM = BLKNUM + 1
 E99C go process that >>E989

E99F did we find a free bit? (FE59)

E9A5 no -- volume full >>E9C7
 E9A7 save VCB bitmap block offset (D91C)
 E9AA save free block count in VCB also (FE4F)
 E9B6 are there enough to satisfy request? (D914)
 E9C5 yes, exit
 E9C6 RETURN

E9C7 volume full error
 E9CA RETURN

E9CB ***** SCAN AND COUNT BITMAP BLOCKS *****

E9CB scan through both buffer pages
 E9D2 counting one bits <E9F8>
 E9D0 ---
 E9E0 found free block already? (FE63)
 E9E3 if so -- done >>E9F7
 E9E5 any blocks found yet? (FE4E)
 E9EB no >>E9F7
 E9ED yes, compute total no. of bitmap blocks <EA08>
 E9F1 less number remaining (FE64)

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: E9F4
 ADDR DESCRIPTION/CONTENTS

E9F4 gives bitmap block with first free bit (FEb3)
 E9F7 exit

E9F8 ***** COUNT ONE BITS IN A BYTE *****

E9F8 shift and...

E9FB count bits that are on (FE4E)
 EA03 exit when byte goes to zero
 EA07 RETURN

EA08 ***** COMPUTE NO. BITMAP BLKS -1 *****

EA08 get blocks on vol count (-1) (FE59)
 EA14 ---
 EA15 isolate top nibble of block count
 EA16 for bit map block count
 EA19 RETURN

EA1A ***** FREE A BLOCK ON DISK *****

EA1A save MSB (FE64)
 EA1D and LSB
 EA21 block number passed too big for (D913)
 EA24 volume size? (FE64)
 EA28 yes, error >>EA98
 EA2B no, get bit position for block no.
 EA31 save it (FE63)
 EA35 divide block no. by 8 (FE64)
 EA38 giving byte offset as remainder
 EA41 save byte offset (FE6A)
 EA44 make quotient/2 into block index (FE64)
 EA47 remember which page in that block (FE6C)
 EA4A read bit map block (after checkpoint) <EB43>
 EA4D error? >>EA97
 EA4F are we at proper block of bitmap yet? (FE71)
 EA55 yes! >>EA6D
 EA57 no -- checkpoint <EB76>
 EA5A error? >>EA97
 EA5C indicate block wanted in VCB (FE64)
 EA65 DEVNUM of bitmap (FE6E)
 EA68 read actual block directly <EB87>
 EA6B error? >>EA97
 EA6D get byte offset into page (FE6A)
 EA70 which page? (FE6C)
 EA73 get bit pattern to set (FE63)
 EA76 page 0? >>EA80
 EA78 no, turn bit on in page 1 (DB00)
 EA7E and continue >>EA86
 EA80 turn bit on in page 0 (DA00)
 EA86 mark bitmap needs checkpoint
 EA8E count block freed (FE8A)

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: EA96

 ADDR DESCRIPTION/CONTENTS

EA96 exit normally
 EA97 RETURN

EA98 bad bitmap error
 EA9B RETURN

EA9C ***** FIND A FREE DISK BLOCK AND *****
 ***** AND ALLOCATE IT *****

EA9C go read bitmap <EB43>
 EA9F error? >>EAC4
 EA01 first page 0
 EAA6 scan 1st page of bitmap for free block(s) (DA00)
 EAAE bump tm page 1 of buffer (FE6C)
 EAB1 bump page offset (FE6B)
 EAB4 scan 2nd page too (DB00)
 EABC bump page (FE6B)
 EABF get next block <EB28>
 EAC2 continue >>EA01
 EAC4 error exit

EAC5 save byte index (FE6A)
 EAC8 shift combination of page no. and (FE6B)
 EACB byte offset left 3 bits to make (FE4F)
 EACE room for bit position.
 EADD depending on buffer page ... (FE6C)
 EAE2 reload bit pattern from page 0... (DB00)
 EAE7 or page 1 (DA00)
 EAEA shift bit pattern, bumping block no. LSB
 EAEB until a one bit is found >>EAF0
 EAF0 then shift it back the way it was
 EAF1 (with that bit turned off) >>EAF0
 EAF3 store LSB of block no. (FE4E)
 EAF6 store updated byte back in proper page (FE6C)
 EB03 indicate bitmap needs checkpoint
 EB0B one less block available in VCB (FE59)
 EB20 ---
 EB21 return with new block no. (FE4E)
 EB27 RETURN

EB28 ***** GET NEXT BITMAP BLOCK *****

EB28 use blocks of vol to compute (FE59)
 EB2B number of blocks in bitmap (D913)
 EB32 just scanned last block? (D91C)
 EB35 yes, no space >>EB72
 EB37 no, get next block (D91C)
 EB40 checkpoint old one <EB76>

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: EB40

 ADDR DESCRIPTION/CONTENTS

EB43 ***** READ BITMAP BLOCK *****

EB43 have we read bitmap for this unit yet? (FE59)
 EB4C yes >>EB5C
 EB4E no, checkpoint bitmap of some other unit <EB76>
 EB51 error? >>EB71
 EB56 get new bitmap unit no. (D910)
 EB5C was bitmap modified? (FE6D)
 EB5F yes >>EB66
 EB61 no, read it <EB87>
 EB64 error? >>EB71
 EB66 save bitmap block offset times 2 (FE59)
 EB69 (page number) (D91C)
 EB70 exit
 EB71 RETURN

EB72 disk full error
 EB75 RETURN

EB76 ***** CHECKPOINT VOLUME BITMAP *****

EB76 ---
 EB77 needs checkpoint? (FE6D)
 EB7A no >>EB71
 EB7C yes, write it <EBD1>
 EB7F error? >>EB71
 EB81 doesn't need checkpoint now
 EB86 exit

EB87 ***** READ BITMAP *****

EB87 save DEVNUM (FE6E)
 EB8A copy block offset wanted (FE59)
 EB94 BITMAP BLOCK = BITMAP PTR + BLOCK OFFSET (D91A)
 EBA2 set up read command

*** READ OR WRITE BITMAP ***

EBA4 save I/O command
 EBAA device = bitmap device (FE6E)
 EBB0 block = bitmap block (FE6F)
 EBBA point to bitmap buffer (EA82)
 EBBD do the I/O <EBDF>
 EBC2 restore old DEVNUM (BF30)
 EBC5 ok? >>EBC8
 EBC7 no, error exit
 EBC8 RETURN

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: EBC8

 ADDR DESCRIPTION/CONTENTS

EBC9 ***** READ BLOCK DESIGNATED BY A,X *****
 EBC9 Put low byte of block number in BLKNUM
 EBCB and high byte in BLKNUM+1
 EBCD Read a block <EBD9>
 EBD0 RETURN

EBD1 ***** WRITE BITMAP *****
 EBD1 set up write command
 EBD3 and go do it >>EBA4

EBD5 ***** WRITE BLOCK *****

EBD5 set up write command
 EBD7 and go do it >>EBDB

EBD9 ***** READ BLOCK *****

EBD9 set up read command

EBDB ***** READ OR WRITE BLOCK *****

EBDB save I/O command
 EBDD where is my buffer?
 EBDf save flags
 EBE0 and disable
 EBE3 Set low byte of Buffer pointer
 EBE5 to zero
 EBE7 Initialize Global Page System error to 0 (BF0F)
 EBFA set I/O transfer occurred flag
 EBFf set unit to do I/O on (BF30)
 EBF4 do block I/O <DEA4>
 EBF7 error? >>EBFC
 EBF9 no errors, restore things and exit
 EBFb RETURN

EBFC error exit
 EBFf RETURN

EBFF ***** MLI GET MARK CALL *****

EBFF copy mark to caller's list from FCB (FE5A)
 EC0F exit with no errors
 EC10 RETURN

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: EC10

 ADDR DESCRIPTION/CONTENTS

EC11 bad position error
 EC14 RETURN

EC15 ***** MLI SET MARK CALL *****

EC15 set up to...
 EC1D copy user's mark to temporary
 EC1F new mark variable (FE70)
 EC24 make sure it will not exceed EOF (D815)
 EC29 else, error >>EC11
 EC2C ---

*** STILL IN SAME DATA BLOCK? ***

EC32 get old mark (FE5A)
 EC35 find its block no. (*2) (D813)
 EC3D compute distance in pages from old mark's (FE73)
 EC41 block to new mark (FE4E)
 EC47 earlier -- need new data block >>EC58
 EC4B too far forward -- need new block >>EC58
 EC50 MSB's match? (D814)
 EC55 then mark is still in this block >>ED79

EC58 check storage type (D807)
 EC5B zero? >>EC64
 EC5D seedling, sapling or tree?
 EC61 no, special handling for DIR files >>EDAB

EC64 This is a bug!!!
 (The immediate addressing mode was used
 where absolute addressing was intended.)
 EC66 This will stomp on another FCB! (D800)
 EC69 return with bad REFNUM error
 EC6C RETURN

*** NEED DIFFERENT DATA BLOCK ***

EC6D copy storage type (D807)
 EC73 old data block needs writing? (D808)
 EC78 no >>EC7F
 EC7A yes, do so <EE83>
 EC7D error? >>ECE8
 EC7F see if new mark is outside the range of (FE5A)
 EC82 the current index block (D814)
 EC91 yes >>ECB1
 EC95 yes >>ECB1
 EC97 no, same index block (FE5E)
 EC9A check storage type

```

ProDOS MLI -- V1.2 -- 6 SEP 86          NEXT OBJECT ADDR: EC9B
-----
ADDR  DESCRIPTION/CONTENTS
-----
EC9B  sapling or tree are ok >>ED16

    *** SEEDLING ***

ECA0  seedling, check position (FE73)
ECA4  if position is outside of block 0..
ECA6  promote to sapling >>ED04
ECAE  else, (D80C)
      go get key block (seedling data block) >>ED6F

    *** NEED TO CHANGE DATA BLOCKS ***

ECB1  does old index block need dumping? (D808)
ECB6  no >>ECBD
ECB8  yes, do so <EE97>
ECBB  error? >>ECE8
ECBD  check storage type (FE5E)
ECC0  tree file?
ECC2  yes >>ECE9
ECC4  no, sapling (FE74)
ECC9  is position in first index block?
ECCC  no, need master index, subindex and data >>ED2F
ECCE  yes, first index, reset flags <ED9F>
ECD1  is this a seedling?
ECD2  if so, see if in first block >>EC9D

    *** SAPLING ***

ECD4  no, sapling, read its only index block <EE2A>
ECD7  error? >>ECE8
ECDC  set block no. of index block
ECE6  Always branch >>ED16

ECE8  Error exit

    *** TREE FILE/NEED ANOTHER INDEX BLOCK ***

ECE9  reset flags <ED9F>
ECEC  read master index block <EE2A>
ECEF  error? >>ECE8
ECF1  make index into block from (FE74)
ECF4  MSB of position/2
ECFA  is there a subindex there?
ECFC  yes! >>ED09
ED02  no, fall thru to make one

    *** GET NEW INDEX BLOCK ***

ProDOS MLI -- V1.2 -- 6 SEP 86          NEXT OBJECT ADDR: ED04
-----
ADDR  DESCRIPTION/CONTENTS
-----
ED04  need an index and data block
ED06  go allocate them >>ED2F

ED09  set up block no. of subindex
ED11  read it <EE0D>
ED14  error? >>ECE8

    *** SAPLING/TREE - THIS INDEX BLOCK ***

ED16  make block no. out of position (FE74)
ED1F  use as an index to examine index block
ED21  entry
ED27  if its zero...
ED2B  need new data block
ED2F  set flags for what to allocate (FE5A)
ED38  new index block being created?
ED3A  zero data block in any case <ED57>
ED3D  if not index block that's it >>ED79
ED3F  Zero the Index Block I/O Buffer <ED45>
ED42  and continue >>ED79

ED45  ***** ZERO INDEX BLOCK I/O BUFFER *****

ED45  ---
ED48  Zero first page
ED4F  and second page of Index Block I/O buffer
ED54  Restore pointer to beginning of buffer
ED56  RETURN

ED57  ***** ZERO OUT DATA BLK I/O BUFFER *****

ED57  ---
ED5A  Zero first page
ED61  and second page of data block I/O buffer
ED66  Restore pointer to beginning of buffer
ED68  RETURN

ED69  ***** READ FILE DATA BLOCK *****

ED69  set block no. LSB
ED6B  copy MSB from index entry
ED6F  ---
ED71  read new data block <EDF4>
ED74  error? >>ED9E
ED76  reset block allocation flags <ED9F>

```



```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: ED76
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: EDEF
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

*** GOT DATA BLOCK WANTED ***

```

ED79  ---
ED80  save previous mark in my variables (D812)
ED86  set new mark in the FCB (FE72)
ED91  ($4A/$4B --> data block buffer)
ED93  $4C/$4D --> start of the page in
ED95  the data block buffer which contains (FE73)
ED98  the mark.
ED9E  exit

```

ED9F ***** RESET BLOCK ALLOC FLAGS *****

```

ED9F  get flags (FE5A)
EDA5  turn off low 3 bits (allocate no new
EDA7  blocks to file) (D808)
EDAA  RETURN

```

EDAB ***** SET DIR FILE POSITION *****

```

EDAB  DIR file?
EDAD  yes! >>EDB4
EDAF  no, bad storage type error
EDB1  go to SYSERR <BF09>
EDB4  else, get page distance (FE4E)
EDB7  make it into blocks (divide by 2)
EDBE  new position beyond old? (FE73)
EDC1  yes >>EDD1
EDC3  else, use previous mark
EDC5  copy to BLKNUM <EDDF>
EDC8  error? >>EDEE
EDCA  count it (FE62)
EDCD  more to skip? >>EDC3
EDCF  no, got it >>ED79
EDD1  use next block pointer in DIR block
EDD3  copy to BLKNUM <EDDF>
EDD6  error? >>EDEE
EDD8  count it (FE62)
EDDB  more to skip >>EDD1
EDDD  got it now! >>ED79

```

*** COPY LINK TO BLKNUM ***

```

EDDF  copy block number link
EDE1  to BLKNUM
EDE4  if non zero,
EDEA  then go read block. >>EDF0
EDEE  else, EOF error
-----
EDEF  RETURN

```

EDF0 ***** READ FILE BLOCK *****

```

EDF0  set block number to read
EDF4  store read I/O command
EDF8  read to $48/$49 buffer
EDFA  read the block <EE50>
EDFD  error? >>EE0C
EE02  copy block no. just read to FCB
EE0C  exit

```

EE0D ***** READ SUB-INDEX BLOCK *****

```

EE0D  set read I/O command
EE11  read to $48/$49 buffer
EE13  read the block <EE50>
EE16  error? >>EE26
EE1B  save BLKNUM in FCB as current index
EE1D  block. (D80E)
EE26  exit

```

EE27 ***** WRITE KEY INDEX BLOCK *****

```

EE27  set write I/O command
EE29  Use bit instruction to skip over two bytes

```

EE2A ***** READ KEY INDEX BLOCK *****

```

EE2A  ---

```

EE2C ***** READ OR WRITE KEY INDEX BLOCK *****

```

EE2C  save command
EE2F  block no. is key block in FCB (FE5A)
EE34  use $48/$49 buffer

```

*** I/O BLOCK ***

```

EE36  set I/O command
EE38  and block no. (D800)
EE42  must be non-zero block number
EE46  or horrible death!
EE4B  fall through to read/write block (D801)

```

*** SET UP AND DO FILE BLOCK I/O ***

```

EE50  (xreg = buff ptr in zero page)
EE51  disable
EE52  set up buffer pointer
EE5D  get DEVNUM from FCB (D801)
EE63  set I/O transfer has occurred flag

```

PRODOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: EE68
 ADDR DESCRIPTION/CONTENTS

EE68 set unit no. from DEVNUM (BF30)
 EE6D no errors have occurred yet
 EE72 do block I/O <DEE4>
 EE75 error? >>EE7A
 EE77 no, exit normally
 EE79 RETURN
 EE7A else, exit with error
 EE7C RETURN

EE7D ***** CHECKPOINT BITMAP & KEY BLOCK *****

EE7D checkpoint bitmap buffer <EB76>
 EE80 go write key block for file >>EE27

EE83 ***** CHECKPOINT DATA BLOCK BUFFER *****

EE83 buffer pointer at \$4A/\$4B
 EE85 point to block no. in FCB
 EE8D go write buffer to disk <EE36>
 EE90 error? >>EEB4
 EE94 go turn off \$40 flag in FCB and exit >>EEAB

EE97 ***** CHECKPOINT INDEX BLOCK BUFFER *****

EE97 checkpoint volume bitmap <EB76>
 EE9A use \$48/\$49 buffer
 EE9C block no. is current index block in FCB
 EEA2 set to write
 EEA4 go write it to disk <EE36>
 EEA7 error? >>EEB4
 EEA9 no longer needs checkpoint
 EEAB set flags accordingly (FE5A)
 EEB4 and exit

EEB5 ***** MLI OPEN CALL *****

EEB5 search path for file <E593>
 EEB8 found it? >>EEBE
 EEB8 no, bad path error
 EEEB exit >>EEC5
 EEEB else, see if FCB already open on file <EF9B>
 EEC1 for write. if not, continue. >>EECB
 EEC3 else, file already open error
 EEC5 ---
 EEC6 RETURN

PRODOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: EEC6
 ADDR DESCRIPTION/CONTENTS

EEC7 Error -- unsupported storage type
 EEC8 RETURN

EECB get FCB index (FE5A)
 EED1 free FCB found? >>EED7
 EED3 no, all FCB's in use error
 EED6 RETURN

EED7 zero out unused FCB
 EEE2 copy file ID fields to FCB
 EEE5 (DEVNUM, DIR HDR BLK, DIR BLK, (FE5A)
 EEE8 DIR ENTRY NO.)
 EEEF isolate storage type (FE27)
 EEFB and copy to FCB (D807)
 EEFE get access (FE45)
 EF03 DIR file?
 EF05 no >>EF09
 EF07 yes, we are only reading (I hope)
 EF09 update access flag in FCB (D809)
 EF0E write protected? >>EF15
 EF10 no, another FCB open on this file? (FE5F)
 EF13 yes, no touchie >>EEC3

EF15 storage type must be < \$4
 EF19 or equal to \$D

EF1B else, storage type error >>EEC7

EF1D ---

EF1F copy key block, blocks used, and

EF21 EOF mark to FCB (FE5A)

EF31 BLKNUM = key block number

EF36 store REFNUM in FCB (FE62)

EF3C go check and assign I/O buffer <FBB1>

EF3F error? >>EF65

EF41 go find VCB and set buff ptrs <E1E2>

EF44 set current level in FCB (BF94)

EF4A seedling, sapling or tree? (D807)

EF4F no, skip next stuff >>EF7C

EF51 yes, make current mark in FCB outside

EF53 first index block to force a read of all (D814)

EF56 index blocks and BLOCK 0.

EF5A zero mark wanted, however (FE72)

EF60 go set mark to zero <EC32>

EF63 OK? >>EF81

EF65 no, save the error code

EF69 got and I/O buffer? (D80B)

EF6C no >>EF74

EF6E yes, free it <FC0E>

EF74 mark FCB not in use

EF7A exit with error

EF7B RETURN

ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: EF7B	ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: F001
ADDR	DESCRIPTION/CONTENTS	ADDR	DESCRIPTION/CONTENTS
EF7C	else, read key block to I/O buffer <EDFA>	F001	LENGTH = EOF - current mark (D815)
EF7F	error? >>EF65	F019	are we already at EOF? (FEA2)
EF81	bump open file count in VCB (FE59)	F01C	no >>F02E
EF87	indicate files are open in VCB (D911)	F01E	yes, EOF error
EF8F	put REF NUM in caller's parmlist (FE5A)	F023	else, zero length request? (FEA2)
EF99	exit with no errors	F029	no >>F02E
EF9A	RETURN	F02B	yes, set mark and exit >>F0E1
EF9B	***** FIND A FCB *****	F02E	validity check data buffer <FC46>
EF9B	***** FIND A FCB *****	F031	no good? >>F020
EF9B	***** FIND A FCB *****	F033	ok, get storage type for file <F200>
EF9B	***** FIND A FCB *****	F036	standard kind of file?
EF9B	***** FIND A FCB *****	F038	yes >>F03D
EF9B	***** FIND A FCB *****	F03A	no, DIR file >>F1A3
EF9B	***** FIND A FCB *****	F03D	else, set mark (to read proper buffers) <EC32>
EF9B	***** FIND A FCB *****	F040	error? >>F020
EF9B	***** FIND A FCB *****	F042	set up buffer indexing <F0F8>
EF9B	***** FIND A FCB *****	F045	move all that can be moved out of data buff <F122>
EF9B	***** FIND A FCB *****	F048	newline or len=0: exit now! >>F02B
EF9B	***** FIND A FCB *****	F04A	newline enabled? continue block by block >>F03D
EF9B	***** FIND A FCB *****	F04C	at least 1 block's worth left to be read? (FE76)
EF9B	***** FIND A FCB *****	F050	if not, never mind >>F03D
EF9B	***** FIND A FCB *****	F052	if so, store block count wanted (FE77)
EF9B	***** FIND A FCB *****	F055	get FCB flags <F5D6>
EF9B	***** FIND A FCB *****	F058	data block modified?
EF9B	***** FIND A FCB *****	F05A	yes, continue block by block for now >>F03D
EF9B	***** FIND A FCB *****		*** FAST DIRECT READ ROUTINE ***
EF9B	***** FIND A FCB *****	F05C	signal no read occurred yet (FE7A)
EF9B	***** FIND A FCB *****	F05F	read directly into caller's data buffer
EF9B	***** FIND A FCB *****	F067	set mark/read data block to caller's buff <EC32>
EF9B	***** FIND A FCB *****	F06A	error? >>F0D5
EF9B	***** FIND A FCB *****	F06C	bump buffer pointer to next location
EF9B	***** FIND A FCB *****	F070	drop length remaining by 512 bytes (FE76)
EF9B	***** FIND A FCB *****	F076	bump mark (FE73)
EF9B	***** FIND A FCB *****	F07E	and mark's MSB as necessary (FE74)
EF9B	***** FIND A FCB *****	F081	check if we are out of index block (FE74)
EF9B	***** FIND A FCB *****	F087	drop counter of multi-blocks (FE77)
EF9B	***** FIND A FCB *****	F08A	and keep on >>F099
EF9B	***** FIND A FCB *****	F08C	end of multi-block read, put ptrs back <F195>
EF9B	***** FIND A FCB *****	F08F	more to read? (FE75)
EF9B	***** FIND A FCB *****	F095	no, exit through finish-up >>F0E1
EF9B	***** FIND A FCB *****	F097	yes, conventional block by block read then >>F03D
EF9B	***** FIND A FCB *****		***** MLI READ CALL *****
EF9B	***** FIND A FCB *****		*****
EF9B	***** FIND A FCB *****	EF99	point to data buffer <F1F5>
EF9B	***** FIND A FCB *****	EF9C	copy request length <F1DA>
EF9B	***** FIND A FCB *****	EF9F	save access
EF9B	***** FIND A FCB *****	EFF0	set up marks <F207>
EF9B	***** FIND A FCB *****	EFF4	read access permitted?
EF9B	***** FIND A FCB *****	EFF6	yes >>EFFC
EF9B	***** FIND A FCB *****	EFF8	no, access error
EF9B	***** FIND A FCB *****	EFFC	will we read past EOF? >>F023
EF9B	***** FIND A FCB *****	EF9E	yes, (FE5A)

```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: F097
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

F099  crossed index block? go do set mark >>F067
F09B  make index block offset from mark (FE74)
F0A4  BLKNUM = next block in index block
F0AA  zero entry?
F0B2  if so, no direct read can occur until next (FE7A)
F0B5  set-mark/read >>F0BA
F0B7  get MSB of BLKNUM
F0BA  (put index ptr back)
F0BE  finish setting BLKNUM MSB
F0C0  if no read occurred within setmark, (FE7A)
F0C3  go back to setmark call >>F067
F0C7  disable
F0C8  do I/O to caller's buffer directly
F0CC  do block I/O directly <DEE4>
F0CF  error? >>F0D4
F0D2  go back for more >>F06C

```

*** ERROR CLEANUP ***

```

F0D4  ---
F0D5  ---
F0D6  set buffer ptrs/VCB <F195>
F0DA  ---
F0DB  finish up I/O <F0E1>
F0DF  exit with error
F0E0  RETURN

```

F0E1 ***** I/O FINISH UP *****

```

F0E1  ---
F0E4  return actual length read in caller's list (FEA2)
F0F5  and exit by setting new mark >>EC32

```

F0F8 ***** SET UP BUFFER INDEXING *****

```

F0F8  ---
F0FC  back up pointer to data buffer by an
F0FE  amount equal to the LSB of the mark (FE72)
F101  (which makes indexing easier)
F107  newline mode enabled? (D81F)
F10B  no, CLC >>F117
F10D  yes, SEC
F10E  copy newline mask (FE79)
F111  and newline character (D80A)
F117  first char index is LSB of mark in YREG (FE72)
F11A  $4C/$4D --> page containing mark
F11E  request count LSB in XREG (FE75)
F121  exit

```

```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: F121
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

F122 ***** COPY FROM I/O BLOCK BUFF *****

```

***** TO DATA BUFFER *****
EXITS IF:  LENGTH GOES TO ZERO
          NEXT BLOCK IS NEEDED
          NEWLINE IS FOUND
ON EXIT:  OVERFLOW FLAG SET IF DONE
          OVERFLOW ZERO IF NEXT BLOCK NEEDED

```

```

F122  ---
F123  partial page to move? >>F12D
F125  no, any full pages left? (FE76)
F128  no, read complete >>F17C
F12A  yes, drop MSB of request length (FE76)
F12D  ---
F12E  copy one byte $4C --> $4E
F132  check for newline if carry set >>F165
F134  ---
F135  end of requested chunk >>F150
F137  ---
F139  more bytes to copy >>F12E
F13B  end of page, bump pointers
F13F  bump new mark (FE73)
F147  finished first page of block buffer?
F14B  if so, continue >>F12E
F14E  no, need another block from disk >>F17F
F150  another page in request length? (FE76)
F153  no >>F16F
F156  more in this block-page? >>F15E
F158  no, on last page of block?
F15C  no >>F161
F15E  yes, drop request len by one page (FE76)
F161  back up to next byte again
F162  go copy next page >>F137
F165  check for newline
F16D  not it, never mind! >>F134
F16F  else, were we done with page?
F170  no >>F17C
F172  yes, bump pointer
F174  and mark (FE73)
F17C  set overflow flag (read completed) (F194)
F17F  update mark LSB (FE72)
F184  bump request count if necessary
F185  update count LSB (FE75)
F18B  point beyond data in caller's buffer
F193  ---
F194  and exit

```

ADDR	DESCRIPTION/CONTENTS
------	----------------------

F213 and set previous mark also (FE55)

F216 add length giving new mark in scratch area (FEA2)

F21D (3 byte addition)

```
F225 WILL new mark exceed EOF? (FE4E)
F233 return with carry set according to v
```

cczr
reccar
wrm
carry sec acco

F234 ***** SET NEW MARK & EOF *****

F234 set up indexes <F266>

```
F23/ set new EOF in FCB (FE52)
F03D set new mark (FE55)
```

```
F23D and new malloc (FE35)
F243 save new mark in scratch variable too (FE4E)
```

F24A does mark exceed EOF? <F266>

F24D if so, we must extend EOF <F225>

F253 save old EOF (D815)

```
F25B  set new EOF to mark if necessary (FE4E)
      EOF
```

F201	---
F265	evit

3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842

F266 subroutine to set 3 byte indexes

F26D RETURN

***** M.I. WRITE CALL. *****

F26E copy request length <FLDA>

F272 copy file mark <F207>

```
F275 extend EOF II needed <F250>
F279 write access enabled?
```

F27C while access enabled.
F27B ves > F281

F27D no, access error

F281 check status of this device <F431>

```
F284 error? >>F2C1
```

```
F286 request length = 0? (FEAZ)
F28C      C  \ F291
```

```
F28C  NO  >I251
F28E  ves. exit through finish-up >F0E1
```

THE HISTORY OF THE UNITED STATES

```
F291 find caller's data buffer <FlF5>
```

F294	check storage type
------	--------------------

```
F296      if DIR file, error >>F2/D
F300      set mark/read blocks <E33>
F300
```

```
F298 set MAILK/LEAD PROCSS \EC3Z/
F299 error? >>F2C1
```

```
F29D get FCB flags <F5D6>
```

F2A0 any new blocks needed?

F2A2 no >> F306

F2A4 yes, allocating them

FZA6 ---

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: F2A7

 ADDR DESCRIPTION/CONTENTS

F2A7 count number of blocks needed
 F2AA store number needed (FE5C)
 F2B0 see if the blocks are available <F959>
 F2B3 no, disk full >>F2C1
 F2B5 yes, get FCB flags <F5D6>
 F2B8 master index block needed?
 F2BA no >>F2C9
 F2BC yes, go add it <F381>
 F2BF and go on if no errors >>F2D5
 F2C1 error,
 F2C2 set new mark/EOF <F234>
 F2C6 and finish I/O, exit with error >>F0DA
 F2C9 check FCB flags again <F5D6>
 F2CC need sub-index block?
 F2CE no >>F2D5
 F2D0 yes, go do it <F3BD>
 F2D3 error? >>F2C1
 F2D5 buy a new block for data <F411>
 F2D8 error? >>F2C1
 F2DA get FCB flags <F5D6>
 F2DD indicate index buffer changed
 F2DF no new blocks needed now
 F2E1 update FCB flags (D808)
 F2E7 make index block offset from mark
 F2EF store new block no. in index block (FE4F)
 F2FC and store it as current data block (FE5A)
 F306 set up buffer indexing <F0F8>
 F309 start writing <F311>
 F30C go see if more blocks are needed >>F298
 F30E I/O finish up when done >>F0E1

F311 ***** COPY WRITE DATA TO I/O BLOCK *****

 F314 lower request count by 1 (FE76)
 F31C ---
 F31D copy partial page from caller's data
 F31F to I/O block buffer
 F324 ---
 F327 next page in caller's area
 F32B bump mark by \$100 (FE73)
 F333 still in same I/O block page?
 F337 yes >>F31C
 F33A no, clear overflow (I/O incomplete) >>F361

ProDOS MLI -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: F33A

 ADDR DESCRIPTION/CONTENTS

F33C any complete pages left to write? (FE76)
 F33F no >>F351
 F341 yes, more in this page?
 F342 yes >>F34A
 F344 no, first block-page?
 F348 no >>F34D
 F34A yes, one less complete page to do (FE76)
 F34D readjust index
 F34E continue with full page >>F324
 F351 ---
 F352 a few bytes left to write? >>F35E
 F354 no, bump data buffer by \$100
 F356 and mark (FE73)
 F35E set overflow (I/O complete) (F194)
 F361 store LSB of mark (FE72)
 F364 and of request count (FE75)
 F368 indicate data block modified <F5D6>
 F36B and DIR entry needs update
 F371 advance pointer into caller's buffer (FE72)
 F37C set FCB flag to indicate write occurred <FA2C>
 F380 exit

F381 ***** ADD NEW MASTER INDEX BLOCK *****
 (MAKE A TREE FILE)

F381 add higher level <F3CA>
 F384 error? >>F3C9
 F386 get storage type <F200>
 F389 tree?
 F38B yes >>F392
 F38D no, add another level <F3CA>
 F390 error? >>F3C9
 F392 buy another block <F411>
 F395 error? >>F3C9
 F397 male offset into current index block (FE74)
 F39A from current mark
 F39C point index to new block (FE4E)
 F3AB also save as current data block (FE5A)
 F3B5 checkpoint bitmap & key block <EE7D>
 F3B8 error >>F3C9
 F3BA zero out new index block >>ED45

F3BD ***** ADD NEW INDEX BLOCK *****

F3BD check storage type <F200>
 F3C2 seedling? >>F3CA
 F3C4 no, read key index block <EE2A>
 F3C7 and go add data block >>F392
 F3C9 exit if error occurs

```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: F3C9
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

*** ADD A HIGHER INDEX LEVEL TO FILE ***

```

```

F3CA  buy a block <F411>
F3CD  error? >>F410
F3D2  save old key block number (D80C)
F3DA  make new block the key block (D80C)
F3E7  and current index block in FCB (D80F)
F3F0  store pointer to old key block
F3F3  in first position of new index
F3FA  checkpoint bitmap and new key block <EE7D>
F3FD  error? >>F410
F3FF  get storage type <F200>
F404  upgrade it to next higher type (D807)
F407  indicate DIR entry needs update (D808)
F410  exit

```

```

F411  ***** BUY A DISK BLOCK *****

```

```

F411  allocate a disk block <EA9C>
F414  error? >>F430
F416  get FCB flags <F5D6>
F419  indicate DIR entry needs update
F422  add 1 to blocks in use for file
F42F  ---
F430  exit

```

```

F431  ***** DO STATUS IF NO I/O YET *****

```

```

F431  get FCB flags <F5D6>
F434  any buffers in use? (I/O activity)
F436  if so, assume its ok >>F42F
F438  no, (D801)
F43B  select new device (BF30)

```

```

*** STATUS CALL ***

```

```

F43E  Save Unit Number
F440  Save Block Number on stack
F446  Indicate Status call
F44A  Indicate Block 0
F44E  Go do I/O <DEE4>
F451  Restore Block Number to original value
F459  Exit

```

```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: F45A
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

F45A  ***** MLI CLOSE CALL *****
      *****

```

```

F45A  check REF NUM
F45E  specific close? >>F494

```

```

*** CLOSE ALL OPEN FILES ***

```

```

F460  no errors yet (FE39)
F465  store FCB index (FE5D)
F469  get its level (D81B)
F46C  if below system LEVEL, skip it (BF94)
F46F  yes, skip it >>F486
F471  no, active FCB? (D800)
F474  no >>F486
F476  yes, flush it and update directory <F4F2>
F479  error? >>F4C7
F47B  no, close specific FCB <F499>
F480  is this a close-all?
F482  yes, ignore errors >>F486
F484  no, stop on error >>F4C7
F486  bump FCB index to next one (FE5D)
F48C  and continue >>F465
F48E  when all FCBs checked, load error number (FE89)
F491  no error >>F4C5
F493  error exit

```

```

*** CLOSE SPECIFIC FILE ***

```

```

F494  flush it <F4FA>
F497  error? >>F4C7
F499  get buffer number (FE5D)
F49F  free its pages <FC11>
F4A2  error? >>F4C7
F4A4  release FCB
F4AC  set DEVNUM (D801)
F4B2  find VCB for device <E859>
F4B5  decrement count of open files in VCB (FE5C)
F4BB  some are open... >>F4C5
F4BD  if all are closed, turn off (D911)
F4C0  "files open" flag
F4C5  ---
F4C6  exit

```

```

F4C7  Branch to handle close error >>F4F7

```

ProDOS MLI -- V1.2 -- 6 SEP 86	ProDOS MLI -- V1.2 -- 6 SEP 86	ProDOS MLI -- V1.2 -- 6 SEP 86	ProDOS MLI -- V1.2 -- 6 SEP 86
ADDR	DESCRIPTION/CONTENTS	ADDR	DESCRIPTION/CONTENTS
F4C9 *****	***** MLI FLUSH CALL *****	F54C error? >>F4F7	***** CLOSE ERROR *****
F4CD yes >>F4FA	flush specific file?	F54E copy directory header <E695>	F5C7 *****
F4CF no, clear flush-all error code (FE89)		F551 are we in block with this file's entry? (FE27)	F5C7 is this a close or flush all?
F4D2 do all FCBs		F55A no >>F561	F5CC no >>F5D4
F4D4 set FCB index for next FCB (FE5D)		F55F yes >>F568	F5D0 yes, save error code (FE89)
F4D8 is this file open? (D800)		F561 no, set new block number	F5D3 RETURN
F4DB no >>F4E2		F565 read it <EBD9>	F5D4 else, real error right now
F4DD yes, flush it <F4F2>		F568 point at directory entry in block <E499>	F5D5 RETURN
F4E0 error? >>F4F7		F56B copy file entry from directory <E598>	F5D6 ***** GET FCB FLAGS *****
F4E2 bump to next FCB (FE5D)		F571 copy blocks used count to entry (D818)	F5D6 load FCB flags (FE5D)
F4E8 and go flush it too >>F4D4		F57F copy new EOF (D815)	F5D9 from FCB (D808)
F4EA ---		F58A and new key block no. (D80C)	F5DC and exit
F4EB return with error code if any (FE89)		F593 isolate new storage type (D805)	F5DD ***** FILE ACCESS ERROR *****
F4F1 RETURN		F59D combine it with name length (FE2A)	F5DD exit with file access error code
F4F2 ***** FLUSH A FILE & UPDATE DIRECTORY *****		F5A5 and update type/len field in entry (FE2A)	F5E0 RETURN
F4F2 find buffer/VCB <E1E2>		F5A8 write entry back to directory <E4B2>	F5E1 ***** MLI SET EOF CALL *****
F4F5 no error? >>F504		F5AB error? >>F5C7	*****
F4F7 go handle close error >>F5C7		F5B0 turn off "write occurred" flag (D81C)	
F4FA zero out close-all error		F5B8 same bitmap in memory (FE24)	
F4FF validity check REF NUM <E1C7>		F5BE no, exit now >>F5C5	
F502 error? >>F4F7		F5C0 yes, checkpoint it also <EB76>	
F504 is write access allowed? (D809)		F5C5 no errors, exit	
F509 no, exit >>F4EA		F5C6 RETURN	
F50B has a write occurred since last flush? (D81C)			
F50E yes >>F517			
F510 no, <F5D6>			
F513 does anything need flushing anyway?			
F515 no, then exit now >>F4EA			
F517 else, get FCB flags <F5D6>			
F51A has data buffer changed?			
F51C no >>F523			
F51E yes, checkpoint it <EE83>			
F521 error? >>F4F7			
F523 get flags again <F5D6>			
F526 has index buffer changed?			
F528 nm >>F52F			
F52A yes, checkpoint it <EE97>			
F52D error? >>F4F7			
F52F ---			
F536 copy file identifier data to my variables (D800)			
F540 set DEVNUM (BF30)			
F543 BLKNUM = current DIR block (FE25)			
F549 read DIR block <EBC9>			

ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: F5E1	ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: F70C
ADDR	DESCRIPTION/CONTENTS	ADDR	DESCRIPTION/CONTENTS
F5E1	get storage type <F200>	F70C	force current mark to infinity (D812)
F5E4	if DIR file...	F713	go set mark <EC32>
F5E6	its an access error >>F5DD	F716	no errors? >>F71F
F5E8	else, save type for truncate to	F718	if error, indicate in saved status
F5E9	mess with.	F71E	but continue
F5EF	write access permitted? (D809)	F71F	copy caller's EOF to FCB <F628>
F5F4	no, error >>F5DD	F722	Flush and update <F4FA>
F5F6	check device status <F431>	F725	no errors? >>F72E
F5F9	error? >>F5DD	F727	if error, indicate in saved status
F602	copy EOF from FCB (D815)	F72D	but continue
F610	copy caller's new EOF	F72E	---
F61B	compare old EOF to new (FE55)	F730	exit
F621	if less than or equal to... >>F628		
F623	if greater... >>F63D	F731	***** MLI GET EOF CALL *****
	*** OLD EOF <= NEW EOF ***		***** MLI GET EOF CALL *****
	*** NO TRUNCATE NEEDED ***		
F628	new eof beyond old	F731	---
F62F	copy caller's EOF to FCB	F736	copy EOF to caller's list (D815)
F63A	exit by indicating flush needed >>FA2C	F742	exit -- no errors
	*** OLD EOF > NEW EOF ***	F743	***** MLI NEW LINE CALL *****
	*** TRUNCATE FILE ***		***** MLI NEW LINE CALL *****
F63D	flush first <F4FA>	F743	---
F640	error? >>F5E0	F745	copy newline mask
F642	\$43/\$49 --> end of data block I/O buffer	F74E	and newline character
F64C	compare current mark to new EOF (FE5D)	F754	return, no errors
F659	it is prior to EOF >>F672		
F661	if past EOF, force mark back to EOF (FE5D)	F755	***** MLI GET FILE INFO CALL *****
F672	construct EOF block number and (FE75)		***** MLI GET FILE INFO CALL *****
F675	byte offset into block from new (FE91)		
F678	EOF mark. (FE76)		
F690	on a block boundary? (FE92)	F755	get the file entry <E593>
F693	yes >>F6B2	F758	ok? >>F79C
F695	no, (FE90)	F75A	no, bad path?
F699	decrement block by 1	F75D	no, real error >>F7B9
F6A7	but don't let it fall below 0	F75F	else, make it VOL DIR type
F6B2	copy key block number (FE5D)	F761	with name length = 0 (FE2A)
F6C1	set blocks freed to zero	F766	no free blocks needed (FE5F)
F6C9	truncate file at new EOF <FA3E>	F76C	go through the motions to update the (FE5C)
F6CC	save status	F76F	VCB block count. <E964>
F6D4	set new key block in FCB (FE8A)	F775	copy blocks free from VCB (D915)
F6DA	drop FCB block count by number (D818)	F781	copy total blocks on volume to AUX_ID (D913)
F6DD	of blocks freed in truncate routine. (FE8D)	F78F	total - free = blocks used (FE5F)
F6EA	copy new storage type (FE8C)	F79C	shift type down from high nibble (FE2A)
F6F7	turn off all block allocation flags <ED9F>	F7A8	copy the data to caller's parmlist (FDD7)
F6FA	update VCB free block count <F9BD>	F7B9	and exit
F704	copy mark (D812)		

ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: F7B9	ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: F832
ADDR DESCRIPTION/CONTENTS		ADDR DESCRIPTION/CONTENTS	

F7BA *****	***** MLI SET FILE INFO CALL *****	*** RENAME FILE ***	
F7BA	get the file entry <E593>	F833	get path index <F925>
F7BD	error? >>F7E4	F836	copy old name with prefix to my buffer (D700)
F7BF	indicate backup needed now (BF95)	F842	copy new name to buffer <F917>
F7CE	copy 13 parms from caller's list to (FDD7)	F845	error? >>F889
F7D1	file entry staging area >>F7D8	F847	get path index <F925>
F7D8	---	F84D	compare all levels of names up to and (DC00)
F7DD	if any spurious access bits are on...	F850	including the last. Find first which
F7E1	access error!	F851	differ.
F7E4	RETURN	F855	save indicies into names which point to (FE84)
F7E5	else, anything in his modification date?	F858	final name. (FE85)
F7E9	no >>F7EE	F85B	---
F7EB	yes, go update directory >>E4C2	F865	exit if they match completely
F7EE	no, use system date then update directory >>E4B2	F866	RETURN
F7F1 *****	***** MLI RENAME CALL *****	F867	index to differing new name (FE84)
F7F1	follow path to file <E5A6>	F86A	point past it (D700)
F7F4	ok? >>F833	F872	must be the last! (D700)
F7F6	no, bad name?	F875	it isn't >>F887
F7F8	no, real error >>F812	F877	it is, (FE85)
	*** RENAME VOLUME ***	F87A	do the same with the old name (DC00)
F7FA	yes, copy new name <F917>	F885	difference is only in last index? >>F88B
F7FD	error? >>F812	F887	no, bad path error
F7FF	get first length (D700)	F889	---
F803	get next (D700)	F88A	RETURN
F806	bad path if more than one name for vol >>F887	F88B	names good. follow path to new file <E5A6>
F80B	files open on volume? (D911)	F88E	better get an error >>F894
F80E	no, continue >>F814	F890	if found, duplicate name in directory
F810	yes, file open error	F893	RETURN
F812	---	F894	if error, better be file not found
F813	RETURN	F896	or else its really an error... >>F889
F814	make type/len for a VOL DIR HDR	F898	copy old pathname again <E081>
F81B	write new name to VOL HDR <F908>	F89B	get its file entry <E593>
F81E	error? >>F889	F89E	error? >>F889
F825	copy new name to device's VCB (D700)	F8A0	search FCB's <EF9B>
F831	exit, no errors	F8A5	exit if the file is open for write >>F889
F832	RETURN	F8AA	does ACCESS permit rename?
		F8AC	yes >>F8B2
		F8AE	no, access error
		F8B0	---
		F8B1	RETURN
		F8B2	get type/len from entry (FE2A)
		F8B7	DIR file?
		F8B9	yes, ok >>F8C3
		F8BB	seedling, sapling or tree?
		F8BD	yes, ok >>F8C3

ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: F8BF	ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: F95C
ADDR	DESCRIPTION/CONTENTS	ADDR	DESCRIPTION/CONTENTS
F8BF	else, compatibility error	F95C	check status of device (BF30)
F8C3	copy new path again <F917>	F962	error? >>F97E
F8C6	error? >>F889	F964	point to key block (FE3B)
F8C8	get length of last name (FE84)	F973	DIR file?
F8D3	copy it and name to file entry buffer (D700)	F977	no >>F980
F8E3	combine new len with type (D700)	F979	yes, handle differently >>F9D8
F8E9	DIR file?		
F8EB	no, go update entry and exit >>F905	F97C	File open error
F8ED	yes, (FE3B)	F97E	---
F8F3	read key block of this subdirectory <EBC9>	F97F	RETURN
F8F6	error? >>F889		
F8FB	copy new name to DIR HDR (D700)		*** DESTROY NON-DIRECTORY FILE ***
F900	and update directory's key block <F908>	F980	save the storage type (FE8C)
F903	error? >>F889	F987	set EOF to zero (FE8C)
F905	go update directory entry and exit >>E4C2	F98D	byte offset = \$200
		F992	"truncate" the file at EOF=0 <FA3E>
F908	***** COPY PATH TO BUFF & WRITE *****	F995	if error >>F97E
F908	copy type/len and path to my buffer	F997	free the key block in volume bitmap (FE8B)
F914	go write the block >>E8D5	F9A0	error >>F97E
F917	***** POINT TO NEW NAME *****	F9A2	mark the file as deleted in DIR
	COPY TO BUFFER	F9A7	decrement file count in DIR (FE1E)
F917	\$48/\$49 --> second pathname	F9B2	checkpoint volume bit map <EB76>
F922	go copy it >>E08C	F9B5	error >>F97E
F925	***** LOAD PATH INDEX *****	F9B7	update free block count in VCB <F9BD>
		F9BA	and go update the directory >>E4B2
F925	load pathname index		*** SUBROUTINE TO UPDATE FREE BLOCK ***
F92C	(including prefix if any) (BF9A)		*** COUNT IN VCB ***
F92F	---	F9BD	add blocks freed to total free blocks (FE5C)
F931	RETURN	F9C0	in VCB. (FE8D)
F932	***** MLI DESTROY CALL *****	F9D2	start next search for free blocks at
		F9D4	start of bitmap. (D91C)
		F9D7	exit
F932	get file entry <E593>		*** DESTROY DIRECTORY FILE ***
F935	error? >>F97E	F9D8	DIR file?
F937	find FCB if any <EF9B>	F9DA	no, error >>FA27
F93A	FCB open? (FE62)	F9DC	read volume bitmap block <EB43>
F93D	yes, file open error >>F97C	F9DF	error? >>FA26
F93F	no free blocks needed	F9E1	BLKNUM = key block pointer (FE3B)
F947	go compute VCB free block count <E959>	F9EB	read it <EBD9>
F94A	ok? >>F950	F9EE	errors? >>FA26
F94C	error, disk full?	F9F0	if DIR has any files... (DC25)
F94E	no, real error >>F97E	F9FA	access error
F950	DESTROY enabled in ACCESS? (FE48)	F9FF	write back block marking entry free (DC04)
F955	yes >>F95C	FA05	error? >>FA26
F957	no, access error	FA07	if "next_pointer" is zero.... (DC02)
		FALL	go back and pretend it's a seedling >>F997

```

PRODOS MLI -- V1.2 -- 6 SEP B6
NEXT OBJECT ADDR: FA13
NEXT OBJECT ADDR: FA92

```

ADDR	DESCRIPTION/CONTENTS
------	----------------------

```

FA13 else, (DC03)
FA16 free next block <EALA>
FA19 error? >>FA26
FA1B BLKNUM = next block (DC02)
FA21 read it <EBC9>
FA24 if ok, continue in loop >>FA07
FA26 else, error exit
FA27 incompatible file format error
FA2C ***** SET WRITE OCCURRED FLAG *****
FA2C save some registers
FA2F indicate write occurred (FE5D)
FA3A restore registers and exit
FA3D RETURN
FA3E ***** TRUNCATE FILE AT EOF *****
FA3E check storage type*16 (FEBC)
FA41 seedling?
FA43 yes >>FA52
FA45 no, sapling?
FA47 yes >>FA55
FA49 no, tree?
FA4B yes >>FA5B
FA4D General error--wrong storage type
FA4F jump to system death <BF0C>
FA52 go to seedling truncate >>FB24
FA55 go to sapling truncate >>FAEB
FA5B truncate tree,
FA5A at most 12B blocks in master index (FE93)
FA5D read the master index <FB4F>
FA60 error? >>FABD
FA62 at EOF yet? (FE93)
FA6B yes >>FABE
*** FREE WHOLE INDEX BLOCKS AFTER EOF ***
(free 8 subindex blocks each time the
master index block is read since we must
share its buffer)
copy up to 8 non-zero index block
FA6A numbers to (DC00)
FA6F a handy table (FE95)
FA80 ---
FA89 if there weren't 8 left to do, zero (FE95)
FABC remainder of the table (FE9D)

---
update master index counter (FE93)
for all 8 entries: (FE94)
set BLKNUM, (FE95)
(exit when a 0 entry is found), >>FA5D
read the sub-index block, <EBD9>
(quit if error), >>FABD
zero all its blocks, <FB7D>
(quilt if error), >>FABD
and loop until all 8 are done. >>FA98
then go back and reread master index >>FA5D
normal exit
RETURN
FABD
FABE now go free all the sub-index blocks (FE8F)
FAC2 which follow EOF <FB7F>
FAC5 if error >>FABD
FAC7 write back master index <EBD5>
FACA if error >>FABD
FACC EOF in first subindex? (FE8F)
FACF if so, demote to sapling file >>FAE6
FAD1 else, BLKNUM = subindex block which (DC00)
contains the EOF mark
FAD4 (exit if none there) >>FABC
FAD9 else, read the final subindex block <EBD9>
FAE0 and treat it as a sapling file >>FAF0
FAE3 unless there is an error.
FAE5
FAE6 Demote tree to sapling <FB5B>
FAE9 if error >>FABD
*** TRUNCATE SAPLING FILE ***
read index block <FB4F>
FAEB if error >>FABD
FAEE index of last block in the file (FE90)
FAF0 add one to point past end of file
FAF3 if zero, no blocks to free >>FB00
FAF4 zero blocks past EOF <FB7F>
FAF6 if error >>FABD
FAF9 write back modified index block <EBD5>
FAFB if error >>FABD
FAFE index of last block in file (FE90)
FB00 this index block is empty! >>FB1A
FB03 get BLKNUM of last data block (DC00)
FB05 (no block allocated?) >>FABC
FB0D read in last data block <EBD9>
FB14 and treat it as a seedling file >>FB29
FB17 unless error occurred.
FB19

```

ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: FB19
ADDR DESCRIPTION/CONTENTS	
FB1A more index blocks (tree file)? (FE8F)	
FB1D yes, must be tree file >>FB05	
FB1F no, demote to seedling <FB5B>	
FB22 if error >>FB4E	
*** TRUNCATE SEEDLING FILE ***	
FB24 read key block <FB4F>	
FB27 error? >>FB4E	
FB29 EOF in first page? (FE92)	
FB2C yes >>FB34	
FB2E EOF in second page?	
FB2F no, exactly 256 bytes >>FB4D	
FB31 get byte offset (FE91)	
FB34 ---	
FB36 zero bytes in second page (DD00)	
FB3C EOF in first page? (FE92)	
FB3F no, we're done. >>FB4A	
FB41 yes, zero bytes in first page, too (FE91)	
FB4A then write block back and exit >>EBD5	
FB4D exit normally	
FB4E RETURN	
FB4F ***** READ INDEX BLOCK *****	
FB4F Put index block number in A,X (FE8A)	
FB55 Go read the block >>EBC9	
FB5B ***** DEMOTE FILE TO SMALLER FILE TYPE*****	
FB5B get high byte of index block (FE8B)	
FB5E and low byte (FE8A)	
FB61 free the index block in the volume bitmap <EA1A>	
FB64 if error >>FB7C	
FB66 Establish first block of old index block (DC00)	
FB69 as new index block. (FE8A)	
FB73 reduce storage type by one (FE8C)	
FB7B and exit	
FB7C RETURN	
FB7D ***** FREE ALL BLOCKS IN AN INDEX BLK *****	
FB7F save BLKNUM	
FB85 Save Y-register (index within block) (FE68)	
FB90 if it is non-zero....	
FB97 free the block in the volume bitmap <EA1A>	
FB9A if error >>FBAB	
FB9C Restore index to Y-reg (FE68)	
ProDOS MLI -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: FB9F
ADDR DESCRIPTION/CONTENTS	
FB9F zero this entry	
FBA7 ---	
FBA8 loop through all entries >>FB85	
FBAB save error message, if any	
FBAD restore old BLKNUM	
FBB3 and exit	
FBB4 ***** ALLOCATE I/O BUFFER *****	
FBB4 ---	
FBB6 get I/O buffer page number	
FBB9 can't be below \$800	
FBBB else, error >>FBFF	
FBBD can't be above \$BC00	
FBBF else, error >>FBFF	
FBC4 \$4A/\$4B --> I/O buffer	
FBC8 must be page aligned! >>FBFF	
FBCF ---	
FBCF check each page of I/O buffer for <FC3A>	
FB2 prior allocation in system bit map (BF58)	
FBDF ---	
FBE0 if ok, mark each page as allocated <FC3A>	
FBE3 in system memory bit map (BF58)	
FBF0 assign buffer number (REFNUM*2) in FCB (D800)	
FBF8 and save buffer location in buffer list	
FBFD exit	
FBFE RETURN	
FBFF bad I/O buffer error	
FC02 RETURN	
FC03 ***** LOCATE I/O BUFFER *****	
FC03 ---	
FC04 AREG contains buffer number *2 (BF6E)	
FC07 move buffer pointer to NEXTBUF variable (FEA8)	
FC10 exit	
FC11 ***** FREE I/O BUFFER *****	
FC11 is buffer already free? <FC03>	
FC16 yes, exit >>FC38	
FC1A zero its address in system global page (BF6F)	
FC27 ---	
FC28 free each page in buffer <FC3A>	
FC2B by marking system bit map	
FC38 exit	
FC39 RETURN	

```
ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: FC39
-----
ADDR  DESCRIPTION/CONTENTS
-----
```

```
FC3A ***** LOCATE BIT MAP POSLTION *****
      (GIVEN PAGE NUMBER)
```

```
FC3A  XREG contains page number
FC3B  compute page number times 8
FC3E  use as offset for bitmask (FDCB)
FC45  page number / 8 = byte offset
FC46  into bitmap
FC48  exit
```

```
FC49 ***** CHECK BUFFER VALIDITY *****
      START > $200      END < $BF00
```

```
FC49  get buffer address (MSB)
FC4D  must be >$200 else error >>FBFF
FC4F  get length (FEA6)
FC55  compute last page no. of buffer
----
FC5A  may not extend into $BF00
FC61  else, error >>FBFF
FC63
```

```
*** CHECK 1F BLOCK OF MEMORY 1S FREE ***
```

```
FC66  ---
FC67  see if this page is allocated <FC3A>
FC6D  if so, error >>FBFF
FC6F  else, check other pae also
FC73  then exit if both have been checked
FC74  RETURN
```

```
FC75 ***** MLI GET BUFF CALL *****
***** MLI GET BUFF CALL *****
```

```
FC75  get next available buffer
FC7A  put its address in caller's parmlist
FC82  and exit
FC83  RETURN
```

```
FC84 ***** MLI SET BUFF CALL *****
***** MLI SET BUFF CALL *****
```

```
FC84  mark his buffer allocated
FC89  error? >>FCAB
FC8B  get old buffer address (FEA9)
FC95  free old buffer's pages in map <FC20>
FC9C  copy old buffer contents
FC9E  to new buffer
FCAA  then exit
```

```
ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: FCAB
-----
ADDR  DESCRIPTION/CONTENTS
-----
```

```
FCAB  RETURN
```

```
FCAC ***** GO TO QUIT CODE HANDLER *****
```

```
FCAC  enable 2nd 4K bank of language card (C083)
FCAF  (Quit code lives at $D100-$D3FF) (C083)
FCB4  Get first four bytes of page 0, (0000)
FCB7  save them on the stack
FCBB  Set ($00) -> $D100
FCBD  Set ($02) -> $1000
FCB9  Set Y = 0
FCCA  3 pages of code to copy
FCCC  ---
```

```
copy quit code handler to $1000
The next five lines of code were added for this version (1.2).
Fortunately they did not survive the next version (1.3).
Let's hope that whoever wrote this "fancy" code
is now working for Commodore.
```

```
FCDD  pull 4 saved bytes off stack
FCDE  and restore them to page 0 (FF04)
FCE4  enable HIGH RAM BANK1 (C08B)
FCE7  (MLI) (C08B)
FCE7  point RESET vector at $1000 (03F2)
FCF4  set power-up byte properly
FCF9  go to quit code handler at $1000 >>1000
```

```
FCFC ***** ACCESS RAM-BASED DEVICE DRIVER *****
```

```
This (undocumented?) routine allows a device driver
to reside in BANK2 of auxiliary high RAM (they normally
reside in slot ROM). When the device driver is set up,
the address of this routine, which may be found at $3EA,
becomes the address of the device driver. Bytes $3E4 and $3E5
are changed to the address of the real driver in aux high RAM.
This routine must call the page 3 routine at $3D6
because the MLI is in main high RAM and will be
swapped out. The page 3 routine calls the real driver
and returns here with the error code, if any.
```

```
FCFC  Get current P-reg in accumulator,
FCFE  then save it on the stack
FCFF  clear overflow flag
FD00  interrupts disabled?
FD02  no >>FD07
FD04  yes, set overflow flag (FD25)
FD07  disable interrupts
FD08  enable RAM, BANK2 (C083)
FD0E  set carry, indicating error
FD0F  indicate 6 bytes to move to aux z-page
FD11  Call real driver thru page 3 routine <03D6>
FD14  store error number (BF0F)
FD17  enable RAM, BANK1 (C08B)
```

```

FD40 GET FILE INFO ***** MLI COMMAND ADDRESS TABLE *****

```

```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: FD70
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

FD70 CREATE
FD72 DESTROY
FD74 RENAME
FD76 SET FILE INFO
FD78 GET FILE INFO
FD7A ON LINE
FD7C SET PREFIX
FD7E GET PREFIX
FD80 OPEN
FD82 NEWLINE
FD84 READ
FD86 WRITE
FD88 CLOSE
FD8A FLUSH
FD8C SET MARK
FD8E GET MARK
FD90 SET EOF
FD92 GET EOF
FD94 SET BUF
FD96 GET BUF

```

```

FD98 ***** MLI COMMAND INFO BYTE *****

```

```

PATHNAME FLAG
| REFERENCE NUMBER FLAG
| | DATETIME STAMP FLAG
| | | COMMAND NUMBER
| | | |
FD98 1 0 1 - 00
FD99 1 0 1 - 01
FD9A 1 0 1 - 02
FD9B 1 0 1 - 03
FD9C 1 0 0 - 04
FD9D 0 0 0 - 05
FD9E 0 0 0 - 06
FD9F 0 0 0 - 07
FDA0 1 0 0 - 08
FDA1 0 1 0 - 09
FDA2 0 1 0 - 0A
FDA3 0 1 0 - 0B
FDA4 0 0 1 - 0C
FDA5 0 0 1 - 0D
FDA6 0 1 0 - 0E
FDA7 0 1 0 - 0F
FDA8 0 1 0 - 10
FDA9 0 1 0 - 11
FDAA 0 1 0 - 12
FDAB 0 1 0 - 13

```

```

ProDOS MLI -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: FDAB
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

FDAC ***** CONSTANTS - DATA AREA *****
FDAC Blocks Used
FDAE End of File
FDB1 Special ID (Must be 5 bits on)
FDB2 'HUSTONI' Author's name
FDB9 Previous Block of Vol Dir Key Block
---
THE FOLLOWING IS COPIED TO SUBDIR HDR+$20
FDBB Version of ProDOS
FDBC Minimum Version
FDBD Access Byte (D|Rn|B|000|W|R)
FDBE Entry Length
FDBF Entries per Block
FDC0 File Count
FDC2 Parent LSB (copied to SUBDIR HDR +$20)
---
FDC3 File Type (Directory)
FDC4 Block Number
FDC6 Number of Blocks
FDC8 End of File

```

```

FDCB ***** BITMASK TABLE *****

```

```

FDCB 10000000
FDCC 01000000
FDCD 00100000
FDCE 00010000
FDCF 00001000
FDD0 00000100
FDD1 00000010
FDD2 00000001

```

```

FDD3 ***** OFFSETS INTO FILE CONTROL BLOCKS *****
FDD3 *** (FCB's are at $D800-$D8FF) *****

```

```

FDD3 Key Block

```

```

FDD5 # Blocks Used

```

```

FDD7 End of File

```

```

FDDA ***** SET/GET FILE_INFO OFFSETS *****

```

```

FDDA Access
FDDB File Type
FDDC Aux Type
FDDF Storage Type
FDDF Blocks Used (MSB on means GET only no SET)

```



```

ProDOS MLI -- V1.2 -- 6 SEP 86          NEXT OBJECT ADDR: FDE0
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

FDE1  Datetime (Last Mod)
FDE5  Datetime (Creation)
FDE9  ***** FATAL ERROR MESSAGE *****
FDE9  ' INSERT SYSTEM DISK AND RESTART' -ERR 0 '
FDE1  ---
FDE1  ***** VARIABLES - DATA AREA *****

```

```

FDE1  Parent Pointer Block
FDE3  Parent Entry Number
FDE4  Parent Entry Length
FDE5  Datetime (Creation)
FDE9  Version
FDEA  Min Version
FDEB  Access Byte
FDEC  Entry Length
FDED  Entries per Block
FDEE  File Count
FDE0  Bit Map Pointer
FDE2  Total Blocks
FDE2  THE FOLLOWING 6 BYTES UNIQUELY IDENTIFY
      A FILE:
FDE4  Device Number
FDE5  Current Directory Block Number (HDR)
FDE7  Block Number of File Entry in Directory
FDE9  File Entry Number in Directory
FDEA  ***** FILE ENTRY SUFFER *****

```

```

FDEA  Type/Length (TTTTLLLL)
FDEB  File Name (Max 15) >>000F
FDE3  File Type
FDEB  Key Pointer
FDE3  8locks Used
FDE3  End of File
FDE4  Datetime (Creation)
FDE6  Version
FDE7  Min Version
FDE8  Access Attribute
FDE9  Aux Type (Load Address/Record Length)
FDEB  Datetime (Last Mod)

```

```

ProDOS MLI -- V1.2 -- 6 SEP 86          NEXT OBJECT ADDR: FE4D
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

FE4F  Header Pointer
FE51  ***** Variable Work Area *****
FE51  3 Byte Scratch
FE54  ---
FE55  End of File
FE58  Previous Mark
FE5B  Compare Vol Name Scratch
FE5C  Offset into VCB Table ($D900)
FE5D  Offset into FCB Table ($D800)
FE5E  Free FCB found Flag
FE5F  Number of Free Blocks needed
FE61  Storage Type
FE62  Number of Entries Examined or..
FE63  FCB already open flag
FE63  File Count
FE65  Entries/Block Loop Count/Free FCB's refnum
      Free Entry Found Flag (if > 0) or..
      # of 1st bitmap block with free bit on or..
FE66  bit for free
FE67  # 8locks in 8itmap left to search
FE68  Y Register temp
FE69  Pathname Length
FE6A  Devnum for Prefix Directory Header
FE6B  8lock of Prefix Directory Header
FE6D  Bitmap Byte Offset in Page
FE6E  8itmap Page Offset
FE6F  Bitmap Buffer Page (0 or 1)
FE70  8itmap Flag (if $80, needs writing)
FE71  8itmap DEVNUM
FE72  8itmap Block Number
FE74  Bitmap Block offset for Multiblock Bitmaps
      New Mark to be Positioned to for Set Mark
      or New Moving Mark (for READ)
FE75  or New EOF for SET_EOF
FE78  Request Count (Read/Write etc.)
FE7A  Multi-Block I/O count
FE7B  Newline character
FE7C  Newline mask
FE7D  I/O Transfer occurred flag

```

```

ProDOS MLI -- V1.2 -- 6 SEP 86                NEXT OBJECT ADDR: FE7E
-----
ADDR  DESCRIPTION/CONTENTS
-----
FE7E  MLI Command * 2
FE7F  ORED into Access Flags ($20 - Backup)
FE80  Duplicate Volume Flag (if $FF)
FE81  Duplicate Volume's VCB index
FE82  MLI function code (low 5 bits)
      Characters in current Pathname indx lvl or
FE83  ONLINE: volname len - loop index
FE84  new pathname: index to last name
      old pathname: index to last name or..
FE85  ONLINE: index to data buffer
FE86  Old PFI PTR value
FE87  Pathname fully qualified flag (if $FF)
      Pathname: temp save area for index or..
FE88  ONLINE: DEVCNT
FE89  close-all error code
FE8A  Set EOF: new Key Block pointer
FE8C  New storage type (SET_EOF)
FE8D  Freed Blocks count
FE8F  EOF Block number (MSB then LSB)
FE91  EOF byte offset into Block
FE93  EOF - Master index counter
FE94  Save area for index into table below

FE95  ***** DEVICE TABLE BUILT BY ONLINE *****
      (also used by SET_EOF to keep track of
      8 blocks to be freed at a time)

FE95  device table part one
FE9D  device table part two

FEA5  length of path, etc.
FEA8  next buffer address
FEAA  16 byte stack save area
FEBA  6 byte zero page save area
FEC0  Jump Vector, used for indirect jumps

FEC2  ***** $FEBF-$FEFF NOT USED *****
FEC2  not used

```


ProDOS MLI -- V1.3 -- 2 DEC 86	ProDOS MLI -- V1.3 -- 2 DEC 86	Next Object Addr: FA58	Next Object Addr: FAF0
ADDR	DESCRIPTION/CONTENTS	ADDR	DESCRIPTION/CONTENTS
FA5B	go to sapling truncate >>FAF6	FAF1	Demote tree to sapling <FB63>
FA5E	truncate tree,	FAF4	if error >>FAC8
FA60	at most 128 blocks in master index (FEBC)		*** TRUNCATE SAPLING FILE ***
FA63	read the master index <FB5A>	FAF6	read index block <FB5A>
FA66	error? >>FAC8	FAF9	if error >>FAC8
FA68	at EOF yet? (FEBC)	FAFB	index of last block in the file (FEB9)
FA6E	yes >>FAC9	FAFE	add one to point past end of file
	*** FREE WHOLE INDEX BLOCKS AFTER EOF ***	FAFF	if zero, no blocks to free >>FB0B
	(free 8 subindex blocks each time the	FB01	zero blocks past EOF (when truncating) <FB97>
	master index block is read since we must		or swap bytes for all but first block (when destroying).
	share its buffer)	FB04	if error >>FAC8
		FB06	write back modified index block <EBD5>
FA70	copy up to 8 non-zero index block	FB09	if error >>FAC8
FA72	numbers to (DC00)	FB0B	index of last block in file (FEB9)
FA75	a handy table (FEBC)	FB0E	this index block is empty! >>FB25
FA86	----	FB10	Get BLKNUM of last data block (DC00)
FA8F	if there weren't 8 left to do, zero (FEBC)	FB18	(no block allocated?) >>FAC7
FA92	remainder of the table (FEC6)	FB1F	read in last data block <EBD9>
FA98	----	FB22	and treat it as a seedling file >>FB34
FA99	update master index counter (FEBC)	FB24	unless error occurred.
FA9E	for all 8 entries: (FEBD)	FB25	more index blocks (tree file)? (FEB8)
FAA1	set BLKNUM, (FEBC)	FB28	yes, must be tree file >>FB10
FAA9	(exit when a 0 entry is found), >>FA63	FB2A	no, demote to seedling <FB63>
FAB0	read the sub-index block, <EBD9>	FB2D	if error >>FB59
FAB3	(quit if error), >>FAC8		*** TRUNCATE SEEDLING FILE ***
FAB5	zero all its blocks (if truncating) <FB95>	FB2F	read key block <FB5A>
	or swap pages (if destroying),	FB32	error? >>FB59
FAB8	(quit if error), >>FAC8	FB34	EOF in first page? (FEBB)
FABA	write the former index block back out, <EBD5>	FB37	yes >>FB3F
FAC3	and loop until all 8 are done. >>FA9E	FB39	EOF in second page?
FAC5	then go back and reread master index >>FA63	FB3A	no, exactly 256 bytes >>FB58
FAC7	normal exit	FB3C	get byte offset (FEBA)
FAC8	RETURN	FB3F	----
FAC9	now go free all the sub-index blocks (FEB8)	FB41	zero bytes in second page (DD00)
FACD	which follow EOF <FB97>	FB47	EOF in first page? (FEBB)
FAD0	if error >>FAC8	FB4A	no, we're done. >>FB55
FAD2	write back master index <EBD5>	FB4C	yes, zero bytes in first page, too (FEBA)
FAD5	if error >>FAC8	FB55	then write block back and exit >>EBD5
FAD7	EOF in first subindex? (FEB8)		
FADA	if so, demote to sapling file >>FAF1	FB58	exit normally
FADC	else, BLKNUM = subindex block which (DC00)	FB59	RETURN
FADF	contains the EOF mark		
FAE4	(exit if none there) >>FAC7		
FAEB	else, read the final subindex block <EBD9>		
FAEE	and treat it as a sapling file >>FAFB		
FAF0	unless there is an error.		

```

ProDOS MLI -- V1.3 -- 2 DEC 86          NEXT OBJECT ADDR: FB59
-----
ADDR  DESCRIPTION/CONTENTS
-----

FB5A ***** READ INDEX BLOCK *****
FB5A Put index block number in A,X (FEB3)
FB60 Go read the block >>EBC9

FB63 ***** DEMOTE FILE TO SMALLER FILE TYPE *****
FB63 get high byte of index block (FEB4)
FB66 save it on stack
FB68 get low byte (FEB3)
FB6B save it, too
FB6C free the index block in the volume bitmap <EALA>
FB6F restore the block number of the index block
FB70 to zero page.
FB75 if error writing bitmap >>FB94
FB77 New index block is first block (DC00)
FB7A from old index block. (FEB3)
FB83 For first entry in old index block,
FB85 zero the block number (if truncating) <FBC7>
      or swap the bytes (if destroying).
FB89 reduce storage type by one (FEB5)
FB91 Write the deleted index block back out. <EBD5>
FB94 RETURN

FB95 ***** FREE ALL BLOCK NUMBERS IN *****
      *** AN INDEX BLOCK ***

FB95 ---

FB97 ***** FREE BLOCK NUMBERS BEYOND EOF *****

FB97 save BLKNUM
FB9D Save Y-register (index within block) (FE91)
FBAB if it is non-zero....
FBAB free the block in the volume bitmap <EALA>
FBAB if error >>FBBE
FBBA Restore index to Y-reg (FE91)
FBB7 zero this entry (when truncating) or <FBC7>
      swap the two bytes (when destroying).
---
FBBA loop through all entries >>FB9D
FBBA save error message, if any
FBC0 restore old BLKNUM
FBC6 and exit

ProDOS MLI -- V1.3 -- 2 DEC 86          NEXT OBJECT ADDR: FBC7
-----
ADDR  DESCRIPTION/CONTENTS
-----

FBC7 ***** ZERO OR SWAP INDEX BLOCK BYTES *****
--- >>0001
FBC7 This a destroy operation? (FEBB)
FBCA Yes, swap the two bytes. >>FBCF
FBCB No, zero both bytes.
FBCD A 65C02 instruction!!! >>FBD5
      Note: we think this 65C02 instruction (BRA)
      snuck in by accident. It is the only
      65C02 instruction in all of ProDOS and
      means the 1.3 version won't run on Apple IIs
      that don't have a 65C02. But it is easy to
      patch this--just change the byte at $FBCD
      ($4CCD in the load image) from $80 to $F0,
      because BEQ works fine here.
      Save higher page byte in X-register (DD00)
      Get lower page byte in A-reg and (DC00)
      store A-reg in higher page byte. (DD00)
      Get X-register and
      FBD9 put it in lower page byte. (DC00)
      FBD0 RETURN

FBCF Save higher page byte in X-register (DD00)
FBD2 Get lower page byte in A-reg and (DC00)
FBD5 store A-reg in higher page byte. (DD00)
FBD8 Get X-register and
FBD9 put it in lower page byte. (DC00)
FBD0 RETURN

FBDD ***** ALLOCATE I/O BUFFER *****
---
FBDD get I/O buffer page number
FBE2 can't be below $800
FBE4 else, error >>FC28
FBE6 can't be above $BC00
FBE8 else, error >>FC28
FBED $A/$4B --> I/O buffer
      must be page aligned! >>FC28
---
FBF7 check each page of I/O buffer for <FC63>
FBF8 prior allocation in system bit map (BF58)
---
FC08 if ok, mark each page as allocated <FC63>
      in system memory bit map (BF58)
FC19 assign buffer number (REFNUM*2) in FCB (D800)
FC21 and save buffer location in buffer list
FC26 exit
FC27 RETURN
FC28 bad I/O buffer error
FC2B RETURN

```

```

ProDOS MLI -- V1.3 -- 2 DEC 86      NEXT OBJECT ADDR: FC2C
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

FC2C ***** LOCATE I/O BUFFER *****
FC2C ---
FC2D AREG contains buffer number *2 (BF6E)
FC30 move buffer pointer to NXTBUF variable (FED1)
FC39 exit
FC3A ***** FREE I/O BUFFER *****

```

```

FC3A is buffer already free? <FC2C>
FC3F yes, exit >>FC61
FC43 zero its address in system global page (BF6F)
FC50 ---
FC51 free each page in buffer <FC63>
FC54 by marking system bit map
FC61 exit
FC62 RETURN

```

```

FC63 ***** LOCATE BIT MAP POSITION *****
      (GIVEN PAGE NUMBER)

```

```

FC63 XREG contains page number
FC64 compute page number times 8
FC67 use as offset for bitmask (FDF4)
FC6E page number / 8 = byte offset
FC6F into bitmap
FC71 exit

```

```

FC72 ***** CHECK BUFFER VALIDITY *****
      START > $200      END < $BF00

```

```

FC72 get buffer address (MSB)
FC76 must be >$200 else error >>FC28
FC78 get length (FECF)
FC7E compute last page no. of buffer
FC83 ---
FC8A may not extend into $BF00
FC8C else, error >>FC28

```

```

      *** CHECK IF BLOCK OF MEMORY IS FREE ***

```

```

FC8F ---
FC90 see if this page is allocated <FC63>
FC96 if so, error >>FC28
FC98 else, check other page also
FC9C then exit if both have been checked
FC9D RETURN

```

```

ProDOS MLI -- V1.3 -- 2 DEC 86      NEXT OBJECT ADDR: FC9D
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

FC9E ***** MLI GET_BUFF CALL *****
      *****

```

```

FC9E get next available buffer
FCA3 put its address in caller's parmlist
FCAB and exit
FCAC RETURN

```

```

FCAD ***** MLI SET_BUFF CALL *****
      *****

```

```

FCAD mark his buffer allocated
FCB2 error? >>FCD4
FCB4 get old buffer address (FED2)
FCBE free old buffer's pages in map <FC49>
FCC5 copy old buffer contents
FCC7 to new buffer
FCD3 then exit
FCD4 RETURN

```

```

FCD5 ***** GO TO QUIT CODE HANDLER *****

```

```

FCD5 enable 2nd 4K bank of language card (C083)
FCD8 (Quit code lives at $D100-$D3FF) (C083)
FCDD Get first four bytes of page 0, (0000)
FCE0 save them on the stack
FCE4 Set ($00) -> $D100
FCE6 Set ($02) -> $1000
FCF2 Set Y = 0
FCF3 3 pages of code to copy
FCF5 ---
FCF6 copy quit code handler to $1000
FD04 pull 4 saved bytes off stack
FD0D enable HIGH RAM BANK1 (C08B)
FD10 (MLI) (C08B)
FD15 point RESET vector at $1000 (03F2)
FD1D set power-up byte properly
FD22 go to quit code handler at $1000 >>1000

```

```

FD25 ***** ACCESS RAM-BASED DEVICE DRIVER *****

```

```

This (undocumented?) routine allows a device driver
to reside in BANK2 of auxiliary high RAM (they normally
reside in slot ROM). When the device driver is set up,
the address of this routine, which may be found at $3EA,
becomes the address of the device driver. Bytes $3E4 and $3E5
are changed to the address of the real driver in aux high RAM.
This routine must call the page 3 routine at $3D6
because the MLI is in main high RAM and will be

```

PRODOS MLI -- 2 DEC 86
NEXT OBJECT ADDR: FD25
PRODOS MLI -- V1.3 -- 2 DEC 86
NEXT OBJECT ADDR: FD5E

ADDR	DESCRIPTION/CONTENTS	ADDR	DESCRIPTION/CONTENTS
------	----------------------	------	----------------------

swapped out. The page 3 routine calls the real driver and returns here with the error code, if any.

```

FD25 Get current P-reg in accumulator,
FD27 then save it on the stack
FD28 clear overflow flag
FD29 interrupts disabled?
FD2B no >>FD30
FD2D yes, set overflow flag (FD4E)
FD30 disable interrupts
FD31 enable RAM, BANK2 (C083)
FD37 set carry, indicating error
FD38 indicate 6 bytes to move to aux z-page
FD3A Call real driver thru page 3 routine <03D6>
FD3D store error number (BF0F)
FD40 enable RAM, BANK1 (C08B)
FD46 restore original P-reg
FD48 if error number is zero, (BF0F)
FD4B then indicate no error; >>FD4E
FD4D otherwise indicate error
FD4E RETURN

```

[illegible]

This routine calls a subroutine located at \$D400 in BANK2 of high RAM. It is called when MLI command \$42 is executed. Its purpose is to install a routine that handles unclaimed interrupts. Apparently the user must supply the routine at \$D400.

FD4F Switch to BANK2 of high RAM, (C083)
FD52 execute the program there, <D400>
FD55 then back to BANK1 (C08B)
FD58 and return.

< L C

```
*          *  
* DATA AREA  
*****
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
84

```

IN HASH CODE ORDER: IF COMMAND IS...
ABCD EFGH (IN BINARY 8ITS)
INDEX IS COMPUTED AS:
000D EFGH
+0000 ABCD

```

```
FD59 GET BUF
FD5A UNUSED
FD5B UNUSED
FD5C UNUSED
FD5D ALLOC INTERRUPT
```

ADDR	DESCRIPTION/CONTENTS
------	----------------------

FD5E	DEALLOC INTERRUPT
FD60	UNUSED
FD61	READ BLOCK
FD62	WRITE BLOCK
FD63	GET TIME
FD64	EXIT
FD65	CREATE
FD66	DESTROY
FD67	RENAME
FD68	SET FILE INFO
FD69	GET FILE INFO
FD6A	ON LINE
FD6B	SET PREFIX
FD6C	GET PREFIX
FD6D	OPEN
FD6E	NEWLINE
FD6F	READ
FD70	WRITE
FD71	CLOSE
FD72	FLUSH
FD73	SET MARK
FD74	GET MARK
FD75	UNUSED
FD76	SET EOF
FD77	GET EOF
FD78	SET BUF

FD79 ***** PARAMETER COUNT TABLE *****

FD79	GET BUF
FD7A	UNUSED
FD7B	UNUSED
FD7C	UNUSED
FD7D	ALLOC INTERRUPT
FD7E	DEALLOC INTERRUPT
FD80	UNUSED
FD81	READ BLOCK
FD82	WRITE BLOCK
FD83	GET TIME
FD84	EXIT
FD85	CREATE
FD86	DESTROY
FD87	RENAME
FD88	SET FILE INFO
FD89	GET FILE INFO
FD8A	ON LINE
FD8B	SET PREFIX
FD8C	GET PREFIX
FD8D	OPEN
FD8E	NEWLINE
FD8F	READ

ProDOS MLI -- V1.3 -- 2 DEC 86

NEXT OBJECT ADDR: FD90

ADDR DESCRIPTION/CONTENTS

FD90 WRITE
FD91 CLOSE
FD92 FLUSH
FD93 SET MARK
FD94 GET MARK
FD95 UNUSED
FD96 SET EOF
FD97 GET EOF
FD98 SET BUF

FD99 ***** MLI COMMAND ADDRESS TABLE *****

FD99 CREATE
FD9B DESTROY
FD9D RENAME
FD9F SET FILE INFO
FDA1 GET FILE INFO
FDA3 ON LINE
FDA5 SET PREFIX
FDA7 GET PREFIX
FDA9 OPEN
FDAB NEWLINE
FDAD READ
FDAF WRITE
FDB1 CLOSE
FDB3 FLUSH
FDB5 SET MARK
FDB7 GET MARK
FDB9 SET EOF
FDBB GET EOF
FDBD SET BUF
FDBF GET BUF

FDC1 ***** MLI COMMAND INFO BYTE *****

PATHNAME FLAG
| REFERENCE NUMBER FLAG
| | DATETIME STAMP FLAG
| | | COMMAND NUMBER
| | | |
FDC1 1 0 1 - 00
FDC2 1 0 1 - 01
FDC3 1 0 1 - 02
FDC4 1 0 1 - 03
FDC5 1 0 0 - 04
FDC6 0 0 0 - 05
FDC7 0 0 0 - 06
FDC8 0 0 0 - 07
FDC9 1 0 0 - 08
FDCA 0 1 0 - 09
FDCB 0 1 0 - 0A

ProDOS MLI -- V1.3 -- 2 DEC 86

NEXT OBJECT ADDR: FDCC

ADDR DESCRIPTION/CONTENTS

FDCC 0 1 0 - 0B
FDCD 0 0 1 - 0C
FDCE 0 0 1 - 0D
FDCF 0 1 0 - 0E
FDD0 0 1 0 - 0F
FDD1 0 1 0 - 10
FDD2 0 1 0 - 11
FDD3 0 1 0 - 12
FDD4 0 1 0 - 13

FDD5 ***** CONSTANTS - DATA AREA *****

FDD5 Blocks Used
FDD7 End of File
FDDA Special ID (Must be 5 bits on)
Fddb 'HUSTON!' Author's name
FDE2 Previous Block of Vol Dir Key Block

THE FOLLOWING IS COPIED TO SUBDIR HDR+\$20
FDE4 Version of ProDOS
FDE5 Minimum Version
FDE6 Access Byte (D|Rn|B|000|W|R)
FDE7 Entry Length
FDE8 Entries per Block
FDE9 File Count
FDEB Parent LSB (copied to SUBDIR HDR +\$20)

FDEC File Type (Directory)
FDED Block Number
FDEF Number of Blocks
FDF1 End of File

FDF4 ***** BITMASK TABLE *****

FDF4 10000000
FDF5 01000000
FDF6 00100000
FDF7 00010000
FDF8 00001000
FDF9 00000100
FDFA 00000010
FDFB 00000001

FDFC ***** OFFSETS INTO FILE CONTROL BLOCKS *****
FDFC *** (FCB's are at \$D800-\$D8FF) *****

FDFC Key Block

ProDOS MLI -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: FDFD

ADDR DESCRIPTION/CONTENTS

FDPE # Blocks Used

FE00 End of File

FE03 ***** SET/GET FILE_INFO OFFSETS *****

FE03 Access

FE04 File Type

FE05 Aux Type

FE07 Storage Type

FE08 Blocks Used (MSB on means GET only no SET)

FE0A Datetime (Last Mod)

FE0E Datetime (Creation)

FE12 ***** FATAL ERROR MESSAGE *****

FE12 ' INSERT SYSTEM DISK AND RESTART -ERR 0 '

FE3A ---

FE3A ***** VARIABLES - DATA AREA *****

FE3A Parent Pointer Block

FE3C Parent Entry Number

FE3D Parent Entry Length

FE3E Datetime (Creation)

FE42 Version

FE43 Min Version

FE44 Access Byte

FE45 Entry Length

FE46 Entries per Block

FE47 File Count

FE49 Bit Map Pointer

FE4B Total Blocks

THE FOLLOWING 6 BYTES UNIQUELY IDENTIFY

A FILE:

FE4D Device Number

FE4E Current Directory Block Number (HDR)

FE50 Block Number of File Entry in Directory

FE52 File Entry Number in Directory

FE53 ***** FILE ENTRY BUFFER *****

FE53 Type/Length (TTTTLLLL)

FE54 File Name (Max 15) >>000F

FE63 File Type

FE64 Key Pointer

FE66 Blocks Used

ProDOS MLI -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: FE68

ADDR DESCRIPTION/CONTENTS

FE68 End of File

FE6B Datetime (Creation)

FE6F Version

FE70 Min Version

FE71 Access Attribute

FE72 Aux Type (Load Address/Record Length)

FE74 Datetime (Last Mod)

FE78 Header Pointer

FE7A ***** Variable Work Area *****

FE7A 3 Byte Scratch

FE7D ---

FE7E End of File

FE81 Previous Mark

FE84 Compare Vol Name Scratch

FE85 Offset into VCB Table (\$D900)

FE86 Offset into FCB Table (\$D800)

FE87 Free FCB found Flag

FE88 Number of Free Blocks needed

FE8A Storage Type

Number of Entries Examined or..

FE8B FCB already open flag

FE8C File Count

FE8E Entries/Block Loop Count/Free FCB's refnum

Free Entry Found Flag (if > 0) or..

of 1st bitmap block with free bit on or..

bit for free

FE90 # Blocks in Bitmap left to search

FE91 Y Register temp

FE92 Pathname Length

FE93 Devnum for Prefix Directory Header

FE94 Block of Prefix Directory Header

FE96 Bitmap Byte Offset in Page

FE97 Bitmap Page Offset

FE98 Bitmap Buffer Page (0 or 1)

FE99 Bitmap Flag (if \$80, needs writing)

FE9A Bitmap DEVNUM

FE9B Bitmap Block Number

FE9D Bitmap Block offset for Multiblock Bitmaps

ProDOS MLI -- V1.3 -- 2 DEC 86	Next Object Addr: FE9D	ProDOS MLI -- V1.3 -- 2 DEC 86	Next Object Addr: FEEB
ADDR DESCRIPTION/CONTENTS		ADDR DESCRIPTION/CONTENTS	

FE9E New Mark to be Positioned to for Set Mark
or New EOF for SET_EOF ***** \$FEFC-\$FEFF NOT USED *****
FEFC not used

FEA1 Request Count (Read/Write etc.)
FEA3 Multi-Block I/O count
FEA4 Newline character
FEA5 Newline mask
FEA6 I/O Transfer occurred flag
FEA7 MLI Command * 2
FEA8 ORED into Access Flags (\$20 - Backup)
FEA9 Duplicate Volume Flag (if \$FF)
FEAA Duplicate Volume's VCB index
FEAB MLI function code (low 5 bits)
Characters in current Pathname indx lvl or
FEAC ONLINE: volname len - loop index
FEAD new pathname: index to last name
old pathname: index to last name or...
FEAE ONLINE: index to data buffer
FEAF Old PFXPTR value
FEB0 Pathname fully qualified flag (if \$FF)
Pathname: temp save area for index or..
FEB1 ONLINE: DEVCNT
FEB2 close-all error code
FEB3 Set EOF: new Key Block pointer
FEB5 New storage type (SET_EOF)
FEB6 Freed Blocks count
FEB8 EOF Block number (MSB then LSB)
FEBA EOF byte offset into Block
FEBC EOF - Master index counter
FEBD Save area for index into table below

FEBE ***** DEVICE TABLE BUILT BY ONLINE *****
(also used by SET_EOF to keep track of
8 blocks to be freed at a time)

FEBE device table part one
FEC6 device table part two
FECE length of path, etc.
FED1 next buffer address
FED3 16 byte stack save area
FEE3 6 byte zero page save area

FEE9 Jump Vector, used for indirect jumps
FEEB Destroy flag (1 = destroy operation)

ProDOS System Global Page -- V1.2 NEXT OBJECT ADDR: 3F00

ADDR DESCRIPTION/CONTENTS

BF00 MODULE STARTING ADDRESS

```
*****
*
* PRODOS SYSTEM GLOBAL PAGE
*
* VERSION 1.2 -- 6 SEP 86
* VERSION 1.3 -- 2 DEC 86
*
*****
```

BF00 ***** MLI AND IRQ HANDLER EQUATES *****

```
DE00 Main MLI entry point.
DEAC Address for no device connected.
DF4E IRQ handler within MLI.
DFFF System error handler.
E009 System death handler.
FFD8 Patch in ProDOS IRQ Handler.
```

BF00 ***** JUMP VECTORS *****

```
BF00 ENTRY JMP to MLI. >>BF4B
BF03 JSPARE System death address. >>BF03
BF06 DATETIME JMP To Date/Time routine (RTS if no clock).
BF07 Normal clock code address.
BF09 SYSERR JMP to system error handler. >>DFFF
BF0C SYSDEATH JMP to system death handler. >>E009
BF0F SERR System error number.
```

BF10 ***** DEVICE INFORMATION *****

```
BF10 DEVADR01 Slot 0 reserved.
BF12 DEVADR11 Slot 1, drive 1 device driver address.
BF14 DEVADR21 Slot 2, drive 1 device driver address.
BF16 DEVADR31 Slot 3, drive 1 device driver address.
BF18 DEVADR41 Slot 4, drive 1 device driver address.
BF1A DEVADR51 Slot 5, drive 1 device driver address.
BF1C DEVADR61 Slot 6, drive 1 device driver address.
BF1E DEVADR71 Slot 7, drive 1 device driver address.
BF20 DEVADR02 Slot 0 reserved.
BF22 DEVADR12 Slot 1, drive 2 device driver address.
BF24 DEVADR22 Slot 2, drive 2 device driver address.
BF26 DEVADR32 /RAM device address (128K required).
BF28 DEVADR42 Slot 4, drive 2 device driver address.
BF2A DEVADR52 Slot 5, drive 2 device driver address.
BF2C DEVADR62 Slot 6, drive 2 device driver address.
BF2E DEVADR72 Slot 7, drive 2 device driver address.
```

ProDOS System Global Page -- V1.2 NEXT OBJECT ADDR: BF2E

ADDR DESCRIPTION/CONTENTS

```
BF30 DEVNUM Slot and drive (DSSS0000) of last device.
BF31 DEVCNT Count (minus 1) of active devices
BF32 DEVLST List of active devices (slot, drive, and
identification--DSSSIIII).
```

BF40 "(C)APPLE'83" Copyright notice.

BF4B ***** PATCHES TO ORIGINAL GLOBAL PAGE *****

```
BF4B MLIENT1 Push status reg on stack.
BF4C Disable interrupts
BF4D Go to MLIENT1. >>BF67
```

```
BF50 AFTIRQ Read high RAM, BANK1 (C08B)
BF53 and continue IRQ exit. >>FFD8
```

BF58 BITMAP Bitmap of low 48K of memory.

```
BF70 BUFFER1 Open file 1 buffer address.
BF72 BUFFER2 Open file 2 buffer address.
BF74 BUFFER3 Open file 3 buffer address.
BF76 BUFFER4 Open file 4 buffer address.
BF78 BUFFER5 Open file 5 buffer address.
BF7A BUFFER6 Open file 6 buffer address.
BF7C BUFFER7 Open file 7 buffer address.
BF7E BUFFER8 Open file 8 buffer address.
```

BF80 ***** INTERRUPT INFORMATION *****

```
BF80 INTRUPT1 Interrupt handler address (highest priority).
BF82 INTRUPT2 Interrupt handler address.
BF84 INTRUPT3 Interrupt handler address.
BF86 INTRUPT4 Interrupt handler address (lowest priority).
BF88 INTAREG A-register savearea.
BF89 INTXREG X-register savearea.
BF8A INTYREG Y-register savearea.
BF8B INTSREG S-register savearea.
BF8C INTPREG P-register savearea.
BF8D INTBANKID Bank ID byte (ROM, RAM1, or RAM2).
BF8E INTADDR Interrupt return address.
```

BF90 ***** GENERAL SYSTEM INFO *****

```
BF90 DATE YYYYYYYM MMDDDDD.
BF92 TIME ...HHHHH ..MMMMM.
BF94 LEVEL Current file level.
BF95 BUBIT Backup bit.
BF96 SPARE1 Currently unused.
BF98 MACHID Machine ID byte.
00.. 0... II
```

ProDOS System Global Page -- V1.2 NEXT OBJECT ADDR: BF99

 ADDR DESCRIPTION/CONTENTS

01.. 0... II+
 10.. 0... IIE or IIGS
 11.. 0... Future expansion
 00.. 1... Future expansion
 01.. 1... Future expansion
 10.. 1... IIC
 11.. 1... Future expansion
 ..00 Unused
 ..01 48K
 ..10 64K
 ..11 128K
 X... Reserved
0. No 80-column display
1. 80-column display
00 No compatible clock
01 Compatible clock present

BF99 SLTBYT Slot ROM map (bit on indicates ROM present)
 BF9A PFIPTTR Prefix flag (0 indicates no active prefix)
 BF9B MLIACTV MLI active flag (1... .. indicates active)
 BF9C CMDADR Last MLI call return address.
 BF9E SAVEX X-register savearea for MLI calls.
 BF9F SAVEY Y-register savearea for MLI calls.

BFA0 ***** HANDLE BANK SWITCHING AFTER IRQ *****
 (Enter reading high RAM, BANK1)

BFA0 EXIT \$E000 same as save byte? (E000)
 BFA3 Yes, check for BANK1/BANK2 >>BFAA
 BFA5 No, enable ROM (C082)
 BFA8 and exit now. >>BFB5
 BFAA EXIT1 Get RAM save byte for \$D000. (BFF5)
 BFAD Is it the same as BANK1? (D000)
 BFB0 Yes, exit now. >>BFB5
 BFB2 No, switch to BANK2. (C083)
 BFB5 EXIT2 Restore A-Register and
 BFB6 return from the interrupt.

BFB7 ***** MLI ENTRY, CONTINUED *****

BFB7 MLICONT Carry set will
 BFB8 roll flag bit into MLIACTV. (BF9B)
 BFB9 Save high memory configuration (E000)
 BFBE by storing \$E000 in BNKBYT1 (BFF4)
 BFC1 and \$D000 (D000)
 BFC4 in BNKBYT2. (BFF5)
 BFC7 Then enable high RAM, BANK1 (C08B)
 BFCA for read and write. (C08B)
 BFCD Jump to actual MLI. >>DE00

ProDOS System Global Page -- V1.2 NEXT OBJECT ADDR: BFCD

 ADDR DESCRIPTION/CONTENTS

BFD0 ***** INTERRUPT ROUTINES *****

BFD0 IRQXIT Determine state of high memory. (BF8D)
 BFD3 High RAM, BANK1 enabled. >>BFE2
 BFD5 High RAM, BANK2 enabled. >>BFDE
 BFD7 System have only 48K?
 BFD8 Yes, only ROM in high memory. >>BFE7
 BFDA Enable ROM. (C081)
 BFDD Always branch. >>BFE7
 BFE2 IRQXIT1 Switch to BANK2. (C083)
 BFE2 IRQXIT2 Preset BANKID for ROM.
 BFE4 (Later reset if high RAM interrupt). (BF8D)
 BFE7 ROMXIT Restore accumulator and (BF88)
 BFEA exit.

BFE8 IRQENT Enable high RAM, BANK1 (C08B)
 BFE8 for read and write. (C08B)
 BFF1 Jump into MLI. >>DF4E

BFF4 ***** DATA *****

BFF4 BNKBYT1 Storage for byte at \$E000.
 BFF5 BNKBYT2 Storage for byte at \$D000.
 BFF6 \$BFF6-\$BFFB currently not used.

BFFC ***** VERSION INFORMATION *****

BFFC IBKVER Minimum version of Kernel needed for this interpreter.
 BFFD IVERSION Version number of this in interpreter.
 BFFE KBKVER Currently undefined. Reserved for future use.
 BFFF KVERSION MLI Version number:
 =2 in Version 1.2
 =3 in Version 1.3

ProDOS QUIT Code -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 1000

ADDR DESCRIPTION/CONTENTS

1000 MODULE STARTING ADDRESS

```
*****
*
* * QUIT Code
*   Stored in BANK2 of High RAM
*   at $D100. A move routine in
*   the MLI moves the code to
*   $1000 and JMPs to it when a
*   QUIT command is issued.
*
* * VERSION 1.2 -- 6 SEP 86
*   Move routine at $FCA9
*
* * VERSION 1.3 -- 2 DEC 86
*   Move routine at $FCD5
*
*****
```

1000 ***** ZERO PAGE EQUATES *****

0024 Cursor Horizontal
0025 Cursor Vertical

1000 ***** EXTERNAL EQUATES *****

0280 Prefix Buffer
1800 Buffer
2000 Buffer
BF00 MLI Entry
BF58 Bitmap

1000 ***** SOFT SWITCHES *****

C000 Keyboard
C000 Disable 80 column store
C00C Disable 80 column card
C00E Select standard character set
C082 ROM select

1000 ***** MONITOR EQUATES *****

FE84 Initialize 40-column display
FC58 Home
FC9C Clear to end of line
FD0C Read a key
FD8E Output a Carriage Return
FDED Output a Character
FE84 Set Normal display
FE89 Set Keyboard
FE93 Set Video

ProDOS QUIT Code -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 1000

ADDR DESCRIPTION/CONTENTS

FF3A Sound Bell

1000 ***** INITIALIZATION *****

1000 Select ROM (C082)
1003 Disable 80 column card (C00C)
1006 Select standard character set (C00E)
1009 Clear 80-column store (C000)
100C Set Normal display (white on black) <FE84>
100F Initialize 40-column display <FE84>
1012 Set Video <FE93>
1015 Set Keyboard <FE89>

1018 ***** INITIALIZE MEMORY BITMAP *****

1018 Mark pages \$0, \$1, \$4 through \$7
101A and \$BF as in use

102D ***** DISPLAY CURRENT PREFIX *****

102D Clear Screen and Home cursor <FC58>
1030 Go down 1 line <FD8E>
1033 Point to prompt number 1
1035 and print it out <11D6>
1038 Position to line 3
103F Call MLI (GET PREFIX) <BF00>
1042 Data: GET_PREFIX command number
1043 Data: Pointer to Parameter list
1045 Get length of Prefix (0280)
1048 Put a 0
104A at the end of the Prefix (0281)
104D Check prefix length... (0280)
1050 If length=0, there is no current Prefix >>105D
1052 If non-zero, display the current Prefix (0280)
1057 on the video screen (05FF)

105D ***** GET PREFIX NAME *****

105D Initialize counter
1064 Read a key <FD0C>
1067 Is it CARRIAGE RETURN?
1069 Yes, then accept Prefix >>10BD
106B No, then save character
106C Clear to end of line <FC9C>
106F Retrieve character
1070 Is it ESCAPE?
1072 Yes, start all over again >>102D
1074 Is it CANCEL?
1076 Yes, start all over again >>102D
1078 Is it TAB?
107A Yes, sound Bell, get another character >>1093

ProDOS QUIT Code -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 107C

 ADDR DESCRIPTION/CONTENTS

107C Is it DELETE?
 107E Yes. >>1084
 1080 Is it BACKSPACE?
 1082 No, keep checking >>1091
 1084 Yes, is there room to move back?
 1086 No, don't try >>108B
 1088 Decrement cursor horizontal position
 108A Decrement counter
 108B Clear to end of line <FC9C>
 108E Try again >>1064
 1091 Continue if greater or equal to BACKSPACE >>1099
 1093 Else, sound Bell <FF3A>
 1096 Try again >>1064

1099 Is it less than or equal to "Z"?
 109B Yes, keep checking >>109F
 109D Turn off lowercase
 109F Is it less than "."?
 10A1 Yes, Invalid - try again >>1093
 10A3 Is it greater than "Z"?
 10A5 Yes, Invalid - try again >>1093
 10A7 Is it less than or equal to "9"?
 10A9 Yes, keep checking >>10AF
 10AB Is it less than "A"?
 10AD Yes, Invalid - try again >>1093
 10AF Else, valid character - increment counter
 10B0 Found 39 characters?
 10B2 Yes, then start all over >>1076
 10B4 Put valid character in buffer (0280)
 10B7 And Print it <FDED>
 10BA Go back for more >>1064

10BD Check counter
 10BF If 0 then go on >>10D3
 10C1 Else, save length (0280)
 10C4 Call MLI (SET PREFIX) <BF00>
 10C7 Data: SET PREFIX command number
 10C8 Data: Pointer to Parameter list
 10CA Carry on if no error >>10D3
 10CC Sound Bell <FF3A>
 10CF Force branch to
 10D1 always be taken >>1076

10D3 ***** GET APPLICATION NAME *****

10D3 Clear Screen and Home cursor <FC58>
 10D6 Go down 1 line <FD8E>
 10D9 Point to prompt number 2
 10DB and print it out <11D6>
 10DE Position to line 3

ProDOS QUIT Code -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: 10E5

 ADDR DESCRIPTION/CONTENTS

10E5 Initialize counter
 10E7 Wait for keypress <FD0C>
 10EA Is it ESCAPE?
 10EC No, keep checking >>10F4
 10EE Yes, get Cursor horizontal position
 10F0 If not 0 try again >>10D3
 10F2 If 0 start all over again >>10D1
 10F4 Is it CANCEL?
 10F6 Yes, try again >>10D3
 10F8 Is it TAB?
 10FA Yes, sound Bell - try again >>1109
 10FC Is it DELETE?
 10FE Yes >>1104
 1100 Is it BACKSPACE?
 1102 No, keep checking >>1107
 1104 Yes, then handle it >>11C0

1107 Continue if greater than BACKSPACE >>110F
 1109 Sound Bell <FF3A>
 110C Go back and try again >>10E7

110F Is it CARRIAGE RETURN?
 1111 Yes, then go load Application >>113C
 1113 Is it less than or equal to "Z"?
 1115 Yes, keep checking >>1119
 1117 Turn off lower case
 1119 Is it less than "."?
 111B Yes, Invalid - try again >>1109
 111D Is it greater than "Z"?
 111F Yes, Invalid - try again >>1109
 1121 Is it less than or equal to "9"?
 1123 Yes, keep checking >>1129
 1125 Is it less than "A"?
 1127 Yes, Invalid - try again >>1109
 1129 Else, valid character - save it
 112A Clear to end of line <FC9C>
 112D Retrieve character
 112E and Print it <FDED>
 1131 Increment counter
 1132 Found 39 characters?
 1134 Yes, start again >>10F6
 1136 No, save character in buffer (0280)
 1139 and go get another >>10E7

113C ***** LOAD AND EXECUTE APPLICATION *****

113C Output a blank
 1141 Store length of Application name (0280)
 1144 Call MLI (GET FILE INFO) <BF00>
 1147 Data: GET FILE INFO command number
 1148 Data: Pointer to Parameter list

ProDOS QUIT Code -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: 114A	ProDOS QUIT Code -- V1.2 -- 6 SEP 86	NEXT OBJECT ADDR: 11BA
ADDR	DESCRIPTION/CONTENTS	ADDR	DESCRIPTION/CONTENTS
114A	Continue if no error >>114F	11BA	This area of the code was modified for version 1.2, and a bug was created. We are not sure it is safe to assume that the P-register is non-zero; that is, a BNE may not force the required branch. Also, there is a misplaced label here that will cause read errors to be ignored.
114C	Else, go to Error Handler >>11E2	11BB	Was READ good?
114F	Get File Type (12A5)	11BD	No, go to Error Handler >>11B7
1152	Is it ProDOS System file?	11BD	Yes, execute application >>2000
1154	Yes, continue >>115B	11C0	***** BACKSPACE ROUTINE *****
1156	No, indicate Error \$01	11C0	Get cursor position horizontal
1158	Go to Error Handler >>11E2	11C2	If 0 exit routine >>11D3
115B	Set Reference number to 0	11C4	Decrement counter
1160	Call MLI (CLOSE) <BF00>	11C5	Output a space
1163	Data: CLOSE command number	11CA	Move cursor back 2 spaces
1164	Data: Pointer to Parameter list	11CE	Output a space <FDED>
1166	Continue if no error >>116B	11D1	Move cursor back 1 space
1168	Else, go to Error Handler >>11E2	11D3	Return to get another character >>10E7
116B	Get Access Byte (12A4)	11D6	***** PRINT TEXT ROUTINE *****
1170	Yes, >>1177	11D6	Get a character (1211)
1172	No, Indicate Error \$27	11D9	If it is 0 then exit >>11E1
1174	Go to Error Handler >>11E2	11DB	Output it <FDED>
1177	Call MLI (OPEN) <BF00>	11DE	Increment offset
117A	Data: OPEN command number	11DF	Get another character >>11D6
117B	Data: Pointer to Parameter list	11E1	Return to caller
117D	Continue if no error >>1182	11E2	***** PRINT ERROR MESSAGE *****
117F	Else, go to Error Handler >>11E2	11E2	Save Accumulator (Error Number)
1182	Get Reference Number (12B8)	11E4	Position to line 12
1185	and update READ and (12BC)	11EB	Get Error number
1188	GET EOF parameter lists (12C4)	11ED	Is it 1?
118B	Call MLI (GET_EOF) <BF00>	11EF	No, keep checking >>11F5
118E	Data: GET_EOF command number	11F1	Yes, point to error message 1
118F	Data: Pointer to Parameter list	11F3	and go print it >>120B
1191	If error, handle it >>11E2	11F5	Is it \$40?
1193	Is EOF mark less than \$10000 (12C7)	11F7	Yes, print error message 3 >>1209
1196	Yes, continue on >>119C	11F9	Is it \$44?
1198	No, Indicate Error \$27	11FB	Yes, print error message 3 >>1209
119A	Go to Error Handler >>11E2	11FD	Is it \$45?
119C	Transfer EOF to Request count (12C5)	11FF	Yes, print error message 3 >>1209
119F	in READ parameter list (12BF)	1201	Is it \$46?
11A8	Call MLI (READ) <BF00>	1203	Yes, print error message 3 >>1209
11AB	Data: READ command number	1205	Point to error message 2
11AC	Data: Pointer to Parameter list	1207	and go print it >>120B
11AE	Save status of READ		
11AF	Call MLI (CLOSE) <BF00>		
11B2	Data: Get Prefix command number		
11B3	Data: Pointer to Parameter list		
11B5	Continue if no error >>11BB		
11B7	Else, retrieve status		
11B8	and go to Error Handler >>11E2		

```

ProDOS QUIT Code -- V1.2 -- 6 SEP 86          NEXT OBJECT ADDR: 1209
-----
ADDR  DESCRIPTION/CONTENTS
-----
1209 Point to error message 3
120B Print Error message <lld6>
120E Get application name again >>l0DE

1211 ***** ASCII TEXT *****
      Prompt1
1211 'ENTER PREFIX (PRESS "RETURN" TO ACCEPT)'
      Prompt2
1239 'ENTER PATHNAME OF NEXT APPLICATION'
      Error1
125C Ring Bell
125D 'NOT A TYPE "SYS" FILE'
      Error2
1273 Ring Bell
1274 'I/O ERROR'
      Error3
128A Ring Bell
128B 'FILE/PATH NOT FOUND'

12A1 ***** PARAMETER LISTS *****
      GET_FILE_INFO Parmlist
12A1 ParmCount
12A2 Pathname
12A4 Access
12A5 File Type
12A6 Aux Type
12A8 Storage Type
12A9 Blocks Used
12AB Datetime (modified)
12AF Datetime (creation)

      OPEN Parmlist
12B3 ParmCount
12B4 Pathname
12B6 I/O Buffer
12B8 Reference Number

      CLOSE Parmlist
12B9 ParmCount
12BA Reference Number

ProDOS QUIT Code -- V1.2 -- 6 SEP 86          NEXT OBJECT ADDR: 12BA
-----
ADDR  DESCRIPTION/CONTENTS
-----
      READ Parmlist
12BB ParmCount
12BC Reference Number
12BD Data Buffer
12BF Request Count
12C1 Transfer Count

      GET_EOF Parmlist
12C3 ParmCount
12C4 Reference Number
12C5 EOF Mark

      GET_SET_PREFIX Parmlist
12C8 ParmCount
12C9 Pathname

12CB ***** $12CB-$12FF UNUSED *****
12CB These unused bytes are $D3CB-$D3FF in high RAM
12FF and $5BCB-$5BFF when loaded as part of "PRODOS" file.

```


Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D000

ADDR DESCRIPTION/CONTENTS

D000 MODULE STARTING ADDRESS

```

*****
*
* 5.25" DISK DEVICE DRIVER
*
*
* RESIDES AT $D000-$D6FF
*
*
* VERSION 1.2 -- 6 SEP 86
* (SAME AS IN VERSION 1.1.1)
*
*****

```

D000 ***** ZERO PAGE EQUATES *****

```

003A Checksum
003A Workbyte
003E Slot (Temporary)
0042 Command
0043 Unit Number
0044 I/O Buffer Pointer (low)
0045 I/O Buffer Pointer (high)
0046 Block Number (low)
0047 Block Number (high)

```

D000 ***** INTERNAL EQUATES *****

```

1000 Dummy Block Buffer (1st half)
1100 Dummy Block Buffer (2nd half)

```

D000 ***** EXTERNAL EQUATES *****

```

C080 Phase Zero Off
C088 Motor Off
C089 Motor On
C08A Drive Select
C08C Read Data Register
C08D Write Data Register
C08E Set Read Mode
C08F Set Write Mode
C0EC Read Data Register (slot 6)

```

D000 ***** 5.25" DISK DRIVER ENTRY *****

```

D000 Clear decimal mode
D001 Clear phases in case IWM device in this slot <D6BE>
D004 Five NOP's so code below will
D005 fit up against Table at $D196
D009 Check validity of calling parameters <D6D0>
D00C If not valid exit with error >>D034
D00E Convert Block Number to a Track and Sector

```

Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D010

ADDR DESCRIPTION/CONTENTS

```

D010 ---
D014 00000000T TTTTABC
D015 . . >>D010
D017 . .
D018 . . >>D01C
D01A 00TTTTT 0000BC0A
D01C ---
D020 Preserve Sector Number
D021 Execute command <D038>
D024 Restore Sector Number - was prior action ok?
D025 NO, then exit >>D030
D027 Increment Buffer Pointer
D029 Increment Sector Number by 2 for rest of Block
D02B Execute command <D038>
D02E Decrement Buffer Pointer (to start of block)
D030 Get error number (if any - 0 indicates no error) (D358)
D033 Return to caller

```

D034 ***** I/O ERROR ROUTINE *****

```

D034 Indicate "I/O Error"
D036 Set Carry flag
D037 Return to caller

```

D038 ***** MAIN CODE *****

```

D038 Set recalibration count to 1
D03D Preserve sector number (D357)
D040 Get "Unitnum" DSSS0000
D042 Strip out Drive 0SSS0000
D044 Preserve slot number
D046 Check for slot change, turn off motor if so <D69B>
D049 See if motor is on <D4DA>
D04C Save test results
D04F Initialize counter for delay routine (D370)
D054 See if slot or drive has changed (D359)
D057 Update "current" unit number (D359)
D05A Save test results
D05B Put drive number in Carry flag
D05C Turn motor on (C089)
D062 Select appropriate drive (C08A)
D065 Check test results - Same slot/drive?
D066 Yes, then skip delay >>D072
D069 Wait for new Drive
D06B to speed <D385>
D072 Is command a status request?
D074 Yes, then do not move disk arm >>D07C
D076 Get track number for current request (D356)
D079 And go there <D10C>
D07C Check test results - Was motor on?
D07D Yes, then skip delay >>D08E

```

Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D07F

ADDR DESCRIPTION/CONTENTS

```

D07F Wait for Drive to
D081 come up to speed <D385>
D089 Is motor on yet? <D4DA>
D08C No, then exit with error >>D0EA
D08E Is command a "status" request?
D090 Yes, then determine status >>D0FD
D092 Is command a "read" request?
D093 Yes, then continue on >>D098
D095 Prepare data for write (preinbblize) <D5F0>
D098 ---
D09A Initialize "retry" count at 64 (D369)
D09D ---
D09F Read an address field - Good read? <D398>
D0A2 Yes, then continue on >>D0BE
D0A4 Decrement "retry" count - More to try? (D369)
D0A7 Yes, then try again >>D09D
D0A9 NO, just in case indicate "I/O Error"
D0AB Decrement "recalibration" count - More to try? (D36A)
D0AE NO, then exit with error >>D0EA
D0B0 Get "current" track (D35A)
D0B3 Preserve it
D0B4 Double it and
D0B5 add 16 to it for recalibration
D0B7 Reinitialize Retry Count
D0BC Branch always taken >>D0CC
D0C1 Was the right track found? (D35A)
D0C4 Yes, then continue on >>D0D5
D0C6 Get "current" track (D35A)
D0C9 Preserve it
D0CA Get track we found
D0CB Double it
D0CC Put new value in Device Track Table <D4D3>
D0CF Get track we want
D0D0 And go there <D10C>
D0D3 Branch always taken >>D09D
D0D8 Was the right sector found? (D357)
D0DB NO, then try again >>D0A4
D0DF Is command a "write" request?
D0E0 Yes, then go do it >>D0F4
D0E2 Read the data - Good read? <D3FD>
D0E5 NO, then try again >>D0A4
D0E7 Indicate no errors
D0E9 BNE Instruction, never taken
D0EA Indicate error
D0EB Preserve error number (D358)
D0EE Get Slot
D0F0 Turn motor off (C083)
D0F3 Return to caller

```

Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D0F3

ADDR DESCRIPTION/CONTENTS

```

D0F4 ***** HANDLE WRITE REQUEST *****
D0F4 Write data - Good write? <D500>
D0F7 Yes, then exit >>D0E7
D0F9 Indicate "Write-protect error"
D0FB Branch always taken >>D0EA
D0FD ***** GET STATUS *****
D0FD Get Slot number
D102 Check "write-protect" status (C08E)
D105 Put result in Carry flag
D106 Select read mode (C08C)
D109 Exit with appropriate status >>D0F7
D10C ***** LOCATE DESIRED TRACK *****
D10C Double the track number for proper phase
D10D Preserve destination track * 2 (D36F)
D110 Turn all phases off <D125>
D113 Get offset into Device Track Table <D4F1>
D116 Get track (D359)
D119 Update "current" track (D35A)
D11C Get destination track (D36F)
D11F Update Device Track Table (D359)
D122 Move arm to desired track <D133>
D125 Initialize phase number, starting with 3
D127 ---
D128 Clear a phase <D18A>
D12B Decrement phase number - More to do?
D12C Yes, then continue until all phases done >>D127
D12E Divide track number by 2 (D35A)
D132 Return to caller
D133 ***** ARM MOVE ROUTINE *****
D133 Preserve track to find (D372)
D136 Are we already there? (D35A)
D139 Yes, then set appropriate phase and exit >>D187
D13D Initialize phase count (halftracks) (D36B)
D143 Preserve "current" track for comparisons (D371)
D146 Subtract track to find to compute delta-tracks
D147 Are we already there? (D372)
D14A Yes, then clear prior phase and exit >>D183
D14C Positive delta-tracks - go move arm out >>D155
D14E Negative delta-tracks - Get absolute value delta-tracks less 1
D150 Increment current phase to move in (D35A)
D153 Branch always taken >>D15A
D155 Compute absolute value delta-tracks less 1
D157 Decrement current phase to move out (D35A)

```

Disk II Device Driver -- V1.2 -- 6 SEP 86			NEXT OBJECT ADDR: D15A		
ADDR	DESCRIPTION/CONTENTS		ADDR	DESCRIPTION/CONTENTS	
D15A	Compare delta-tracks with phases moved (D36B)		D1C7	Read Translate	
D15D	Use smaller value for offset to delay tables >>D162			Bit Mask 3	
D162	Are we pointing at last table value Yet?		D1E0	00000000	
D164	Yes, then continue to use current offset >>D168		D1E1	00001000	
D166	Else, use new offset		D1E2	00000100	
D167	Set Carry flag for set phase operation		D1E3	00001100	
D168	Set a phase <D187>		D1E4	Read Translate	
D16B	Get delay value from table (D373)		D200	***** TABLE 2 *****	
D16E	Delay <D385>			Write Translate Table	
D171	Get prior phase number (D371)			Every 4th byte starting at \$D203	
D174	Clear Carry flag for clear phase operation			Postnibbleize Bit mask Tables	
D175	Clear a phase <D18A>			Bit mask 1 (Every 4th byte starting at \$D200	
D178	Get delay value from table (D37C)			Bit mask 2 (Every 4th byte starting at \$D201	
D17B	Delay <D385>			Bit mask 3 (Every 4th byte starting at \$D202	
D17E	Increment phases moved (D36B)		D200	Entry for Bit Mask 1	
D183	Delay <D385>		D201	Entry for Bit Mask 2	
D187	Get "current" phase number (D35A)		D202	Entry for Bit Mask 3	
D18A	Use low two bits only, zero to three - 0000000PP		D203	Entry for Write Translate	
D18C	Multiply by two and bring in Carry - 000000PPC		D300	***** AUXILIARY BUFFER *****	
D18D	Merge in slot number - 0SSS0PPC			Auxiliary Buffer (\$56 bytes) >>0056	
D18F	Put in X-reg for following operation		D356	***** VARIABLE AREA *****	
D190	Toggle appropriate phase (C080)		D356	Track number	
D193	Restore slot number to X-reg		D357	Sector number	
D195	Return to caller		D358	Error number	
D196	***** TABLE 1 *****			Disk Device Track Table	
	Read Translate Table with Prenibbleize		D359	Table Entry	
	Bit mask Tables and Epilog Table in		D359	Current Unit	
	unused areas		D35A	Current Track	
D196	Read Translate		D35B	Slot 1, Devices 1 & 2	
	Bit Mask 1		D35D	Slot 2, Devices 1 & 2	
D1A0	00000000		D35F	Slot 3, Devices 1 & 2	
D1A1	10000000		D361	Slot 4, Devices 1 & 2	
D1A2	01000000		D363	Slot 5, Devices 1 & 2	
D1A3	11000000		D365	Slot 6, Devices 1 & 2	
D1A4	Read Translate		D367	Slot 7, Devices 1 & 2	
	Bit Mask 2			Epilog Table (\$DE,\$AA,\$EB)	
D1C0	00000000				
D1C1	00100000				
D1C2	00010000				
D1C3	00110000				

Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D367

 ADDR DESCRIPTION/CONTENTS

D369 Retry count (initially 64)
 D36A Recalibration count (initially 1)
 D36B Counter for Read Address routine
 D36B Temporary storage for Read Address routine
 D36B Track counter for Arm Move routine
 D36C Checksum computation
 D36D Volume found
 D36E Sector found
 D36F Delay counter (low byte)
 D36F Track found
 D370 Checksum found
 D370 Delay counter (high byte)
 D371 Prior Track
 D372 Track number for Arm Move routine

D373 ***** PHASEON/PHASEOFF TABLES *****

D373 Phase on table (delays for disk head acceleration)

D37C Phase off table (delays for disk head deacceleration)

D385 ***** WAIT ROUTINE *****

D385 Wait about 100 times A-register (microseconds)

D387 ---

D392 ---

D397 Return to caller

D398 ***** READ ADDRESS FIELD *****

D398 Initialize "must find" count at \$FCFC

D39D Increment count (low order byte) - Zero yet?

D39E No, skip ahead >>D3A5

D3A0 Increment count (high order byte) - Zero yet? (D36B)

D3A3 Yes, exit and indicate Read Error >>D3FB

D3A5 Read data register (C08C)

D3A8 Loop until data valid >>D3A5

D3AA Is it first address mark (\$D5)?

D3AC No, then increment "must find" count >>D39D

D3AE Delay for data latch to clear

D3AF Read data register (C08C)

D3B2 Loop until data valid >>D3AF

D3B4 Is it second address mark (\$AA)?

D3B6 No, then see if it's first address mark >>D3AA

D3B8 Initialize count for four byte read

D3BA Read data register (C08C)

D3BD Loop until data valid >>D3BA

D3BF Is it third address mark (\$96)?

D3C1 No, then see if it's first address mark >>D3AA

D3C3 Set Interrupt flag

Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D3C4

 ADDR DESCRIPTION/CONTENTS

D3C4 Initialize checksum
 D3C9 Read "odd" encoded byte 1X1X1X1X (C08C)
 D3CE Align "odd" bits 1X1X1X1X
 D3CF Save for later (D36B)
 D3D2 Read "even" encoded byte 1X1X1X1X (C08C)
 D3D7 Combine bytes XXXXXXXX (D36B)
 D3DA Preserve data (Volume,Track,Sector,Checksum) (D36D)
 D3DD Do checksum computation (D36C)
 D3E0 Decrement counter - Finished field yet?
 D3E1 No, do some more >>D3C6
 D3E3 Is checksum computation zero?
 D3E4 No, then exit with carry set >>D3FB
 D3E6 Read data register (C08C)
 D3E9 Loop until data valid >>D3E6
 D3EB Is it first trailing byte (\$DE)?
 D3ED No, then exit with carry set >>D3FB
 D3EF Delay for data latch to clear
 D3F0 Read data register (C08C)
 D3F3 Loop until data valid >>D3F0
 D3F5 Is it second trailing byte (\$AA)?
 D3F7 No, then exit with carry set >>D3FB
 D3F9 Clear the Carry flag (no error)
 D3FA Return to caller
 D3FB Set the Carry flag (error occurred)
 D3FC Return to caller

D3FD ***** READ DATA (ON THE FLY) ROUTINE *****

D3FD Convert slot number to an

D3FE absolute reference (i.e. \$60 -> \$EC)

D400 Modify code for current slot number (D45A)

D403 (i.e. \$C08C,X -> \$C0EC) (D473)

D40F Get data buffer pointers

D413 Modify code for current Buffer address (D4AF)

D416 Provides access to top 3rd of Buffer (D4B0)

D41A Subtract \$54 from current address

D41F Modify code for current address - \$54 (D497)

D422 Provides access to middle 3rd of Buffer (D498)

D426 Subtract \$57 from current address

D42B Modify code for current address - \$AB (D470)

D42E Provides access to bottom 3rd of Buffer (D471)

D431 Initialize must find count at \$20

D433 Decrement count - More to do?

D434 No, then exit >>D46D

D436 Read data register (C08C)

D439 Loop until data valid >>D436

D43B Is is 1st header mark (\$D5)?

D43D No, then try again >>D433

D43F Delay for register to clear

D440 Read data register (C08C)

Disk II Device Driver -- V1.2 -- 6 SEP 86			NEXT OBJECT ADDR: D443		
ADDR	DESCRIPTION/CONTENTS		ADDR	DESCRIPTION/CONTENTS	
D443	Loop until data valid >>D440		D443	Disk II Device Driver -- V1.2 -- 6 SEP 86	
D445	Is is 2nd header mark (\$AA)?			NEXT OBJECT ADDR: D4CA	
D447	No, then see if it is 1st header mark >>D43B			-----	
D449	Delay for register to clear			ADDR DESCRIPTION/CONTENTS	
D44A	Read data register (C08C)			-----	
D44D	Loop until data valid >>D44A			D4CA Yes, then continue with carry clear >>D4CD	
D44F	Is is 3rd header mark (\$AD)?			D4CC Set Carry flag indicating error	
D451	No, then see if it is 1st header mark >>D43B			D4CD Get byte we stored away, we have time now	
D453	Initialize offset into data buffer			D4CE Set proper offset	
D457	Initialize checksum			D4D0 Store byte in Primary buffer (offset \$55)	
D459	Read a data byte (C0EC)			D4D2 Return to caller	
D45E	Translate it (D100)			D4D3 ***** UPDATE DEVICE TRACK TABLE *****	
D461	Store it in Auxiliary buffer (D256)			D4D3 Get offset into Device Track Table <D4F1>	
D464	Compute running checksum			D4D6 Update Device Track Table (D359)	
D466	Increment offset - More to do?			D4D9 Return to caller	
D467	Yes, then continue >>D457			D4DA ***** DETERMINE IF DRIVE IS ON (DATA CHANGING)*****	
D469	Reinitialize offset into data buffer			D4DA Get slot number	
D46B	Branch always taken >>D472			D4DC Initialize counter	
D46D	Set carry flag indicating error			D4DE Read data register (C08C)	
D46E	Return to caller			D4E1 Delay 25 cycles <D4F0>	
D46F	Store byte in Primary buffer (bottom third) (1000)			D4E6 Has data register changed? (C08C)	
D472	Read a data byte (C0EC)			D4E9 Yes, then exit >>D4F0	
D477	Translate it and merge in (D100)			D4EB Just in case indicate No Device Connected Error	
D47A	bits from Auxiliary buffer (D256)			D4ED Decrement count - 256 tries yet?	
D480	Increment offset - done yet?			D4EE No, try again >>D4DE	
D481	No, then do another >>D46F			D4F0 Return to caller	
D483	Save last byte for later, no time now			D4F1 ***** CONVERT SLOT/DRIVE TO TABLE OFFSET *****	
D484	Strip off last two bits XXXXXX00			D4F1 Preserve A-register	
D486	Reinitialize offset			D4F2 Get Unit number DSSS0000	
D488	Read a byte (C0EC)			D4F4 Divide by 16 0000DSSS	
D48D	Translate it and merge in (D100)			D4F8 Put Drive into Carry 0000DSSS D	
D490	bits from Auxiliary buffer (D256)			D4FA Strip out Drive 00000SSS D	
D496	Store byte in Primary buffer (middle third) (1000)			D4FC Roll left 0000SSSD	
D499	Increment offset - done yet?			D4FD Put result in X-register	
D49A	No, then do another >>D488			D4FE Restore A-register	
D49C	Read a byte (C0EC)			D4FF Return to caller	
D4A1	Strip off last two bits XXXXXX00			D500 ***** WRITE DATA ROUTINE *****	
D4A3	Reinitialize offset			D500 Set Carry flag (anticipate error)	
D4A5	Translate byte and merge in (D100)			D504 Is diskette "write-protected"? (C08E)	
D4A8	bits from Auxiliary buffer (D254)			D507 No, then continue on >>D50C	
D4AE	Store byte in Primary buffer (top third) (1000)			D509 Go to error routine >>D5DF	
D4B1	Read a byte (C0EC)			D50C Put transition byte from secondary buffer (D300)	
D4B6	Increment offset - done yet?			D50F Put zero page for timing	
D4B7	No, then do another >>D4A5			D511 Use \$FF for "sync" byte	
D4B9	Strip off last two bits XXXXXX00			D513 Write first "sync" byte (C08F)	
D4BB	Is checksum valid? (D100)			D519 Set counter for four more	
D4BE	No, then exit with error >>D4CC			D51C Delay so that writes occur	
D4C0	Get slot number			D51D Exactly on 40 cycle loops	
D4C2	Read data register (C08C)				
D4C5	Loop until data valid >>D4C2				
D4C7	Is it 1st trailing mark (\$DE)?				

Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D51E

ADDR	DESCRIPTION/CONTENTS
D51E	---
D520	Write "sync" byte <D5E7>
D523	Decrement counter, done yet?
D524	No, then do another >>D51E
D526	Write first data mark (\$D5)
D52B	Write second data mark (\$AA)
D530	Write third data mark (\$AD)
D535	Initialize checksum
D536	Initialize index into Auxiliary buffer
D538	Branch always taken >>D53D
D53A	Get data byte (Auxiliary buffer) (D300)
D53D	Exclusive-or with previous data byte (D2FF)
D540	Put result in X-reg for table lookup
D541	Lookup "disk byte" in table (D203)
D544	Get slot
D546	Write "disk byte" (C08D)
D54C	Decrement index - Done with Auxiliary buffer?
D54D	No, then another byte >>D53A
D54F	Get last byte of Auxiliary buffer
D551	Initialize index into Primary buffer
D553	Exclusive-or with next data byte (1000)
D556	Strip out last two bits XXXXX00
D558	Put result in X-reg for table lookup
D559	Lookup "disk byte" in table (D203)
D55C	Get slot
D55E	Write "disk byte" (C08D)
D564	Get data byte (Primary buffer) (1000)
D567	Increment offset, end of this page?
D568	No, then continue on >>D553
D56A	Did buffer start on page boundary?
D56C	Yes, then go write checksum >>D5C0
D56E	Did buffer start one past page boundary?
D570	Yes, then go write last byte >>D5B3
D572	Carry indicates odd or even buffer end
D573	Get transition byte
D575	Write it (C08D)
D57B	Get second transition byte
D57D	Delay 2 cycles for correct timing
D57E	Increment offset, buffer end on odd byte?
D57F	Yes, go see if we're done then >>D599
D581	Exclusive-or with next data byte (1100)
D584	Strip out last two bits XXXXX00
D586	Put result in X-reg for table lookup
D587	Lookup "disk byte" in table (D203)
D58A	Get slot
D58C	Write "disk byte" (C08D)
D592	Get data byte (Primary buffer - page 2) (1100)
D595	Increment offset
D596	Exclusive-or with next data byte (1100)
D599	End of buffer? - Put result in carry
D59B	Strip out last two bits XXXXX00

Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D59D

ADDR	DESCRIPTION/CONTENTS
D59D	Put result in X-reg for table lookup
D59E	Lookup "disk byte" in table (D203)
D5A1	Get slot
D5A3	Write "disk byte" (C08D)
D5A9	Get data byte (Primary buffer - page 2) (1100)
D5AC	Increment offset - Done yet?
D5AD	No, then do another >>D581
D5AF	Yes, then go write checksum >>D5B1
D5B1	--- >>D5C0
D5B3	Get last byte
D5B6	Write it (C08D)
D5BC	Delay 14 cycles for correct timing
D5C0	Use last byte in Primary buffer as checksum
D5C2	Lookup "disk byte" (D203)
D5C5	Get slot
D5C7	Write "disk byte" (C08D)
D5CD	Initialize offset into "epilog" table
D5CF	Delay 11 cycles for correct timing
D5D3	Load "epilog" from table (\$DE,\$AA,\$EB,\$FF) (D1C4)
D5D6	Go write it <D5E9>
D5D9	Increment offset
D5DA	Done all four yet?
D5DC	No, then do another >>D5D3
D5DE	Clear Carry flag (no error)
D5DF	Select read mode (C08E)
D5E5	Return to caller
D5E6	***** WRITE A BYTE SUBROUTINE *****
D5E6	Wait 9 cycles before write
D5E7	Wait 7 cycles before write
D5E9	Put A-register in data register (C08D)
D5EC	And write data register (C08C)
D5EF	Return to caller
D5F0	***** PRENIBLIZE BLOCK ROUTINE *****
D5F0	Get buffer pointer
D5F5	Add \$2 to buffer address
D5F7	To access top third of buffer >>D5FA
D5FA	Store result in code below (D630)
D601	Subtract \$54 from buffer address
D603	To access middle third of buffer >>D606
D606	Store result in code below (D625)
D60D	Subtract \$AA from buffer address
D60F	To access bottom third of buffer >>D612
D612	Store result in code below (D61B)
D618	Initialize offset
D61A	Get data byte (bottom third) XXXXXXXX (1100)
D61D	Get last two bits 000000AB
D61F	Put in X-reg for table lookup

Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D620

ADDR DESCRIPTION/CONTENTS

```

D620 Use lookup to reposition bits 0000BA00 (D1E0)
D623 Save result on stack
D624 Get data byte (middle third) XXXXXXXX (1056)
D627 Get last two bits 000000CD
D629 Put in X-reg for table lookup
D62A Get current value from stack 0000BA00
D62B Merge in new bits using table 00DCBA00 (D1C0)
D62E Save result on stack XXXXXXXX (10AC)
D632 Get last two bits 000000EF
D634 Put in X-reg for table lookup
D635 Get current value from stack 00DCBA00
D636 Merge in new bits using table FEDCBA00 (D1A0)
D639 Save result on stack
D63A Get offset into primary buffer
D63B Compute offset into Auxiliary buffer
D63D Put in X-reg
D63E Get data byte just created FEDCBA00
D63F Store it in Auxiliary buffer (D300)
D642 Increment offset primary buffer, done yet?
D643 No, then do another >>D61A
D645 Get low order byte of buffer
D647 Subtract 1 (offset to last byte in buffer)
D648 Save it for later
D64A Get low order byte of buffer
D64C Modify code in Write Data Routine (offset) (D552)
D64F Buffer on page boundary? - Yes, skip ahead >>D65F
D651 Else, compute offset to last byte
D653 Before page boundary
D654 Get byte (page boundary -1)
D656 Point at next byte (page boundary)
D657 Exclusive-or them together XXXXXXXX
D659 Strip off last two bits XXXXXXX0
D65B Put in X-reg for table lookup
D65C Get "disk byte" from table (transition byte) (D203)
D65F Save result (0 indicates page boundary)
D661 Buffer on page boundary? - Yes skip ahead >>D66F
D663 Get offset to last byte in buffer
D665 Carry indicates odd or even buffer start
D666 Get byte (page boundary)
D668 Did buffer start on odd byte? - Yes skip >>D66D
D66A Point at next byte (page boundary +1)
D66B Exclusive-or them together
D66D Save result
D66F Point at last byte in buffer
D671 Get last byte in buffer XXXXXXXX
D673 Strip off last two bits XXXXXXX0
D675 Save result ("checksum byte")
D677 Get high order byte of buffer
D679 Modify code in Write Data Routine (D555)
D68C Get slot number for this operation

```

Disk II Device Driver -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D68E

ADDR DESCRIPTION/CONTENTS

```

D68E Modify code in Write Data Routine (D55D)
D69A Return to caller
D69B ***** DETERMINE IF SLOT/DRIVE HAS CHANGED *****
D69B Compare unit number with "current" unit number (D359)
D69E Put "current" drive in Carry
D69F Has slot changed? - No, then exit >>D6BD
D6A9 Get "current" slot
D6AB Put in X-register
D6AC Exit if Slot 0 >>D6BD
D6AE Is "current" motor is on? <D4DC>
D6B1 No, then exit >>D6BD
D6B8 Wait until "current" motor is off (D370)
D6BB Or else timeout >>D6A6
D6BD Return to caller
D6BE ***** CLEAR IWM PHASES *****
D6BE Get unit number
D6C0 Strip drive bit
D6C2 Put slot*16 in X-Register
D6C3 Clear phases in case there is (C080)
D6C6 one of them new-fangled storage (C082)
D6C9 devices sharing this slot (C084)
D6CC with my (t)rusty old Disk II. (C086)
D6CF Return to caller
D6D0 ***** CHECK CALLING PARAMETERS *****
Note: For 40-track drives, change byte at $D6E3
from $18 to $40
D6D0 Check command code
D6D2 Is it greater or equal to 4?
D6D4 Yes, indicate error >>D6E6
D6D6 Get Block Number
D6DA Is Block Number good? (D356)
D6DD Yes, if less than $100 >>D6E8
D6E0 No, if greater than or equal to $200 >>D6E6
D6E4 No, if greater than or equal to $118 >>D6E8
D6E6 Indicate error
D6E7 Return to caller
D6E8 All is well
D6E9 Return to caller
D6EA ***** $D6EA-$D6FF NOT USED *****
D6EA Not used

```

Disk II Device Driver -- V1.3 -- 2 DEC 86 NEXT OBJECT ADDR: D6BE

 ADDR DESCRIPTION/CONTENTS

```
*****
*
* 5.25" DISK DEVICE DRIVER
*
* RESIDES AT $D000-$D6FF
*
* VERSION 1.3 -- 2 DEC 86
*
*****
```

The Disk II Device Driver for Version 1.3 changes only in one routine--the "clear phases" subroutine. Phases are now cleared with a "LDA" instead of a "STA" to eliminate bus fights that potentially cause unwanted writing to the 5.25" disk.

D6BE ***** CLEAR IWM PHASES *****

```
D6BE    Get unit number
D6C0    Strip drive bit
D6C2    Put slot*16 in X-Register
D6C3    Turn off 8 phases
D6CF    Return to caller
```

D6D0 ***** CHECK CALLING PARAMETERS *****
 Note: For 40-track drives, change byte at \$D6E3 from \$18 to \$40.

```
D6D0    Check command code
D6D2    Is it greater or equal to 4?
D6D4    Yes, indicate error >>D6E6
D6D6    Get Block Number
D6DA    Is Block Number good? (D356)
D6DD    Yes, if less than $100 >>D6E8
D6E0    NO, if greater than or equal to $200 >>D6E6
D6E4    NO, if greater than or equal to $118 >>D6E8
D6E6    Indicate error
D6E7    Return to caller
D6E8    All is well
D6E9    Return to caller
```

D6EA ***** \$D6EA-\$D6FF NOT USED *****
 D6EA Not used

IRQ Handler -- V1.2 -- 6 SEP 86			NEXT OBJECT ADDR: FF9B		
ADDR	DESCRIPTION/CONTENTS		ADDR	DESCRIPTION/CONTENTS	
FF9B	MODULE STARTING ADDRESS	*****	FF9B	Monitor IRQ on the stack	FFC4
	* IRQ Handler	*****	FFC8	Select ROM - execution continues in ROM (C082)	
	* Resides at \$FF9B. Put	*		***** RESET CODE *****	
	* there by ProDOS Relocator.	*	FFCB	Push (\$FA61) address less 1 of (FFD7)	
	* VERSION 1.2 -- 6 SEP 86	*	FFCE	Hardware Reset routine on to stack	
	* VERSION 1.3 -- 2 DEC 86	*	FFD3	Exit via select ROM code above >>FFC8	
	* (The IRQ Handler is still the	*	FFD6	Address (-1) of Hardware Reset routine	
	* same as it was in Version 1.0.1)	*		***** IRQ CODE *****	
	* *****	*		Called via \$BF50 in System Global Page	
FF9B	***** GLOBAL PAGE EQUATES *****		FFD8	Save Accumulator in Global page (BF88)	
BF56	Temporary storage 1		FFD8	Restore \$45 with original value (BF56)	
BF57	Temporary storage 2		FFE0	Select RAM (read & write) (C08B)	
BF88	A register savearea		FFE3	use BANK1 (C08B)	
BF8D	Bank ID byte		FFE6	Get Bank ID byte (BF57)	
BFD3	IRQ exit code		FFE9	Leave via Global Page IRQ exit code >>BFD3	
FF9B	***** EXTERNAL EQUATES *****		FFEC	***** \$FFEC-\$FFF9 UNUSED *****	
D000	RAM/ROM test byte		FFEC	These unused bytes are at \$4FEC-\$4FFF9 when	
C082	ROM Select		FFF9	loaded as part of the "PRODOS" file.	
C08B	BANK1 Select		FFFA	***** VECTORS *****	
FF9B	***** IRQ CODE *****		FFFA	NMI Vector	
FF9B	Put A-Register on stack		FFFC	Reset Vector	
FF9C	Get Accumulator value from \$45		FFFE	IRQ Vector	
FF9E	and save it (BF56)				
FFA1	Replace \$45 with A-Register				
FFA2	since it may have been destroyed				
FFA4	Load Status register				
FFA5	Restore onto stack				
FFA6	Isolate B flag - Was it a BRK?				
FFA8	Yes, skip Interrupt stuff >>FFC2				
FFAA	Else, Check location \$D000 (D000)				
FFAD	Do we have RAM active				
FFAF	Yes, indicate so >>FFB3				
FFB1	Else, indicate ROM				
FFB3	Update Bank ID byte (BF8D)				
FFB6	Also save temporarily (BF57)				
FFB9	Push (\$BF50) address of				
FFBB	routine to bank in Ram and				
FFBC	call IRQ on the stack				
FFBF	Push a new P-Register on stack with				
FFC1	the Interrupt Disable flag set				
FFC2	Push (\$FA41) address less 1 of				

IRQ Handler -- V1.2 -- 6 SEP 86

NEXT OBJECT ADDR: FF9B

NEXT OBJECT ADDR: FFC4

ThunderClock Code -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D742

ADDR DESCRIPTION/CONTENTS

D742 MODULE STARTING ADDRESS

```
*****
* * * * *
* * CLOCK Code (for ThunderClock)
* * If a ThunderClock or its
* * equivalent is located, then
* * this code is loaded into the
* * ProDOS data area at $D742.
* *
* *
* * VERSION 1.2 -- 6 SEP 86, and
* * VERSION 1.3 -- 2 DEC 86
* *
*****
```

D742 ***** ZERO PAGE EQUATES *****

```
003A    Binary month (1=JAN, 2=FEB, etc.)
003B    Binary day of week (0=Sunday, 1=Monday, etc.)
003C    Binary day of the month (1-31)
003D    Binary hour of the day (0-23)
003E    Binary minute of the hour (0-59)
```

D742 ***** EXTERNAL EQUATES *****

```
0200    Input Buffer
BF90    Global page year-month-day
BF92    Global page hours-minutes
```

D742 ***** CLOCK CODE ENTRY POINT *****

```
D742    Get slot ROM high byte (D750)
D745    Get a screen hole byte for this slot (0538)
D748    and save it on the stack
      The two JSR addresses that follow will be
      modified by ProDOS Relocator so that they
      will access the correct slot ROM.
```

```
D74B    Write an $A3 to the clock (consult your Thunderclock manual) <C10B>
D74E    Read the clock. <C108>
```

```
      Reading the clock results in an ASCII string
      being placed in the input buffer. A sample
      string might be "07,06,04,22,46,57", which is
      July (month 07) Saturday (day-of-week 6)
      the 4th (day of month 4) 10 PM (hour 22)
      46 minutes and 57 seconds after the hour.
```

ThunderClock Code -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D751

ADDR DESCRIPTION/CONTENTS

D751 ***** CONVERT ASCII TO BINARY *****

```
D751    ---
D752    Five values to convert (ProDOS ignores seconds)
D754    Y-reg is index into
D756    the input buffer (0200)
D759    Strip ASCII from ten's digit
D75D    by 10
D762    Add in one's digit (0201)
D766    and subtract off ASCII,
D768    then store as binary in Z-page
D76A    Skip over comma
D76B    and two digits
D76E    More values to convert >>D756
```

D770 ***** NOW CONVERT TO PRODOS DATE, TIME *****

```
D770    Save month in Y-reg
D771    three low bits of month
D774    three high bits of accum,
D775    combine with day of month,
D777    and store in low byte of DATE (MMDDDDDD) (BF90)
D77A    Save carry (high bit of month)
D77B    Add day of the month
D77D    to table value to get Julian date (D7AB)
D780    Late September? >>D784
D782    Yes, add 3 and carry (see notes below)
D784    Compute Julian date MOD 7
```

```
D785    ---
D78B    Subtract day-of-week to get year index
D78D    Index positive? >>D791
D78F    No, make it positive
D791    Index to Y-Reg
D792    Get year from year table (D7B8)
D795    Get high bit of month in carry
D796    roll it into accumulator
D797    to get high byte of DATE (YYYYYYM) (BF91)
D79A    Put hour
D79C    in high byte of TIME (BF93)
D79F    Put minutes
D7A1    in low byte of TIME (BF92)
D7A8    Restore saved screen hole value (0538)
D7AB    RETURN
```

D7AC ***** JULIAN TABLE *****

```
D7AC    January
D7AD    February
D7AE    March
D7AF    April
D7B0    May
```

```
ThunderClock Code -- V1.2 -- 6 SEP 86      NEXT OBJECT ADDR: D7B1
-----
ADDR  DESCRIPTION/CONTENTS
-----
D7B1  June
D7B2  July
      If month>7, value in table is one
      less than Julian, because a carry
      is added along with the day of the month
D7B3  August
D7B4  September
      Note: For Julian dates>255, the table value
            is three more than the low byte should be,
            so that it will properly divide by 7.
D7B5  October
D7B6  November
D7B7  December

D7B8  ***** YEAR TABLE *****
      This table is good for the years 1986-91
      D7B8 1990
      D7B9 1989
      D7BA 1988 (March to December)
      D7BB 1988 (January and February)
      D7BC 1987
      D7BD 1986
      D7BE 1991
```

IIGS Clock Code -- V1.2 -- 6 SEP 86 NEXT OBJECT ADDR: D742 NEXT OBJECT ADDR: D788

 ADDR DESCRIPTION/CONTENTS

D742 MODULE STARTING ADDRESS

```
*****
*
* IIGS CLOCK CODE *****
*
* If ProDOS 8 is booted on
* an Apple IIGS, then this
* code is loaded into the
* ProDOS data area at $D742.
*
*
* VERSION 1.2 -- 6 SEP 86, and
* VERSION 1.3 -- 2 DEC 86
*
*****
```

D742 ***** GLOBAL PAGE VALUES *****

```
BF90    ProDOS DATE word, YYYYYYMMDDDDDD.
BF92    ProDOS TIME word, 000HHHHHH00MMMM.
```

D742 ***** IIGS SOFT SWITCH *****

```
C068    One byte sets 8 soft switches.
```

D742 ***** CLOCK CODE ENTRY POINT *****

```
D742    8-bit memory and index operations.
D744    Get IIGS STATEREG Status Byte, (C068)
D747    save it temporarily. (D790)
D74A    Make sure we're in bank 0.
D750    Get out of emulation mode.
D751    16-bit memory and index operations.
D756    Push 4 null words on the stack.
D75A    Tool = ReadTimeHex. (0D03)
D75D    Jump to the tool dispatcher. <E10000>
D761    8-bit memory operations.
D763    Get pre-call Status Byte (D790)
D766    and restore all soft switches. (C068)
D769    Throw away seconds.
D76B    Store minutes in ProDOS Global Page. (BF92)
D76F    Store hours in ProDOS Global Page. (BF93)
D772    Get year
D773    and store it temporarily. (BF91)
D776    Get day of month
D777    in range 1-31
D778    and save it temporarily. (BF90)
D77B    Get month
D77C    in range 1-12
D77D    and shift it left five bits.
D782    Combine with the date (BF90)
D785    and store in Global Page as MMMDDDDD. (BF90)
```

```
D788    Roll high bit of month into year to put (BF91)
        YYYYYYM in Global Page.
```

```
D78B    Throw away day of week
```

```
D78C    and null byte.
```

```
D78E    Back to emulation mode.
```

```
D78F    RETURN
```

```
D790    Saved STATEREG Byte.
```

```
D791    Vanity code.
```

```
D7A1    $D7A1 to $D7BE not used, set to 0.
```

HOW "BASIC.SYSTEM" IS LOADED AND RELOCATED

- ② The BI Relocator moves the Interpreter to \$9A00-\$BCFF, and the BI Global Page to \$BE00-\$BEFF.

```

I                                     I
I-----I$BF00
I  BI GLOBAL PAGE  I
I-----I$BE00
INAMES OF OPEN FILES I
I-----I$BD00
I                                     I
I          BASIC          I
I                                     I
I      INTERPRETER      I
I                                     I
I      (run location)  I
I                                     I
I-----I$9A00
I                                     I

```

- ① The "BASIC.SYSTEM" file is loaded to memory address \$2000 by the SYSTEM file loader (or a "-" command) which then jumps to \$2000 (the BI Relocator).

```

I-----I
I                                     I
I  "BASIC.SYSTEM" I
I  21 BLOCK FILE I
I                                     I
I(20 data blocks I
I plus one index I--->
I block)        I
I          L$2800 I
I                                     I
I-----I
I                                     I
I-----I$4800
I  BI GLOBAL PAGE  I
I-----I$4700
I                                     I
I          BASIC          I
I                                     I
I      INTERPRETER      I
I                                     I
I      (load location)  I
I                                     I
I-----I$2400
I  BI RELOCATOR      I
I-----I$2000
I                                     I

```

- ③ The BI Relocator searches for a "STARTUP" file in the same directory as "BASIC.SYSTEM". If found, it loads and executes the "STARTUP" program. Otherwise, it prints out a greeting and cold starts BASIC by jumping to the BASIC entry point at \$BE00.

BI Relocator -- VI.1 -- 18 JUN 84 NEXT OBJECT ADDR: 2000
 ADDR DESCRIPTION/CONTENTS

2000 MODULE STARTING ADDRESS

 *
 * PRODOS BASIC INTERPRETER RELOCATOR
 * LOADED AS THE FIRST TWO BLOCKS
 * OF BASIC.SYSTEM AT \$2000.
 * THIS ROUTINE MOVES THE BASIC
 * INTERPRETER TO \$9A00-\$BCFF.
 *
 * BASIC VERSION 1.1 -- 18 JUN 84
 *
 * DISTRIBUTED WITH PRODOS 8 VERSIONS
 * 1.1.1, 1.2, and 1.3.
 *

***** ZERO PAGE ADDRESSES *****

"FROM" POINTER FOR COPY

"TO" POINTER FOR COPY

0000
 0001
 0002
 0003
 0036
 0038
 006F
 0073
 00F2
 CSWL VECTOR
 KSWL VECTOR
 APPLESOFT START OF STRINGS
 APPLESOFT HIMEM
 APPLESOFT TRACE FLAG

***** EXTERNAL ADDRESSES *****

0200 PATHNAME BUFFER
 0280 PREFIX BUFFER
 0281 START OF PREFIX NAME

03D0 WARMSTART VECTOR
 03D3 COLDSTART VECTOR
 03F0 BRK HANDLER ADDRESS
 03F1 RESET HANDLER ADDRESS
 03F2 POWER-UP BYTE
 03F3 APPLESOFT & VECTOR
 03F4 CTL-Y VECTOR
 03F5
 03F8

***** SCREEN LINE ADDRESSES *****

BI Relocator -- VI.1 -- 18 JUN 84 NEXT OBJECT ADDR: 2000
 ADDR DESCRIPTION/CONTENTS

0400 FIRST SCREEN BUFFER LINE
 0480 SCREEN BUFFER LINE
 0628 SCREEN BUFFER LINE
 ***** BASIC GLOBAL PAGE *****

BC7A BASIC INTERPRETER VERSION NUMBER
 BE00 BASIC INTERPRETER ENTRY POINT
 BE03 BI COMMAND SCANNER (SYNTAX)
 BE10 COUT VECTORS FOR EACH SLOT
 BE20 KSWL VECTORS FOR EACH SLOT
 BE3C DEFAULT SLOT NO.
 BE3D DEFAULT DRIVE NO.
 BEFB HIMEM

***** SYSTEM GLOBAL PAGE *****

BF00 MACHINE LANGUAGE INTERFACE ENTRY
 BF30 LAST DEVICE USED
 BF58 MEMORY MAP
 BF98 MACHINE TYPE FLAGS
 BF99 SLOTS WHICH CONTAINS CARDS WITH ROM
 BF9A IF 0, NO PREFIX ACTIVE
 BFFD INTERPRETER VERSION NUMBER

***** ROM ADDRESSES *****

E000 APPLESOFT ENTRY POINT
 FA59 BRK HANDLER
 FB2F INIT SCREEN, MONITOR, ETC.
 FC58 CLEAR SCREEN, HOME CURSOR
 FDED STANDARD CHARACTER OUT
 FDF0 CHARACTER OUTPUT TO SCREEN
 FE84 SET NORMAL CHARACTER ATTRIBUTE

2000 ***** BASIC INTERP RELOCATOR ENTRY *****

2000 JUMP OVER STARTUP FILENAME >>2047
 2006 STARTUP FILENAME LENGTH (7)
 2007 'STARTUP'
 200E ALLOW FOR 64 CHAR FILENAME
 2047 \$00 --> \$2400
 204B \$02 --> \$9A00
 2055 COPY 35 PAGES
 2058 COPY INTERP TO HIGH MEMORY AT \$9A00 <20C4>
 205D PAGE FOLLOWING INTERP IMAGE IS...
 205F BASIC GLOBAL PAGE IMAGE
 2061 COPY THAT TO \$BE00 <20C4>
 2064 TO GET 40-COL DISPLAY, SEND A CTRL-U

BI Relocator -- V1.1 -- 18 JUN 84 NEXT OBJECT ADDR: 2066

ADDR DESCRIPTION/CONTENTS

```

2066 OUT THE NORMAL OUTPUT VECTOR. <FDED>
2069 SET NORMAL CHARACTER ATTRIBUTE <FE84>
206C INITIALIZE SCREEN/WINDOW <FB2F>
206F CLEAR SCREEN/HOME CURSOR <FC58>
2076 SET BITMAP TO MARK LOWER 48K FREE (BF58)
207C EXCEPT PAGES 0 AND 1 AND
207E TEXT PAGES 4 THROUGH 7 (BF58)
2086 MARK $9000-$BFFF IN USE..
2091 EXCEPT FOR $BA00-$BDEF ARE FREE
2096 LOOK AT LANGUAGE IN ROM (E000)
2099 IS IT APPLESOFT?
209B NO, THEN CAN'T RUN INTERP >>20B1
20A0 GOT AT LEAST 64K?
20A2 NO, THIS ONLY WORKS IN 64K >>20B1
20A6 SET MY CSWL/KSWL FOR INTERP INIT (221A)
20AC COPY ALL 4 BYTES >>20A6
20AE THEN GO TO BASIC COLDSTART >>E000
      (WE WILL GET CONTROL AT $20D4 AGAIN)

```

20B1 ***** ERROR EXIT *****

```

20B1 ---
20B3 PRINT "UNABLE TO EXECUTE BASIC SYSTEM" (223F)
20BC ALLOW REBOOT IF RESET PRESSED (03F4)
20C2 GO TO SLEEP FOREVER >>20C2

```

20C4 ***** COPY PAGES (\$0/1-->\$2/3) *****

```

20C4 ---
20C5 COPY FROM $0/1
20C7 TO $2/3
20CA A PAGE AT A TIME >>20C4
20D0 COUNT PAGES
20D3 RETURN

```

20D4 ***** CSWL INTERCEPT / CONTINUE *****

```

20D4 "]" APPLESOFT PROMPT?
20D6 NO...DON'T PRINT WHATEVER IT IS >>20D3
20D8 YES, APPLESOFT DONE SETTING UP (BE10)
20DB POINT CSWL TO STANDARD OUTPUT
20E2 CHECK LAST DEVICE USED (BF30)
20E5 SET ONLINE PARAMETER TO THIS (2238)
20EB DRIVE ONE OR TWO? >>20EE
20EE STORE DEFAULT DRIVE (D) (BE3D)
20F2 ISOLATE SLOT FROM DEVICE NO.
20F7 AND STORE DEFAULT SLOT (S) (BE3C)
20FE GET SLOT BYTE SHOWING CARDS PRESENT (BF99)
2102 PICK OFF ITS BITS ONE BY ONE
2108 SET OUTVECS AND INVECS TO $CS00 (BE10)
210B FOR ALL SLOTS WITH ROMS IN THEM (BE20)

```

BI Relocator -- V1.1 -- 18 JUN 84 NEXT OBJECT ADDR: 2115

ADDR DESCRIPTION/CONTENTS

```

2115 ---
211B SET HIMEM TO $9000
211D IN VARIOUS PLACES
2124 GOT A DEFAULT PREFIX? (BF9A)
2127 NO >>214E
2129 YES, MLI: GET PREFIX <BF00>
212F ERROR? >>218B
2136 BACKSCAN PREFIX FOR "/"'S (0280)
213B AND COUNT THEM IN $223E (223E)
213E ---
213F FOR A COUNT OF SUBLEVELS >>2136
2146 MORE THAN JUST VOLUME NAME? >>216F
2148 NO, MLI: SET PREFIX <BF00>
214E MLI: ONLINE <BF00>
2154 ERROR? >>218B
2156 GET VOL NAME LENGTH (0281)
215B NONE THERE? >>218B
215F ADD ONE TO NAME LENGTH (0280)
2164 AND PREFIX IT WITH A "/" (0281)
2167 MLI: SET PREFIX <BF00>
216D ERROR? >>218B

```

***** FIND STARTUP FILE *****

```

216F MLI: GET FILE INFO <BF00>
2172 FIND "STARTUP" FILE
2175 ERROR? >>218B
217A SAVE LENGTH OF STARTUP FILE NAME (2236)
217D COPY NAME TO $200 (2006)
2186 FIRST COMMAND WILL BE "-STARTUP"
218B CHECK NUMBER OF SUBLEVELS (223E)
2190 MORE THAN JUST VOL? >>2198
2192 MLI: SET PREFIX <BF00>
2198 ANY STARTUP FILE NAME? (2236)
219B YES, SKIP MESSAGE >>21C1
219D SET TRUE KSWL <2209>
21A2 PRINT '      PRODOS BASIC 1.1' (2267)
21AD PRINT '      COPYRIGHT ... (2283)
21B6 SKIP THREE LINES

```

***** FINISH UP AND GO TO B1 *****

```

21C1 ---
21C3 COPY WARMSTART JMP TO PAGE 3 (21FF)
21C9 AND COLDSTART (03D3)
21CC AND CTL-Y (03F8)
21CF POINT & VECTOR (2206)
21D2 TO $BE03 (CMD SCANNER) (03F5)
21D8 COPY BRK HANDLER JMP ALSO (2202)
21E7 AND RESET JMP (03F2)
21F2 SET POWER-UP BYTE ACCORDINGLY (03F4)

```

```

BI Relocator -- V1.1 -- 18 JUN 84          NEXT OBJECT ADDR: 21F7
-----
ADDR  DESCRIPTION/CONTENTS
-----
21F7 SET APPLESOFT IN NON-TRACE MODE
21F9 GET INTERPRETER VERSION NUMBER, (BC7A)
21FC PUT IT, IN SYSTEM GLOBAL PAGE. (3FFD)
21FF GO TO INTERPRETER >>BE00

***** VECTOR ADDRESSES *****
2202 BREAK HANDLER ADDRESS FOR PAGE 3
2204 RESET HANDLER IS BASIC INTERP
2206 APPLESOFT & GOES TO BI CMD SCANNER >>BE03

2209 ***** FIRST KSWL INTERCEPT *****
2209 SET KSWL TO CURRENT DEVICE HANDLER (BE20)
2213 RETURN LENGTH OF FIRST COMMAND (2006)
2217 FOLLOWED BY A RETURN
2219 RETURN

221A ***** DATA *****
221A CSWL (20D4) INTERCEPT ADDR
221C KSWL (2209) INTERCEPT ADDR

221E GET FILE INFO PARMLIST
221F FILE NAME IS AT $2006
2221 15 BYTES RESERVED FOR OTHER GET_FILE PARMS (NOT USED)
2230 THIS BYTE NOT USED

2231 SET PREFIX PARM LIST
2232 FOR PREFIX AT $2234

2234 NULL PREFIX
2235 "/"

2236 SAVED LENGTH OF STARTUP FILE NAME

2237 ONLINE PARM LIST
2239 PUT VOLUME NAME AT $281

223B SET PREFIX PARMLIST
223C PREFIX IS AT $280

223E NUMBER OF SUBLEVELS IN PREFIX +1

223F '*** UNABLE TO EXECUTE BASIC SYSTEM ***'
2267 '      PRODOS BASIC 1.1.'
2283 '      COPYRIGHT APPLE, 1983-84'

BI Relocator -- V1.1 -- 18 JUN 84          NEXT OBJECT ADDR: 2283
-----
ADDR  DESCRIPTION/CONTENTS
-----
22A3 ***** $22A3-$23FF NOT USED *****
22A3 NOT USED

2400 ***** START OF BI IMAGE *****
2400 BASIC INTERP IMAGE

```


BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9A00

ADDR DESCRIPTION/CONTENTS

9A00 MODULE STARTING ADDRESS

```
*****
*
* PRODOS BASIC INTERPRETER (BI)
* THIS CODE STARTS IN THE THIRD
* BLOCK OF THE FILE BASIC.SYSTEM.
* IT PERFORMS COMMAND HANDLING
* FOR ALL BUILT-IN PRODOS COM-
* MANDS AND SUPPORTS BASIC'S FILE
* HANDLING.
*
* VERSION 1.1 -- 18 JUN 84
*
* DISTRIBUTED WITH PRODOS VERSIONS
* 1.1.1, 1.2, AND 1.3.
*****
```

***** ZERO PAGE ADDRESSES *****

```
0024 CURSOR HORIZONTAL
0028 SCREEN LINE BASE ADDR
0029
0033 MONITOR PROMPT CHARACTER
0036 CRT DISPLAY VECTOR (CSWL)
0037
0038 KEYBOARD INPUT VECTOR (KSWL)
0039
003A SCRATCH POINTER AND LOOP COUNTER
003B
003C SCRATCH POINTER AND LOOP COUNTER
003D
003E POINTER TO APPLESOFT VARIABLES
003F
0050 APPLESOFT: LINE NUMBER
0051
0067 APPLESOFT: START OF PROGRAM PTR
0068
0069 APPLESOFT: LOMEM (START OF VARS)
006A
006B APPLESOFT: START OF ARRAY VARS PTR
006C
006E APPLESOFT: START OF FREEAREA PTR
006D
006F APPLESOFT: START OF STRINGS PTR
0070
0073 APPLESOFT: HIMEM (END OF STRINGS)
0074
0075 APPLESOFT: CURRENT LINE BEING EXECUTED
0076
```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9A00

ADDR DESCRIPTION/CONTENTS

```
009B APPLESOFT: ADDR OF LINE AFTER FINDLINE
009C
00AF APPLESOFT: END OF PROGRAM PTR
00B0
00B8 APPLESOFT: START OF PROGRAM PTR
00B9
00D6 APPLESOFT: PROGRAM LOCKED (PROTECTED)
00D8 APPLESOFT: ONERR ACTIVE FLAG
00DE APPLESOFT: ONERR CODE
00F2 APPLESOFT: TRACE ACTIVE FLAG
00F8 APPLESOFT: INTERNAL STACK

***** EXTERNAL ADDRESSES *****

0100 START OF 6502 STACK
0200 KEYBOARD INPUT LINE BUFFER
03F4 POWERON RESET FLAG

***** BI GLOBAL PAGE *****

BE06 EXTERNAL COMMAND ENTRY TO BI
BE0C PRINT ERROR MESSAGE ENTRY TO BI
BE0F PRODOS ERROR CODE
BE10 OUTPUT VECTORS FOR ALL SLOTS
BE30 CURRENT OUTPUT VECTOR
BE32 CURRENT INPUT VECTOR
BE34 PRODOS INTERCEPT VECTORS (INPUT/OUTPUT)
BE38 BI'S INTERNAL REDIRECTION VECTORS
BE3C DEFAULT SLOT
BE3D DEFAULT DRIVE
BE3E A REGISTER SAVE AREA
BE3F X REGISTER SAVE AREA
BE40 Y REGISTER SAVE AREA
BE41 TRACE FLAG (APPLESOFT TRACE ON/OFF)
BE42 IMMEDIATE COMMANDS=0, DEFERRED=1
BE43 EXEC FILE ACTIVE=$80
BE44 READ FILE ACTIVE=$80
BE45 WRITE FILE ACTIVE=$80
BE46 READING PREFIX ACTIVE=$80
BE47 DIRECTORY FILE BEING ACCESSED
BE49 FREE STRING SPACE DURING GARBAGE COLLECT
BE4A BUFFERED I/O BYTE COUNT
BE4B INDEX INTO INPUT COMMAND LINE
BE4C LAST OUTPUT CHAR TO PREVENT RECURSION
BE4D NUMBER OF OPEN NON-EXEC FILES
BE4E EXEC FILE BEING CLOSED FLAG
BE4F READ FILE IS TRANSLATED DIRECTORY
BE50 VECTOR TO EXTERNAL COMMAND HANDLER
BE52 LENGTH-I OF EXTERNAL COMMAND STRING
BE53 COMMAND NUMBER
BE54 PARAMETERS ALLOWED FOR THIS COMMAND
```

BASIC Interpreter (BI) -- VI.1 --I8 JUN 84 NEXT OBJECT ADDR: 9A00

ADDR	DESCRIPTION/CONTENTS
BE56	(SEE BIT DEFINITIONS IN TABLE LATER) PARAMETERS FOUND WITH THIS COMMAND (SAME BIT DEFINITIONS AS FOR PBITS)
BE58	A KEYWORD VALUE
BE5A	B KEYWORD VALUE
BE5D	E KEYWORD VALUE
BE5F	L KEYWORD VALUE
BE61	S KEYWORD VALUE
BE62	D KEYWORD VALUE
BE63	F KEYWORD VALUE
BE65	R KEYWORD VALUE
BE68	@ KEYWORD VALUE
BE6A	T KEYWORD VALUE
BE6B	SLOT NUMBER FROM IN# OR PR#
BE70	ISSUE MLI CALL AND XLATE ERROR CODES MLI PARM LIST FIELDS
BEA3	CREATE: ACCESS CODE
BEA4	CREATE: FILE ID
BEA5	CREATE: AUX ID
BEA7	CREATE: FILE KIND
BEB4	SET/GET FILE INFO: PARM COUNT
BEB7	SET/GET FILE INFO: ACCESS CODE
BEB8	SET/GET FILE INFO: FILE ID
BEB9	SET/GET FILE INFO: AUX ID
BEBB	SET/GET FILE INFO: FILE KIND
BEBC	SET/GET FILE INFO: BLOCKS USED
BEBE	SET/GET FILE INFO: MODIFY DATE/TIME
BEC7	ONLINE/GET/SET MARK/EOF/BUF: REF NUM
BEC8	ONLINE/GET/SET MARK/EOF/BUF: MARK/BUF
BEC9	OPEN: SYSTEM BUFFER
BED0	OPEN: REF NUM RETURNED
BED2	NEWLINE: REF NUM
BED3	NEWLINE: NEW LINE CHAR (ALWAYS CR)
BED6	READ/WRITE: REF NUM
BED7	READ/WRITE: DATA ADDRESS
BED9	READ/WRITE: LENGTH OF DATA
BEDB	READ/WRITE: ACTUAL LENGTH TRANSMITTED
BED9	CLOSE/FLUSH: REF NUM
BEDE	BASIC HIMEM VALUE
BEFB	
BE03	QUIT VECTOR
BF30	LAST DEVICE USED
BF58	MEMORY UTILIZATION BIT MAP
BF94	OPEN FILE LEVEL
BF9A	PREFIX ACTIVE FLAG (IF NONZERO)

***** SYSTEM GLOBAL PAGE *****

BASIC Interpreter (BI) -- VI.1 --I8 JUN 84 NEXT OBJECT ADDR: 9A00

ADDR	DESCRIPTION/CONTENTS
C000	***** INPUT/OUTPUT LOCATIONS ***** KEYBOARD STROBE
C010	KEYBOARD STROBE CLEAR
CFFF	RESET I/O ROMS
D43F	***** APPLESOFT ROM LOCATIONS ***** APPLESOFT RESTART ENTRY
D61A	FIND LINE BY NUMBER IN APPLESOFT
D665	SET POINTERS IN APPLESOFT
D7D2	EXECUTE NEW APPLESOFT STATEMENT
D820	APPLESOFT CMD EXECUTE
D865	APPLESOFT SIGNAL ERROR
ED24	APPLESOFT PRINT DECIMAL NUMBER
F273	APPLESOFT SET NORMAL CHARS
FC58	***** MONITOR ROM LOCATIONS ***** MONITOR CLEAR SCREEN/HOME CURSOR
FC9C	MONITOR CLEAR TO EOL
FD10	MONITOR READ KEY (NO CURSOR)
FDED	COUT VECTOR
9A00	***** BASIC INTERPRETER LOAD POINT ***** (ENTRY POINT IS AT \$ABF1, WARDOS)
9A00	***** REMOVE KSWL/CSWL INTERCEPTS *****
9A00	---
9A01	REPLACE CSWL/KSWL WITH CURRENT (BE30)
9A04	ACTUAL DEVICE DRIVER VECTORS
9A16	RETURN
9A17	***** RESET MODE/SET BI INTERCEPTS *****
9A17	SET IMMEDIATE COMMAND MODE
9A19	AND GO SET I/O VECTORS <9F76>
9A1C	KSWL/H ALREADY SET?
9A21	NO? THEN CHECK CSWL >>9A26
9A23	YES, CONTINUE >>9AA3
9A26	CSWL/H ALREADY SET?
9A2B	YES, CONTINUE >>9AA3
9A2D	NO, SAVE CURRENT INTERCEPTS FIRST >>9A8D

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9AA2

ADDR DESCRIPTION/CONTENTS

9AA3 ***** SET CSWL/KSWL INTERCEPTS *****

9AA3 ---

9AA4 COPY VDOSIO VECTORS (BE34)

9AA7 TO CSWL

9AB1 AND KSWL

9AB9 EXIT TO CALLER

9ABA ***** INPUT INTERCEPT: MODE = 0 *****
(IMMEDIATE MODE)

9ABA IS EXEC FILE ACTIVE? (BE43)

9ABD NO >>9AC5

9ABF YES, SAVE REGISTERS <9F62>

9AC2 AND GO READ EXEC FILE FOR INPUT COMMANDS >>9BAF

9AC5 NO EXEC FILE, RESTORE REAL CSWL/KSWL <9A00>

9AC8 NO, READ A KEY FROM KEYBOARD <9A00>

9ACB RETURN?

9ACD NO, EXIT >>9AEB

9ACF YES, SAVE REGISTERS <9F62>

9AD2 STORE IT IN LINE BUFFER (0200)

-- THIS ENTRY CALLED BY EXEC TO PROCESS

A COMMAND STRING STORED AT \$200

9AD5 GO PROCESS THE COMMAND STRING <A677>

9AD8 CHECK COMMAND NUMBER RETURNED FROM PARSE (BE53)

9ADB EXIT BI RIGHT NOW? >>9AEB

9ADD NO, COMMAND RETURNED WITH ERROR CODE? >>9AF0

9ADF NO, RESTORE Y REG (BE40)

9AE2 RETURN A BACKSPACE TO CALLER OF KEYBOARD

9AE4 AND A LINE INDEX OF ZERO

9AE6 EXIT THE BI >>9AEB

9AE8 RESTORE CALLER'S REGISTERS <9F6C>

9AEB AND EXIT BI BY INSTALLING INTERCEPTS >>9A8D

9AEE ***** ERROR HANDLER *****

9AEE ERROR=3, "NO DEVICE CONNECTED"

9AF0 MAIN ENTRY: STORE ERROR CODE (BE0F)

9AF3 AND IN APPLESOFT ONERR

9AF5 CHECK BI STATE (BE42)

9AF8 MEMORIZE WHETHER IT'S IMMEDIATE MODE

9AFD SET A HIGH FILE LEVEL FOR NON-EXEC FILES (BF94)

9B02 NO ACTIVE READ/WRITE FILES OR PREFIX READ (BE44)

9B0B CLOSE ALL OPEN FILES AT OR ABOVE (BEDE)

9B0E FILE LEVEL = \$0F

9B10 MLI: CLOSE (ALL) <BE70>

9B13 ERROR? >>9B27

9B15 WRITE ANY DATA I HAVE BUFFERED <A000>

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9A2F

ADDR DESCRIPTION/CONTENTS

9A2F ***** OUTPUT INTERCEPT: MODE = 0 *****
(IMMEDIATE MODE)

9A2F "#" CHARACTER? (9F61)

9A32 NO... >>9A54

9A34 ELSE, SAVE X REG (BE3F)

9A38 CHECK STACK FOR \$D812 AS RETURN ADDR (0103)

9A3B (APPLESOFT TRACE, PRINTING #LINE0)

9A44 NOT TRACING? >>9A6E

9A46 ELSE, SET DEFERED MODE=4

9A4B GET SET TO PRINT THE "#" (9F61)

9A4E RESTORE X REG (BE3F)

9A51 AND GO TO OTHER OUTPUT HANDLER >>B7F1

9A54 NOT A #, SAME AS LAST OUTPUT THO? (BE4C)

9A57 (SAVE FOR NEXT TIME THRU) (BE4C)

9A5A NO, ALL IS WELL >>9A74

9A5C TWO RETURNS IN A ROW?

9A5E NO, ALL IS WELL >>9A74

9A60 HAS HORIZONTAL CURSOR POSN CHANGED?

9A62 YES... >>9A69

9A64 ELSE, ANYTHING IN PATHNAME BUFFER? (BCBD)

9A67 (MUST BE ALPHA)

9A69 RESTORE A REG

9A6B PATHNAME IS THERE... >>9A74

9A6D ELSE, WE ARE RECURSING INFINITELY, EXIT!

9A6E WE WERE'NT TRACING AFTER ALL, RESTORE X (BE3F)

9A71 AND A REGS, THEN FALL THRU TO EXIT (9F61)

9A74 ***** ECHO OUTPUT CHAR AND EXIT *****

9A74 PUT BACK REAL CSWL/KSWL VECTORS <9A00>

9A77 OUTPUT THE CHARACTER <FDED>

9A7A WAS IT A RETURN?

9A7C NO, EXIT NOW >>9A8D

9A7E ELSE, WAS APPLESOFT TRACING?

9A82 YES >>9A8B

9A84 NO, CLEAR MY TRACE FLAG (PSEUDO TRACE NOW) (BE41)

9A87 FORCE APPLESOFT TO TRACE FOR MY BENEFIT ONLY

9A8B RESTORE A REG AND FALL THRU TO EXIT BI

9A8D ***** SAVE ACTUAL IN/OUT VECTORS *****

9A8D ---

9A8E COPY KSWL/H TO VECIN

9A98 AND CSWL/H TO VECOUT

9A9A IN BI GLOBAL PAGE (BE31)

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9B18
 ADDR DESCRIPTION/CONTENTS

9B18 ERROR? >>9B27
 9B1A PUT FILE LEVEL BACK TO ZERO
 9B22 NOW FLUSH ALL OPEN FILES
 9B24 MLI: FLUSH (ALL) <BE70>
 9B27 ---
 9B28 ASSUME MODE WILL BE 4 (DEFERRED)
 9B2A MEMORIZE WHETHER BASIC ONERR ACTIVE
 9B2C DEFERRED MODE CURRENTLY? >>9B30
 9B2E NO, STILL IMMEDIATE MODE (MODE=0)
 9B30 ---
 9B31 SET MODE AS DEFINED ABOVE <9F76>
 9B34 RESTORE BI'S CSWL/KSWL INTERCEPTS <9AA3>
 9B37 GET ERROR CODE (BE0F)
 9B3B BASIC ONERR ACTIVE? THEN GO HANDLE IT >>9B4D
 9B3E NO, JUST PRINT ERROR MESSAGE <BE0C>
 9B41 CLOSE EXEC FILE IF ONE IS OPEN <B2FB>
 9B45 DEFERRED MODE? >>9B53
 9B47 IMMED. MODE, PRINT RETURN AND... <9FAB>
 9B4A WARMSTART APPLESOFT >>D43F

9B4D RESTORE STACK FOR BASIC
 9B52 PASS ERROR CODE TO BASIC
 9B53 ---
 9B55 JUMP INTO APPLESOFT ERROR HANDLER >>D865

9B58 ***** RETURN TO IMMED. MODE *****

9B58 CLEAR APPLESOFT ERRNUM
 9B5C WILL LOOK FOR "#" FROM APPLESOFT
 9B61 SET NORMAL VIDEO IN APPLESOFT <F273>
 9B64 RESTORE TRUE CSWL/KSWL <9A00>
 9B67 TRY TO WRITE BUFFERED DATA <9FF4>
 9B6A RESET MODE/SET UP BI'S INTERCEPTS <9A17>
 9B6D RESTORE REGISTERS <9F6C>
 9B70 GO TO PROCESS IMMED. INPUT REQUEST >>9ABA

9B73 ***** INPUT INTERCEPT: MODE=4 OR 8 *****

9B73 SAVE REGISTERS <9F62>
 9B76 PREFIX INPUT ACTIVE? (BE46)
 9B79 NO >>9B7E
 9B7B YES, GO DO SPECIAL HANDLING >>9D67
 9B7E ELSE, IS READ FILE ACTIVE? (BE44)
 9B81 NO >>9B86
 9B83 YES, GO DO SPECIAL HANDLING FOR THAT >>9C16
 9B86 ELSE, IS EXEC FILE ACTIVE? (BE43)
 9B89 NO >>9BAF
 9B8B YES, GET PROMPT CHARACTER
 9B8D IT BETTER NOT BE A "]"
 9B8F IT IS, RETURN TO IMMEDIATE MODE >>9B58
 9B91 ELSE, SET TRUE CSWL/KSWL <9A00>

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9B94
 ADDR DESCRIPTION/CONTENTS

9B94 AND PASS CALLER'S AREG TO REMOVE CURSOR (BE3E)
 9B97 RESTORE Y-REGISTER (BD40)
 9B9A REMOVE CURSOR AND GET A KEYPRESS <FD10>
 9B9D BACKSPACE?
 9B9F NO, EXIT BI >>9BAC
 9BA1 YES, CHECK PROMPT
 9BA3 IF ITS A ">"...
 9BA5 THEN EXIT WITH THE BACKSPACE >>9BAA
 9BA8 ELSE, IF AT START OF LINE, REPROMPT >>9B94
 9BAA MIDDLE OF LINE, RETURN A BACKSPACE
 9BAC EXIT BI TO CALLER >>9A8D

9BAF ***** READ EXEC FILE *****

9BAF REMOVE CURSOR FROM SCREEN
 9BE1 CHECK PROMPT CHARACTER
 9BE3 IF ITS A ">"...
 9BE5 DO THINGS DIFFERENTLY >>9BF2
 9BE7 CHECK KEYBOARD (C000)
 9BBA NO KEY READY? >>9BCD
 9BBC GOT A KEY, IS IT CONTROL-C?
 9BBE NO, IGNORE IT >>9BCD
 9BC0 YES, CLOSE EXEC FILE <B2FB>
 9BC3 IMMEDIATE MODE? (BE42)
 9BC6 NO >>9C01
 9BC8 YES, CLEAR KEYBOARD STROBE (C010)
 9BCB AND GO START NEW LINE >>9C01
 9BCD SET UP FOR EXEC LINE READ <9D8A>
 9BD0 READ A LINE TO \$200 <9C6C>
 9BD3 ERROR? >>9BFA
 9BD5 SAVE REGISTERS <9F62>
 9BD8 HOP INTO LOOP >>9BDE
 9BDA ---
 9BDB BACKSCANNING \$200 BUFFER (0200)
 9BDE FORCING THE MSB ON
 9BE6 RESTORE TRUE CSWL/KSWL <9A00>
 9BE9 GO PROCESS COMMAND LINE <9AD5>
 9BEC CHECK COMMAND NUMBER (BE53)
 9BEF IMMEDIATE EXIT? IF NOT, GET NEXT LINE >>9BCD
 9BF1 RETURN

***** HANDLE EXEC PROMPT > *****

9BF2 GET SET TO READ EXEC LINE <9D8A>
 9BF5 READ SINGLE CHARACTER PER CALL <9C48>
 9BF8 NO ERRORS, EXIT TO CALLER NOW >>9BF1

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9BF8

ADDR DESCRIPTION/CONTENTS

***** EXEC ERROR RECOVERY *****

```

9BF8 CLOSE EXEC FILE <B245>
9BFD WAS ERROR "END OF DATA"?
9BFF NO, REAL ERROR THEN >>9C13
9C01 ELSE, OK -- JUST STOP EXECING
9C03 GET CURSOR HORIZONTAL POSITION
9C05 IF IN MID LINE, PASS SCREEN CHAR BACK >>9C0E
9C07 ELSE, CHANGE PROMPT TO "]"
9C0B AND RETURN WITH A BACKSPACE
9C0D RETURN
9C0E GET SCREEN CHARACTER UNDER CURSOR
9C10 AND EXIT THRU KSWL TO GET REAL KEYPRESS >>0038
9C13 REAL ERROR, GO TO BI'S MAIN ERROR HANDLER >>9AF0

```

9C16 ***** INPUT FILE ACTIVE *****

```

9C16 GET PROMPT
9C18 IF ITS A "]"...
9C1C THEN RESET TO IMMEDIATE MODE >>9B58
9C1F ELSE, REMOVE CURSOR FROM SCREEN (BE3E)
9C24 CHECK KEYBOARD (C000)
9C27 NO KEYPRESS? >>9C31
9C29 GOT A KEY, IS IT CONTROL-C?
9C2B NO, IGNORE IT >>9C31
9C2D CLEAR STROBE AND EXIT TO CALLER (C010)
9C30 RETURN

9C31 GET PROMPT AGAIN
9C33 IS THIS A DIRECTORY FILE? (BE47)
9C36 YES >>9C95
9C38 NO, IS PROMPT = ">"?
9C3A YES, READ A SINGLE BYTE AT A TIME >>9C42
9C3C ELSE, READ ENTIRE LINE <9C67>
9C3F ERROR? >>9C13
9C41 RETURN

9C42 READ SINGLE BYTE FROM INPUT FILE <9C48>
9C45 ERROR? >>9C13
9C47 RETURN

```

9C48 ***** READ NEXT BYTE OF FILE *****

```

9C48 SAVE CURRENT READ/WRITE COUNT (BED9)
9C4B IN L KEYWORD VALUE (BE5F)
9C50 SET UP TO READ ONE BYTE (BED9)
9C55 MLI: READ <BE70>
9C58 ERROR? >>9C66
9C5A PUT COUNT BACK TO MAXIMUM AGAIN (BE5F)
9C60 GET FIRST CHARACTER ON $200 LINE (BED7)

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9C63

ADDR DESCRIPTION/CONTENTS

```

9C63 AND RETURN THAT TO CALLER (0200)
9C66 RETURN

```

9C67 ***** READ NEXT LINE OF FILE *****

```

9C67 REMOVE CURSOR FROM SCREEN (BE3E)
9C6C ---
9C6E MLI: READ <BE70>
9C71 ERROR? >>9C66
9C73 GET LENGTH ACTUALLY TRANSMITTED (BEDB)
9C76 NOTHING? >>9C8E
9C79 GOT SOMETHING, FIND END OF DATA (BED7)
9C7D FETCH LAST BYTE OF LINE (01FF)
9C82 IS IT A RETURN CHARACTER?
9C84 NO, LEAVE LINE ALONE >>9C8E
9C86 YES, WAS L KEYWORD GIVEN? (BE57)
9C8B YES, LEAVE IT BE >>9C8E
9C8D ELSE, CHOP OFF THE RETURN ITSELF
9C8E AND EXIT WITH A RETURN
9C90 RESTORING Y REG AS YOU GO (BE40)
9C94 RETURN

```

9C95 ***** READING DIR FILE *****

```

9C95 ">" PROMPT?
9C97 YES, EXIT RIGHT NOW >>9C8E
9C99 ELSE, REMOVE CURSOR FROM SCREEN (BE3E)
9C9E SET 80 COLUMNS
9CA5 MLI: GET MARK <BE70>
9CA8 ERROR? >>9D1F
9CAA ARE WE AT BEGINNING OF THIS FILE? (BEC8)
9CB0 NO, CONTINUE >>9CDF
9CB2 YES, CAT FLAG = 2
9CB7 READ DIRECTORY HEADER <B15D>
9CBA ERROR? >>9D1F
9CBC REF NUM TIMES 32 (BED6)
9CC7 SET THE L VALUE OF THIS DIR FILE IN (BCFF)
9CCA THE OPEN FILE LIST TO THE ENTRY LENGTH (BCB8)
9CCD AND THE NUMBER OF ENTRIES PER BLOCK (BD00)

```

***** FORMAT DIRECTORY NAME *****

```

9CD0 GO FORMAT NAME OF DIRECTORY <B0B8>
9CD3 STORE THE LENGTH OF LINE AT $200
9CD8 PUT A RETURN CHAR AT END OF LINE
9CDU AND EXIT TO CALLER
9CDE RETURN

```

BASIC Interpreter (BI) -- VI.1 --18 JUN 84 NEXT OBJECT ADDR: 9CDE

 ADDR DESCRIPTION/CONTENTS

9CDF GET CAT FLAG (BE4F)
 9CE2 IF ZERO, GO PROCES'S INDIVIDUAL ENTRIES >>9D22
 9CE4 IF MINUS, GO DO SUMMARY LINE OR EXIT >>9CF9
 9CE6 POSITIVE, ASSUME NULL LINE WANTED
 9CE8 DROP CAT FLAG BY ONE (BE4F)
 9CEB IF ZERO, JUST GO PRINT A BLANK LINE >>9CD3

***** FORMAT TITLE LINE *****

9CED ELSE, BLANK OUT \$200 AND <A66C>
 9CF2 UNPACK "NAME TYPE BLOCKS ETC... <9FB0>

9CF5 LINE LENGTH IS 80
 9CF7 GO RETURN IT TO CALLER >>9CD3

***** FORMAT SUMMARY LINE *****

9CF9 DO SUMMARY LINE?
 9CFB NO, JUST EXIT (ALL DONE) >>9DIC
 9CFD YES, DROP CAT FLAG SO EXIT NEXT TIME (BE4F)
 9D02 CLEAR READ/WRITE COUNT (BED9)
 9D0A MLI: READ <BE70>
 9D0D FORMAT BLOCKS FREE AND INUSE SUMMARY LINE <B0E7>
 9D11 GET REF NUM (BED6)
 9D14 AND COPY TO GET/SET LIST (BEC7)
 9D18 NO ERRORS, EXIT >>9CF5
 9D1A ERROR, JUMP TO BI ERROR EXIT >>9D1F
 9D1C "END OF DATA" ERROR
 9D1F GO TO BI ERROR EXIT >>9AF0

***** FORMAT FILE/DIR ENTRIES *****

9D22 SET DIR ENTRY NUM COUNTER TO -1
 9D27 GET REF NUM (BED6)
 9D2A *32
 9D2F USE AS INDEX TO GET ENTRY LENGTH (BCFF)
 9D35 AND ENTRIES PER BLOCK FROM OPEN FILE LIST (BD00)
 9D3B POSITION ON EVEN BLOCK BOUNDARY (BEC9)
 9D41 AND GET SECTOR OFFSET (BEC8)
 9D45 SKIP FILE/DIR ENTRIES UNTIL POSITIONED TO (BCBB)
 9D48 CURRENT POSITION IN THIS BLOCK (BCB7)
 9D50 READ NEXT DIR ENTRY FROM FILE <BD1>
 9D53 NO ERROR? >>9D61
 9D55 ERROR, IF RANGE ERROR...
 9D57 NO, TRUE ERROR >>9D1F
 9D59 RANGE ERROR, READY FOR SUMMARY LINE NEXT (BE4F)
 9D5E RETURN A BLANK LINE THIS TIME >>9CD3

BASIC Interpreter (BI) -- VI.1 --18 JUN 84 NEXT OBJECT ADDR: 9D5E

 ADDR DESCRIPTION/CONTENTS

9D61 FORMAT FILE/DIR ENTRY INTO \$201 <A4C4>
 9D64 AND RETURN IT TO CALLER >>9CF5

9D67 ***** PREFIX INPUT ACTIVE *****

9D67 PROMPT = "]"?
 9D69 NO, ALL IS WELL >>9D6E
 9D6B YES, RETURN TO IMMEDIATE MODE NOW >>9B58
 9D6E REMOVE CURSOR FROM SCREEN (BE3E)
 9D75 PREFIX NO LONGER ACTIVE AFTER THIS (BE46)
 9D7B COPY PATHNAME BUFFER (PREFIX) (BCBC)
 9D7E TO \$200 (01FF)
 9D84 RETURN WITH IT TO BASIC (BCBC)
 9D89 RETURN

9D8A ***** SETUP TO READ LINE FROM EXEC *****

9D8A SET READ REF NUM FOR EXEC FILE (BCA3)
 9D90 READ TO \$200
 9D95 FOR \$EF BYTES OF LENGTH
 9D9A (OR UNTIL A RETURN CHAR)
 9DA2 RETURN

9DA3 ***** OUTPUT INTERCEPT: MODE = C *****
 (LOOK FOR CONTROL-D)

9DA3 SAVE REGISTERS <9F62>
 9DA6 PRINTING A CONTROL-D?
 9DA8 NO >>9DCL
 9DAA YES, WRITE OUT ANY BUFFERED DATA <9FF4>
 9DAD NOTHING IN COMMAND LINE (BE4B)
 9DB0 READ FILE INACTIVE (BE44)
 9DB3 WRITE FILE INACTIVE (BE45)
 9DB6 PREFIX READ INACTIVE (BE46)
 9DBB SET MODE = B FROM NOW ON <9F76>
 9DBE RESTORE REGS AND EXIT >>9F6C

9DCL GOT A CONTROL-D...
 9DC3 SET MODE = 4 FROM NOW ON <9F76>
 9DC6 RESTORE REGISTERS <9F6C>
 9DC9 OUTPUT CHARACTER AND EXIT >>B7F1

9DCC ***** OUTPUT INTERCEPT: MODE = 8 *****
 (ASSEMBLE COMMAND LINE)

9DCC SAVE REGISTERS <9F62>
 9DD2 SAVE CHAR IN COMMAND LINE (0200)
 9DD5 WAS IT A RETURN?
 9DD7 YES, READY TO ROLL >>9DE7
 9DD9 NO, BUMP CHARACTER COUNTER (BE4B)

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9DDC

ADDR DESCRIPTION/CONTENTS

9DDC AND EXIT TO CALLER >>9DE3
 9DDE OOPS! LINE TOO LONG
 9DE0 "SYNTAX ERROR" >>9AF0
 9DE3 ELSE, RESTORE X REG AND EXIT (BE3F)
 9DE6 RETURN

9DE7 ---
 9DE9 NULL LINE? >>9DF6
 9DEB NO, PUT BACK TRUE CSWL/KSWL <9A00>
 9DEE SYNTAX SCAN CMD LINE <A677>
 9DF1 ERROR? >>9DE0
 9DF3 NO, PUT BACK BI'S INTERCEPTS <9A8D>
 9DF6 ---
 9DF8 MODE = 4 NOW <9F76>
 9DFB RESTORE REGS AND EXIT >>9F6C

9DFE ***** WRITE BUFFERED CHARACTER *****

9DFE SAVE Y REG (BE40)
 9E01 CHECK PROMPT
 9E03 CHECK TO SEE IF WE ARE IN "IF", >>9E11
 9E06 "PRINT", "LIST", OR "CALL" STATEMENTS >>9E11
 9E09 OF AN APPLESOFT PROGRAM >>9E11
 9E0B IF NOT, EXIT TO CALLER... (BE40)
 9E0E WITH CHARACTER ECHOED TO SCREEN >>9A74

9E11 GET INDEX TO TEMPORARILY BUFFERED CHARS (BE4A)
 9E16 STORE INTO BUFFER JUST ABOVE HIMEM
 9E1B BUMP INDEX (BE4A)
 9E1E OK >>9E2B
 9E20 BUFFER FULL, SAVE REGISTERS <9F62>
 9E23 WRITE BUFFER OUT TO DISK <9FEE>
 9E26 ERROR? >>9DE0
 9E28 RESTORE REGISTERS <9F6C>
 9E2B AND EXIT ANYWAY

9E2C ***** OUTPUT INTERCEPT: MODE = 4 *****
 (INITIAL ENTRY FOR A RUNNING PROGRAM)
 (FLUSH OUT NON COMMAND LINES)

9E2C PRINTING A "#"? (9F61)
 9E2F NO >>9E49
 9E31 YES, SAVE X REGISTER (BE3F)
 9E35 RETURN ADDR IS IN APPLESOFT... (0103)
 9E38 TRACE ROUTINE...
 9E3C AT \$D812? (0104)
 9E41 YES >>9EB6
 9E43 NO, RESTORE REGISTERS (9F61)
 9E49 IS WRITE FILE ACTIVE? (BE45)
 9E4C NOPE >>9EC
 9E4E YES, PRINTING A "]"?

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9E50

ADDR DESCRIPTION/CONTENTS

9E50 NO >>9E56
 9E52 YES, SAME AS PROMPT CHARACTER?
 9E54 YES >>9E86
 9E56 NO, PRINTING A RETURN CHAR?
 9E58 NO >>9DFE
 9E5A YES, GET PROMPT
 9E60 DOES IT INDICATE RECURSION? >>9DFE
 9E62 YES, WRITE BUFFER OUT <9FF4>
 9E65 OUTPUT FILE INACTIVE NOW (BE45)
 9E6A EXIT WITH RETURN CHAR >>9E9F

 9E6C INPUT FILE ACTIVE? (BE44)
 9E6D NO >>9E7D
 9E73 YES, CHECK PROMPT
 9E75 OR IN \$04
 9E77 CONTROL-D?
 9E79 YES >>9EA2
 9E7B ---
 9E7D NO, HOW BOUT "]"?

9E7E NO, EXIT WITH ECHO THEN >>9E9F
 9E80 YES, IS THIS THE PROMPT CHAR?
 9E82 NO, EXIT WITH ECHO >>9E9F
 9E84 YES, SAVE REGISTERS <9F62>
 9E86 CHECK OPEN FILE COUNT (BE4D)
 9E89 NONE OPEN? >>9E9C
 9E8E SOME OPEN, WRITE BUFFER OUT <9FF4>
 9E91 INDICATE WRITE FILE INACTIVE NOW (BE45)
 9E94 SET TRUE CSWL/KSWL <9A00>
 9E99 PRINT "FILE(S) STILL OPEN" <BE0C>
 9E9C RESTORE REGS <9F6C>
 9E9F AND ECHO EXIT >>9A74

 9EA2 CHAR IS A RETURN?
 9EA3 NO >>9EAA
 9EA5 YES, SAME AS LAST CHAR OUTPUT? (BE4C)
 9EA7 (SAVE IT FOR THIS TEST NEXT TIME) (BE4C)
 9EAA NOT SAME, NO PROBLEM THEN >>9EB1
 9EAD SAME, MARK PROMPT FOR RECURSION
 9EAF RETURN

9EB2 ***** APPLESOFT TRACE INTERCEPT *****
 (CONTROL PASSES HERE FOR EVERY STATEMENT)
 (EXECUTED WHILE PRODOS IS ACTIVE)

9EB2 BUMP APPLESOFT LINE POINTER
 9EB6 ---
 9EBA MARK PROMPT FOR RECURSION
 9EBC JUST IN CASE WE DIED IN HERE
 9EBE RESTORE APPLESOFT'S STACK

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9EC1

ADDR DESCRIPTION/CONTENTS

```

9EC1 DOES BI KNOW WE ARE TRACING? (BE41)
9EC4 YES, REAL LIVE TRACE THEN >>9F39

9EC6 ELSE, PICK UP NEXT TOKEN ON LINE
9ECA IS IT A TOKEN? >>9EF1
9ECC OR END OF LINE? >>9EEE
9ECE NEITHER, DECREMENT STRING SPACE CTR (BE49)
9ED1 OK >>9EEC
9ED3 COMPUTE SIZE OF FREESPACE IN PAGES
9ED7 AT LEAST 3 PAGES AVAILABLE?
9ED9 YES >>9EE5
9EDB NO, WRITE BUFFERED DATA <9FF4>
9EDE AND THEN GARBAGE COLLECT <A044>
9EE3 COMPUTE FREE SPACE NOW
9EE5 AND SAVE IN STRING SPACE CTR (BE49)
9EEA GET NEXT TOKEN
9EEC ---
9EEE JUMP BACK INTO APPLESOFT TO EXECUTE IT >>D820
9EF1 STORE TOKEN IN PROMPT
9EF4 LOOK UP TOKEN IN BI'S TOKEN TABLE (B799)
9EF7 ITS NOT ONE BI IS INTERESTED IN >>9EEE
9EF9 IT IS INTERESTING, CHANGE BRANCH (9EFD)
9EFC AND JUMP TO ONE OF THE FOLLOWING: >>9EFE

9EFE IF OR PRINT: PROMPT = 0
9F00 CLEAR OUT LAST CHAR SAVEAREA (BE4C)
9F03 GO TO MODE = C NEXT TIME THRU (B803)
9F06 (BEGIN LOOKING FOR COMMANDS) (BE38)
9F0F NOW GO PROCESS THE IF OR PRINT >>9F2E

9F11 LIST: PROMPT = 1
9F13 (DON'T LOOK FOR COMMANDS NOW)
9F15 GO DO IT >>9F2E

9F17 CALL: PROMPT = 2
9F19 (DON'T LOOK FOR COMMANDS NOW)
9F1B GO DO IT >>9F2E

9F1D LET: DECREMENT STRING CTR
9F1E AND GO BACK FOR NEXT TOKEN >>9ECE

9F21 TRACE: TURN TRACE ON (BE41)
9F24 THEN CONTINUE BELOW >>9F2A

9F26 NOTRACE: DROP INTO BACKGROUND TRACE (BE41)
9F29 CHANGE TOKEN TO "TRACE"
9F2A FORCE ON APPLESOFT TRACE
9F2E ---
9F2F GO BACK TO APPLESOFT TO PERFORM IT >>D820

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9F2F

ADDR DESCRIPTION/CONTENTS

```

9F32 RESUME: CLEAR ONERR CODE
9F37 GO TO APPLESOFT TO PROCESS IT >>9EEC

***** REAL TRACE ACTIVE *****

9F39 RESTORE TRUE CSWL/KSWL <9A00>
9F3E PRINT "#" <FDED>
9F45 USE APPLESOFT TO PRINT CURRENT LINE NO. <ED24>
9F4A PRINT A BLANK SPACE <FDED>
9F4D PUT BI'S CSWL/KSWL INTERCEPTS BACK <9A8D>
9F51 THEN GO BACK AND HANDLE AS USUAL >>9EC6

9F54 LOOKING FOR A LOWER CASE "c"
9F58 LOOKING FOR A "#"
9F5A STORE CHAR TO SEARCH FOR (9FG1)
9F5E BRANCH BACK INTO APPLESOFT >>9EEC
9F60 BREAK IF Y IS ZERO!!!

9F61 "#" CHARACTER (ASOFT TRACE CHAR)

9F62 ***** SAVE CALLER'S REGISTERS *****
9F6B RETURN

9F6C ***** RESTORE CALLERS REGISTERS *****
9F6E RESTORE A,X AND Y REGS (BE3E)
9F75 RETURN

9F76 ***** SET MODE AND CSWL/KSWL *****
9F7B STORE "STATE" MODE FROM X REGISTER (BE42)
9F7C COPY PROPER CSWL/KSWL VALUES TO REDIRECT... (B7F7)
9F7E VECTOR DEPENDING ON CURRENT MODE (BE38)
9F87 RETURN

9F88 ***** PRINTER: PRINT ERROR MSG *****

9F88 ---
9F89 GET INDEX INTO PACKED MESSAGE TEXTS (BA13)
9F8C UNPACK MESSAGE INTO $201 <9FB0>
9F92 SAVE THE LENGTH (BCB6)
9F95 SKIP A LINE <9FAB>
9F9A PRINT A BELL <9FAD>
9F9D ---
9F9F PRINT CONTENTS OF $201 MSG BUFFER (0201)
9FAB PRINT A RETURN CHARACTER
9FAD AND EXIT >>FDED

```


BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9FAD

ADDR DESCRIPTION/CONTENTS

9FB0 ***** UNPACK ERROR MESSAGE *****

```

9FB0  NOTHING IN BUFFER AT FIRST
9FB6  GET A NIBBLE FROM PACKED MSG <9FD2>
9FB9  NON-ZERO, COMMON CHARACTER >>9FC0
9FBB  IF ZERO, GET NEXT NIBBLE <9FD2>
9FBE  AND CONVERT TO UNCOMMON CHAR INDEX
9FC0  ---
9FC1  GET THE LETTER THIS NIBBLE REPRESENTS (BA28)
9FC4  ZERO? THEN END OF MESSAGE >>9FD1
9FC6  GET INDEX INTO OUTPUT BUFFER (BE4B)
9FC9  AND STORE THE CHARACTER THERE (0201)
9FCC  BUMP INDEX (BE4B)
9FCF  AND CONTINUE >>9FB6
9FD1  RETURN

```

9FD2 ***** UNPACK MESSAGE BYTE *****

```

9FD2  GET NEXT MSG BYTE (BA48)
9FD5  WORKING ON SECOND NIBBLE? >>9FE9
9FD7  NO, TAB INDICATOR? >>9FDF
9FD9  NO, ISOLATE HIGH NIBBLE
9FDD  NEXT TIME GET LOW NIBBLE
9FDE  RETURN

```

```

9FDF  ---
9FE0  GET TAB POSITION (BA48)
9FE3  AND BUMP OUTPUT PTR ACCORDINGLY (BE4B)
9FE7  THEN GO BACK FOR NEXT NIBBLE >>9FD2

```

```

9FE9  BUMP BYTE PTR FOR NEXT TIME
9FEA  ISOLATE LOW NIBBLE
9FEC  NEXT TIME GET HIGH NIBBLE
9FED  RETURN

```

9FEE ***** WRITE ONE BUFFERED BYTE *****

```

9FEE  SET UP COUNT OF 0001
9FF2  AND JUMP INTO ROUTINE BELOW >>A007

```

9FF4 ***** WRITE BUFFERED DATA/TEST ERROR *****

```

9FF4  WRITE BUFFERED DATA <A000>
9FF7  OK? THEN EXIT >>A01C
9FFA  ERROR, POP OUT OF THIS SUBROUTINE
9FFD  AND GO TO ERROR HANDLER >>9AF0

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 9FFD

ADDR DESCRIPTION/CONTENTS

A000 ***** WRITE ALL BUFFERED DATA *****

```

A000  ---
A002  GET BUFFERED DATA COUNT (BE4A)
A005  NONE BUFFERED? >>A01B
A007  STORE BUFFERED DATA COUNT IN RW PARMS (BED9)
A00F  MLI: WRITE <BE70>
A015  NOTHING BUFFERED NOW, COUNT=0 (BE4A)
A019  ERROR? >>A01C
A01B  NO, EXIT
A01C  RETURN

```

A01D ***** SPECIAL GARBAGE COLLECT *****
(PULL OUT STRING CONSTANTS ALSO)

```

A01D  DO GARBAGE COLLECTION NORMALLY FIRST <A044>
A020  ERROR? >>A043
A024  START OF STRING AREA = PROGRAM START PTR (BC84)
A02C  USE GENERAL PURPOSE BUFFER (ABOVE HIMEM)
A02E  FOR A GARBAGE COLLECT WORKAREA (BC7D)
A033  IT IS 3+1 PAGES IN LENGTH (BC7E)
A038  END OF STRING AREA IS AT END OF FREEAREA (BC86)
A040  GO COLLECT CONSTANT STRINGS NOW <A085>
A043  THEN EXIT

```

A044 ***** "FRE" COMMAND *****
(FAST APPLESOFT STRING GARBAGE COLLECTION)

```

HIMEM ---
|-----|
| GENERAL PURPOSE BUFFER |
| (TOP OF OLD STRINGS)  |
|-----|
| NEW STRINGS BUILDING  |
| DOWN                  |
|-----|
| V                      |
| / / / / / / / / / / / |
| / / / / / / / / / / / |
|-----|
| OLD STRINGS           |
|-----|
|-----|
| FREE AREA             |
|-----|

```

TOP PART OF OLD STRINGS IS SAVED IN THE
GENERAL PURPOSE BUFFER OR IN THE FREE
AREA (WHICHEVER IS LARGER) AND A NEW
COPY OF THE STRINGS IS BUILT JUST BELOW
HIMEM.

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A044

ADDR	DESCRIPTION/CONTENTS
------	----------------------

```

A044 STRING AREA START IS ON PAGE BOUNDARY
A04B ASSUME 4 PAGE WORKAREA (BC7E)
A050 IN GENERAL PURPOSE BUFFER ABOVE HIMEM (BC7D)
A055 STRING START PTR IS START OF STRING AREA (BC84)
A059 COMPUTE NUMBER OF FREE PAGES
A05B AT LEAST 7?
A05D IF NOT, USE G.P. WORKAREA INSTEAD >>A079
A05F DON'T USE ALL OF FREE AREA (LEAVE $300)
A061 NEW WORKAREA SIZE IS FREE AREA SIZE-$300 (BC7E)
A066 SET PTR TO WORKAREA AT FIRST FREE PAGE
A06D COMPUTE NUMBER OF STRING PAGES
A071 USE SMALLER OF STRING PAGES OR WORKAREA SIZE (BC7E)
A076 AS NEW WORKAREA SIZE (BC7E)
A079 END OF STRING AREA IS HIMEM
A085 RECORD WHETHER LAST PAGE IS PARTIAL
A089 STRING START MSB IS HIMEM INITIALLY (BC86)
A08E ADJUST LORANGE AND HIRANGE MSB'S
A090 FOR PARTIAL PAGES AT EITHER END, (BC7F)
A093 SETTING THEM AT HIMEM FOR NOW.
A09C SET UP ARRAY END MSB +1 FOR COMPARES (BC82)
A09F $3E/$3F --> FIRST VARIABLE (LESS 7 BYTES)
A0A1 (EACH VARIABLE IS 7 BYTES)
A0AB SET UP ARRAY START LSB FOR COMPARES
A0B0 GET LORANGE VALUE (BC7F)
A0B3 PRIOR TO STRING AREA? (BC84)
A0B6 YES, THEN DONE! >>A0F6
A0B8 ELSE, DROP LORANGE BY WORKAREA SIZE (BC7E)
A0BB AND SAVE THIS VALUE (BC7C)
A0BE NOW DROP IT ALSO BY THE DISTANCE BETWEEN
A0C0 ..THE OLD LORANGE AND THE STRING START PTR (BC7F)
A0CA USE THE LOWER OF THE TWO VALUES (BC7C)
A0CF TO PRODUCE THE MAXIMUM SIZED RANGE (BC7C)
A0D2 IS THIS BELOW THE BOTTOM OF THE STRINGS? (BC84)
A0D5 NO >>A0DC
A0D7 YES, USE THE BOTTOM POINTER INSTEAD (BC84)
A0DA (ADJUSTING FOR PARTIAL PAGE)
A0DC STORE FINAL LORANGE VALUE (BC7F)
A0DF COPY SOME PAGES BELOW HIRANGE TO WORKAREA <A195>
A0E2 (TO MAKE ROOM FOR NEW STRINGS)
A0E4 COLLECT SIMPLE STRING VARS FOR THIS RANGE <A0F7>
A0E7 ERROR? >>A0F4
A0E9 THEN COLLECT STRING ARRAYS <A12D>
A0EC NEW HIRANGE = OLD LORANGE (BC7F)
A0F2 CONTINUE LOOPING >>A09F

A0F4 IF ERROR, "RAM TOO LARGE"
A0F6 EXIT TO CALLER

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A0F6

ADDR	DESCRIPTION/CONTENTS
------	----------------------

```

A0F7 ***** COLLECT SIMPLE STRINGS *****
A0F7 ---
A0F8 ADD 7 BYTES TO $3E/$3F PTR FOR NEXT VAR
A102 PTR AT ARRAYS NOW?
A108 IF SO, WE ARE DONE >>A12B
A10A IS THIS A STRING VARIABLE?
A111 NO >>A0F7
A113 MAKE ABSOLUTELY SURE
A117 GET MSB OF STRING POINTER
A11B IS IT WITHIN MY RANGE? (BC7F)
A11E NO >>A0F8
A123 NO >>A0F7
A125 YES, PULL IT OUT AND TACK IT TO HIMEM <A1B8>
A128 ALL WENT WELL, GET NEXT VARIABLE >>A0F8
A12A IF ERROR, EXIT NOW

A12B NORMAL EXIT TO CALLER
A12C RETURN

A12D ***** COLLECT STRING ARRAYS *****
A12D FIND THE NEXT ARRAY <A15C>
A130 NO MORE? >>A12B
A132 GOT ONE, GET MSB OF ITS STRING PTR
A136 WITHIN MY RANGE? (BC7F)
A139 NO >>A146
A13E NO >>A146
A140 YES, PULL IT OUT AND TACK IT TO HIMEM <A1B8>
A143 AND CONTINUE WITH NEXT ARRAY ELEMENT >>A147
A145 ERROR EXIT

A146 ---
A147 BUMP POINTER TO NEXT ARRAY MEMBER
A151 POINTER NOW AT NEXT ARRAY? (BC81)
A154 NO, DO THIS ELEMENT >>A132
A158 NO >>A132
A15A YES, SET UP TO PROCESS THAT ONE THEN >>A12D

A15C ***** FIND NEXT STRING ARRAY *****
A15C ---
A15D $3E --> ARRAY VARIABLES (BC81)
A164 AT END OF ARRAY VARS
A166 NO, CONTINUE >>A16C
A16A YES, OUT (CARRY SET, NO MORE ARRAYS) >>A194

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A16A

ADDR DESCRIPTION/CONTENTS

A16C POINT TO ARRAY FOLLOWING THIS (LSB AND...)
 A176 MSB TO X REGISTER
 A17D CHECK TYPE OF VARIABLE
 A182 SKIP INTEGER AND REAL ARRAYS >>A15C
 A186 GET NUMBER OF DIMENSIONS
 A188 *2 TO SKIP SIZES
 A189 +5 TO SKIP FIXED STUFF AT BEGINNING
 A18D POINT TO FIRST ARRAY MEMBER
 A191 READY TO ROLL, \$3E POINTS TO IT
 A194 RETURN

A195 ***** COPY PAGES TO WORKAREA *****
 TO MAKE ROOM FOR NEW STRINGS BEING MOVED
 TO HIMEM, COPY SOME STRING PAGES FROM OLD
 STRING AREA TO THE WORKAREA TO PROTECT THEM.

A195 \$3A/\$3B --> FIRST PAGE TO SAVE (BC7C)
 A19A \$3C/\$3D --> WORKAREA (BC7D)
 A1A5 COPY N+1 PAGES (SIZE OF WORKAREA) (BC7E)
 A1A9 ---
 A1B7 EXIT WHEN FINISHED

A1B8 ***** PULL STRING OUT *****
 TACK STRING JUST UNDER HIMEM AT CURRENT
 STRING START POINTER.

A1B8 IS STRING BELOW SAVED AREA? (BC7C)
 A1BB YES, ITS STILL THERE THEN >>A1C4
 A1BD ELSE, POINT TO SAVED STRING IN WORKAREA (BC7C)
 A1C4 \$3A/\$3B --> STRING
 A1CF DROP STRING START PTR BY LEN OF THIS STRING
 A1D4 UPDATE STRING'S LSB IN VARIABLE PTR
 A1D8 FIX UP MSB OF STRING START PTR ALSO
 A1DD AND OF VARIABLE PTR
 A1E1 IS THIS A NULL LENGTH STRING?
 A1E3 YES, NO MOVE TO DO >>A1EE
 A1E6 ---
 A1E7 ELSE, COPY STRING OUT
 A1EE ---
 A1EF OUT OF FREESPACE? (BC82)
 A1F4 RETURN TO CALLER WITH INDICATION

A1F5 ***** ALLOCATE BUFFER *****

A1F5 NEED 4 PAGES

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A1F5

ADDR DESCRIPTION/CONTENTS

***** GENERAL PURPOSE ALLOCATE *****

A1F7 STORE THAT (BB47)
 A1FA GO GARBAGE COLLECT TO GET SPACE <A044>
 A1FD ERROR? >>A24A
 A201 HOW MANY FREE PAGES ARE THERE?
 A203 ARE THERE ENOUGH? (BB47)
 A206 IF NOT, "RAM TOO LARGE" MSG
 A208 TOO FEW... >>A24A
 A20A GOT ENOUGH, \$3A-->TOP OF FREESPACE
 A211 AND \$3C-->NEW TOP AFTER ALLOCATION
 A21B COMPUTE LENGTH OF STRINGS FOR COPY
 A229 COPY STRINGS DOWN "N" PAGES IN MEMORY <A35B>
 A22F SUBTRACT "N" FROM STRING ADDRESS MSB'S (BB47)
 A235 ADJUST ALL POINTERS IN SIMPLE & ARRAY VARS <A39F>
 A23A OLD HIMEM BECOMES BUFF ADDR HIGH WATER MARK (BB49)
 A241 NEW HIMEM IS "N" PAGES LOWER
 A246 FIND PAGE JUST BEYOND A FILE BUFFER (BC88)
 A249 RETURN
 A24A ---
 A24B RETURN

A24C ***** FREE BUFFER *****

A24C GARBAGE COLLECT STRINGS <A044>
 A24F ERROR? >>A299
 A255 PUT HIMEM-\$100 INTO \$3A/3B
 A259 AND HIMEM+\$400 INTO \$3C/3D
 A25F (COPY LSB'S)
 A266 BC92 = LENGTH OF STRINGS (BC92)
 A270 COPY STRINGS UP 4 PAGES <A37F>
 A275 PREPARE TO ADJUST THEM BY \$400 (BC87)
 A27B NEW HIMEM+\$400
 A27D ADJUST ALL STRING ADDRS UP BY \$400 <A39F>
 A283 ARE WE FREEING BOTTOM-MOST BUFFER?
 A285 YES, DONE! >>A2B3
 A288 CHECK OPEN FILE COUNT (BE4D)
 A28B NONE OPEN? (HOW CAN THAT BE?) >>A297
 A28D WHICH FILE'S BUFFER IS NEXT TO HIMEM?
 A292 SEARCH UNTIL IT IS FOUND... >>A29A
 A297 ---
 A299 RETURN IF NO FILE IS USING THIS BUFFER
 A29A ---
 A29B GIVE THAT FILE THE BUFFER PASSED TO US (BEC9)
 A29E (SURE HOPE THAT FILE WAS FLUSHED!) (BC93)
 A2A9 PASS FILE REF NUM TO MLI (BEC7)
 A2AE MLI: SET NEW BUFFER <BE70>
 A2B1 ERROR? >>A299
 A2B3 ---
 A2B4 RETURN

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A2B4
 ADDR DESCRIPTION/CONTENTS

```

A2B5 ***** GETBUFR: GET A BUFFER *****
THIS ROUTINE IS CALLED THROUGH AN EXTERNAL
ENTRY POINT IN THE GLOBAL PAGE. IT ALLO-
CATES A FIXED LOCATION BUFFER BETWEEN THE
BI AND ITS BUFFERS.

A2B5 ALLOCATE A BUFFER OF ANY SIZE (A=PAGES) <A1F7>
A2B8 ERROR? >>A300
A2BD FIND FIRST PAGE OF BUFFER (BB4A)
A2C4 GET FIRST OPEN COUNT (BE4D)
A2C7 NONE OPEN? >>A2EA
A2C9 BUMP BUFFER PAGE PTR BY $400 (BB49)
A2CD TO POINT TO PREVIOUSLY ALLOCATED
A2CF BUFFER. (BB49)
A2D2 FIND OPEN FILE WITH THIS BUFFER (BC93)
A2D7 GOT IT. (BEC9)
A2DA SET FILE BUFFER REAL LOW IN MEMORY <A352>
A2DD THEN SET IT TO NEW BUFFER LOCATION <A29B>
A2E0 BELOW ALL OTHERS (BEC9)
A2E7 DO THIS FOR EACH OPEN FILE...
A2E8 THEREBY INSERTING A BLANK BUFFER >>A2D2
A2ED IS EXEC FILE ACTIVE? (BE43)
A2F0 NO, DONE >>A2FF
A2F2 YES,
A2F4 MOVE EXEC BUFFER DOWN ALSO <A352>
A2FD AND BUMP UP ABOVE IT
A2FF EXIT TO CALLER
A300 RETURN

A301 ***** FREEBUFR: FREE BUFFER *****
THIS ROUTINE IS CALLED THROUGH AN EXTERNAL
ENTRY POINT IN THE GLOBAL PAGE. IT FREES
A FIXED LOCATION BUFFER PREVIOUSLY ALLO-
CATED BY GETBUFR.

A301 GET COUNT OF OPEN FILES (BE4D)
A305 INDEX THIS BY 4 PAGES PER FILE
A306 ADD TO HIMEM MSB
A30B SAVE THIS AS TOP OF BUFFERS (BB49)
A30D THEN SET UP BOTTOM AS HIMEM MSB (BB4A)
A310 GET OLD ORIGINAL HIMEM (BEFORE ANY BUFFERS) (BEFB)
A313 SAME AS THIS ONE?
A315 THEN NOTHING ELSE TO DO >>A350
A317 ASSUME NO BUFFERS BY REPLACING OLD HIMEM
A319 ANY EXEC FILE OPEN? (BE43)
A31C NO, CONTINUE >>A323
A31E YES, MOVE EXEC BUFFER TO OLD HIMEM <A2F2>
A321 AND GO MOVE HIMEM DOWN BY $400 >>A341
A323 ELSE, START WITH TOP BUFFER (BB49)
A326 ANY OPEN FILES? (BE4D)

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A329
 ADDR DESCRIPTION/CONTENTS

```

A329 IF NOT, WE ARE DONE >>A34D
A32B SEARCH FOR OPEN FILE WITH THIS BUFFER (BC93)
A32E NOT IT? >>A34A
A330 GOT IT, GIVE IT NEW HOME AT HIMEM
A332 AND SET BUFFER LOW <A352>
A335 THEN TO NEW LOC <A29B>
A339 DROP TOP BUFFER PTR BY $400 (BB49)
A341 AND DROP HIMEM BY $400
A348 AND GO DO NEXT BUFFER >>A323
A34A ---
A34B (LOOP TO SEARCH FOR OPEN FILES) >>A32B
A34D WHEN FINISHED, GARBAGE COLLECT <A044>
A350 ---
A351 THEN EXIT NORMALLY TO CALLER

***** SET BUFFER BELOW ALL OTHERS ***

A352 ---
A353 USE BOTTOM BUFFER PTR (BB4A)
A356 SET FILE BUFFER <A29B>
A35A AND EXIT

A35B ***** COPY BLOCK DOWN IN MEMORY *****
A35B COPY ALL FULL PAGES DOWN TO THEIR NEW HOME
A362 COPYING $3A-->$3C
A369 BUMP BOTH MSB'S
A36D DROP PAGE COUNTER (BC93)
A370 AND CONTINUE >>A362
A372 NO SHORT LAST PAGE? (BC92)
A375 THEN EXIT NOW >>A37E
A377 ELSE, COPY PARTIAL PAGE
A37E THEN EXIT

A37F ***** COPY BLOCK UP IN MEMORY *****
A37F PARTIAL PAGE? (BC92)
A382 NO, JUST COPY FULL PAGES NOW >>A38B
A384 YES, COPY SHORT PAGE FIRST <A396>
A387 DROP BOTH MSB'S
A38B PAGE COUNT GONE TO ZERO? (BC93)
A38E YES, DONE >>A39E
A390 ELSE, DROP PAGE COUNT (BC93)
A393 AND GO COPY A FULL PAGE UP >>A384

A396 ---
A397 COPY REMAINDER OF PAGE UP (BACKWARDS)
A39E RETURN

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A39E

ADDR DESCRIPTION/CONTENTS

A39F ***** ADJUST ALL STRING ADDRS *****
(BC87 HAS ADDITIVE ADJUSTMENT FACTOR)

```
A39F  USE LOMEM PAGE AS MSB FOR $3E/3F
A3A3  GET LOMEM LSB
A3A5  AND END OF SIMPLE VARS PAGE
A3A8  JUMP INTO THE LOOP >>A3AF
A3AA  ---
A3AB  SKIP ONE SIMPLE VARIABLE
A3AF  ---
A3B1  OVERFLOW? >>A3B5
A3B3  YES, BUMP MSB
A3B5  FINISHED WITH SIMPLE VARS?
A3B9  (CHECK BOTH MSB AND LSB OF PTR)
A3BB  ---
A3BC  YES... >>A3D2
A3BE  NO,
A3C0  LOOK AT A SIMPLE VARIABLE
A3C5  SKIP INTEGER AND REAL VARS >>A3AA
A3C7  (DOUBLE CHECK MSB)
A3CB  ITS A STRING, POINT TO ITS LEN/ADDR
A3CC  ADJUST IT IF NECESSARY <A3F9>
A3CF  THEN SKIP OVER IT >>A3AA
```

```
A3D2  COPY ARRAYS STARTING LSB
A3D4  (MSB IS IN X REGISTER NOW) (BC81)
A3D7  ---
A3D8  FIND A STRING ARRAY <A15C>
A3DB  NO MORE? THEN DONE... >>A40C
A3DD  ---
A3E0  ADJUST ITS ADDRESS IF NEED BE <A3F9>
A3E6  SKIP TO NEXT STRING ELEMENT OF ARRAY
A3EE  AT END OF THIS ARRAY YET? (BC81)
A3F1  NO... >>A3DD
A3F3  (CHECK MSB ALSO)
A3F7  YES..., GO GET NEXT ARRAY >>A3D7
```

A3F9 ***** ADJUST A STRING ADDRESS *****

```
A3F9  GET STRING LENGTH
A3FB  IGNORE NULL STRINGS >>A40C
A3FD  POINT TO MSB OF ADDRESS
A3FF  IS STRING STORED OUTSIDE OF PROGRAM?
A403  NO, LEAVE IT ALONE >>A40C
A405  STORE ABOVE LOMEM, ADD FACTOR TO MSB
A40C  THEN EXIT
```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A40C

ADDR DESCRIPTION/CONTENTS

A40D ***** COMPRESS ALL ASOFT VARS *****
THIS ROUTINE SQUASHES ALL APPLESOFT VARS
UP AGAINST THE BOTTOM OF THE STRINGS
HIMEM -->

STRINGS

ARRAY VARS

SIMPLE VARS

A40D GARBAGE COLLECT FIRST <A01D>

```
A410  ERROR? >>A471
A412  COMPUTE LENGTH OF SIMPLE AND ARRAY VARS
A417  AND SAVE IT (BC89)
A427  NEXT, COMPUTE LENGTH OF SIMPLE VARS ONLY
A42B  AND SAVE IT (BC8B)
A435  SUBTRACT VAR LENGTH FROM STRING START
A437  TO FIND A PLACE TO PUT THE VARS UNDER (BC92)
A43A  THE STRINGS (START ON AN EVEN PAGE BOUND)
A440  $3C/$3D --> PLACE TO PUT VARS
A447  $3A/$3B --> START OF VARS (ROUNDED TO EVEN
A449  PAGE ALIGNMENT)
A44F  COPY VARS UP AGAINST STRINGS <A37F>
A454  STORE START OF VARS PTR (BC8E)
A457  BUMPING PAGE NUMBER BY ONE
A463  SUBTRACT THIS PTR FROM HIMEM TO COMPUTE (BC90)
A466  TOTAL LENGTH OF COMBINED VARS/STRINGS
A468  AND SAVE THIS TOO (BC8D)
A46B  ALSO, SAVE HIMEM MSB IN CASE THEY ARE MOVED
A471  DONE, EXIT
```

A472 ***** REEXPAND COMPRESSED VARS *****
THIS ROUTINE MOVES SIMPLE AND ARRAY VARS
BACK DOWN TO LOMEM.

HIMEM -->

STRINGS

FREE SPACE

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A472

ADDR	DESCRIPTION/CONTENTS
0000	...
0001	...
0002	...
0003	...
0004	...
0005	...
0006	...
0007	...
0008	...
0009	...
000A	...
000B	...
000C	...
000D	...
000E	...
000F	...
0010	...
0011	...
0012	...
0013	...
0014	...
0015	...
0016	...
0017	...
0018	...
0019	...
001A	...
001B	...
001C	...
001D	...
001E	...
001F	...
0020	...
0021	...
0022	...
0023	...
0024	...
0025	...
0026	...
0027	...
0028	...
0029	...
002A	...
002B	...
002C	...
002D	...
002E	...
002F	...
0030	...
0031	...
0032	...
0033	...
0034	...
0035	...
0036	...
0037	...
0038	...
0039	...
003A	...
003B	...
003C	...
003D	...
003E	...
003F	...
0040	...
0041	...
0042	...
0043	...
0044	...
0045	...
0046	...
0047	...
0048	...
0049	...
004A	...
004B	...
004C	...
004D	...
004E	...
004F	...
0050	...
0051	...
0052	...
0053	...
0054	...
0055	...
0056	...
0057	...
0058	...
0059	...
005A	...
005B	...
005C	...
005D	...
005E	...
005F	...
0060	...
0061	...
0062	...
0063	...
0064	...
0065	...
0066	...
0067	...
0068	...
0069	...
006A	...
006B	...
006C	...
006D	...
006E	...
006F	...
0070	...
0071	...
0072	...
0073	...
0074	...
0075	...
0076	...
0077	...
0078	...
0079	...
007A	...
007B	...
007C	...
007D	...
007E	...
007F	...
0080	...
0081	...
0082	...
0083	...
0084	...
0085	...
0086	...
0087	...
0088	...
0089	...
008A	...
008B	...
008C	...
008D	...
008E	...
008F	...
0090	...
0091	...
0092	...
0093	...
0094	...
0095	...
0096	...
0097	...
0098	...
0099	...
009A	...
009B	...
009C	...
009D	...
009E	...
009F	...
00A0	...
00A1	...
00A2	...
00A3	...
00A4	...
00A5	...
00A6	...
00A7	...
00A8	...
00A9	...
00AA	...
00AB	...
00AC	...
00AD	...
00AE	...
00AF	...
00B0	

NAME	TYPE	INITIAL VALUE	SCOPE
array_vars	array	0	global
simple_vars	simple	0	global

```

A472 SAVE LENGTH OF SIMPLE AND ARRAY VARS (BC89)
A479 ADD THIS TO START OF COMPRESSED VARS PTR
A47B TO GIVE START OF STRINGS ($6D/$6E)
A487 $3C/$3D --> LOWEM (WHERE TO PUT SIMPLE VARS)
A48E $6B/$6C --> WHERE TO PUT ARRAY VARS
A499 $3A/$3B --> START OF COMPRESSED VARS (BC8E)
A4A3 COPY SIMPLE/ARRAY VARS DOWN TO LOWEM <A35B>
A4A4 COMPUTE START OF STRINGS BY ADDING VARS
A4AC LENGTH TO VARS ORIGIN
A4B5 DID HIMEM MOVE SINCE VARS WERE COMPRESSED?
A4B8 NO... >>A4C2
A4BA A4BA
A4BC YES, ADJUST BY DIFFERENCE IN HIMEM'S (BC87)
A4BF GO ADJUST ALL STRING POINTERS <A3F>
A4C2 THEN EXIT
A4C3 RETURN

```

[illegible]

```

A4C4      PUT OUT A BLANK LINE <A66C>
A4C7      DOUBLE QUOTE TO $200
A4C7      GET LENGTH OF NAME ($259)
A4C7      COPY NAME TO LINE ($259)
A4D2      ZERO ACCUMULATOR FOR LATER (BCB1)
A4D4      GET FILE TYPE ($269)
A4E3      I KNOW OF ONLY 13
A4E5      ---
A4E7      LOOK UP FILE TYPE IN TABLE (B989)
A4E8      FOUND IT? >>A4F7
A4F0      FILE TYPE NOT IN MY TABLE
A4F2      PRINT IT IN HEXADECIMAL <A612>
A4F5      AND CONTINUE BELOW >>A53B
A4F7      ELSE, FOR KNOWN TYPES
A4FA      COPY NAME OF TYPE TO THE LINE (B997)
A505      80 COLUMNS PER LINE? (BCB6)
A508      YES... >>A553
A508      NO,
A50C      BIN FILE?
A50E      YES... >>A525
A510      TXT FILE?

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84

ADDR	DESCRIPTION/CONTENTS
------	----------------------

```

A512 NO... >>A53B
A514 YES, R VALUE GIVEN AS SUBTYPE
A51F CONVERT R VALUE TO DECIMAL <A62F>
A522 SKIP OVER BIN CODE >>A536
A525 BIN FILE, USE AD VALUE AS SUBTYPE
A52D CONVERT IT TO TWO HEX DIGITS <A612>
A536 ADD AN "=" SIGN
A53B COPY MSB OF END OF FILE MARK (0270)
A549 CONVERT LOW TWO BYTES OF EOF <A62F>
A550 DO CREATION DATE/TIME <A570>
A553 ---
A55B CONVERT BLOCKS USED <A62F>
A563 CHECK FOR WRITE ACCESS
A565 UNLOCKED? >>A56C
A567 NO, ADD A ""
A56C FALL THRU TO DO LAST MODIFIED DATE/TIME
A56E AND THEN EXIT TO CALLER

```

[illegible]

X = OFFSET FROM \$259 TO FIELD
Y = \$201 OFFSET TO DATE/TIME VALUE

```

A570  ISOLATE YEAR (025A)
A574  AND STORE IT (BCB5)
A57B  ISOLATE DAY
A57D  AND STORE IT (BCB4)
A581  ISOLATE MONTH
A587  (MONTH = 0 IS NO GOOD) >>A5A3
A58B  (MONTH > 12 IS ALSO BAD) >>A5A3
A58D  STORE MONTH (BCB3)
A591  MULTIPLY MONTH INDEX BY 3 (BCB3)
A594  AND SAVE IT INSTEAD (BCB3)
A59A  (DAY = 0 IS NO GOOD) >>A5A3
A5A1  (YEAR MUST BE < 99) >>A5B5

A5A3  OTHERWISE, BAD DATE!
A5A5  BACK UP 6 CHARACTERS ON LINE
A5AA  AND PRINT "<NO DATE>" (B9E5)
A5B4  THEN EXIT RIGHT AWAY

A5B5  DATE OK, GET HOUR (025C)
A5B9  AND MINUTES (025B)
A5BE  MINUTES > 60?
A5C0  NO.. >>A5C3
A5C2  YES, USE ZERO MINUTES
A5C3  CONVERT MINUTES (LEFT ZERO FILL) <A60A>
A5C8  THEN PRINT A "." (0201)
A5CC  GET HOUR AGAIN
A5CF  GREATER THAN 24 HOURS?
A5D1  NOPE >>A5D4
A5D3  YES, USE ZERO

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A5D4

ADDR DESCRIPTION/CONTENTS

```
A5D4 10 OR MORE HOURS (TWO DIGITS?)
A5D7 IN ANY CASE, CONVERT HOURS <A62F>
A5DB IF TWO DIGITS... >>A5DE
A5DD IF ONE, ADJUST LINE PTR
A5DE ---
A5E2 CONVERT YEAR (LEFT ZERO FILL) <A60A>
A5E6 GET MONTH INDEX (*3) (BCB3)
A5E9 POINT TO LAST CHARACTER
A5EC COPY MONTH NAME FROM TABLE (B9BD)
A5EF TO LINE (0201)
A5F7 BACKWARDS... >>A5EC
A5FB PUT A "-" IN (0201)
A5FE TWO PLACES (0205)
A607 EXIT BY CONVERTING DAY >>A62F
```

A60A ***** CONVERT 2 DIGIT NUMBER *****
(FORCE LEFT ZERO FILL)

```
A60A ---
A60B ADD 100 TO FORCE SIGNIFICANCE IN TENS
A60D CONVERT IT <A62F>
A610 IGNORE 100'S PLACE
A611 RETURN
```

A612 ***** CONVERT TO HEX *****

```
A612 ---
A613 ISOLATE LOW NIBBLE
A615 AND GO CONVERT IT FIRST <A61D>
A619 NOW ISOLATE HIGH NIBBLE
A61C AND FALL THRU TO CONVERT IT ALSO
A61D CONVERT NIBBLE TO NUMERIC ASCII
A61F >9?
A621 NO >>A625
A623 YES, CONVERT $BA-$BF TO $C1-$C6
A625 AND STORE THE RESULT (0201)
A628 BUMP LINE INDEX BACK
A629 PRECEED WITH A $ SIGN
A62E RETURN
```

A62F ***** CONVERT TO DECIMAL *****

```
A62F A,X = NUMBER Y=INDEX TO LAST FIELD DIGIT (BCB0)
A632 STORE NUMBER IN ACCUMULATOR (BCAF)
A635 DIVIDE BY 10 <A64D>
A638 GET DIGIT AND CONVERT IT (BCB2)
A63D STORE IN LINE (0201)
A640 AND DROP LINE INDEX BY ONE
A641 IS QUOTIENT NOW ZERO? (BCAF)
A64A NO, CONTINUE UNTIL IT IS >>A635
```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A64C

ADDR DESCRIPTION/CONTENTS

```
A64C ELSE, EXIT
***** DIVIDE ACCUMULATOR BY 10 *****
A64D 24 BIT SHIFT (3 BYTES)
A651 CLEAR SUM (BCB2)
A654 GO ROL ACCUMULATOR LEFT ONE BIT <A6D7>
A657 ALSO ROL 4TH BYTE OF ACCUM (BCB2)
A65B IF MSB > 10... (BCB2)
A665 THEN ADD ONE TO ACCUMULATIVE SUM (BCAF)
A668 ---
A669 SHIFT 24 TIMES >>A654
A66B RETURN
A66C ---
A676 RETURN
```

A677 ***** SYNTAX: PARSE COMMAND LINE *****
(ALSO EXTERNAL ENTRY FOR COMMAND STRINGS)

```
A677 INIT COMMAND NUMBER TO -1
A67E A BLANK ENDS EACH STRING (BCA9)
A683 AT MOST 8 CHARACTERS IN A COMMAND (BCAA)
A686 PARSE COMMAND ITSELF <A61B>
A689 GET FIRST LETTER (BCBD)
A68C MUST BE ALPHABETIC
A68E IT IS... >>A697
A690 IT'S NOT, IS IT A "-"?
A692 YES, OK THEN... >>A697/
A694 ELSE, ITS BAD - SYNTAX ERROR >>A839
A697 SCAN FOR COMMAND IN TABLES <AAE1>
A69A BAD COMMAND? >>A694
A69C NO, IMMEDIATE COMMAND MODE? (BE42)
A69F NO, DEFERRED... >>A6AC
A6A1 IMMEDIATE, EXEC ACTIVE? (BE43)
A6A4 YES, NEVER MIND >>A6AC
A6A6 ERASE TO END OF LINE <FC9C>
A6A9 AND GO TO A NEW LINE ON SCREEN <9FAB>
A6AC ASSUME NO PARMS AT ALL
A6B4 NO PATH NAME YET (BCBD)
A6B7 NO SECONDARY PATH NAME EITHER (0280)
A6BD CURRENT SLOT = DEFAULT SLOT (BE61)
A6C3 CURRENT DRIVE = DEFAULT DRIVE (BE62)
A6C8 BUFFER ALLOCATION = HIMEM (BC88)
A6CB GET LENGTH OF COMMAND NAME (BE52)
A6D0 ALLOW 2 MORE CHARACTERS FOR NOW (BCAA)
A6D3 ARE ANY PARAMETERS PERMITTED? (BE54)
A6D6 NO...MUST BE NOW OR NOMON >>A736
A6D8 YES, IN# OR PR#?
A6D9 YES... >>A739
A6DB ELSE, REPARE THE COMMAND <A61B>
A6E0 FOR THIS COMMAND... (BE54)
```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A6E3
 ADDR DESCRIPTION/CONTENTS

A6E3 DOES THE PREFIX NEED FETCHING? >>A6EA
 A6E5 YES,
 A6E7 MLI: GET PREFIX FROM DEFAULT DRIVE <BE70>
 A6EA ---
 A6EC END OF LINE? >>A736
 A6EE NO, COMMA?
 A6F0 NO >>A6F5
 A6E2 YES, NO FILENAME, LOOK FOR KEYWORDS >>A787
 A6E5 "/"?
 A6E7 YES >>A6FD
 A6F9 NO, ALPHABETIC?
 A6FB NO...FILE NAMES MUST BEGIN THAT WAY >>A72F
 A6FD ---
 A6FE DON'T FLUSH ANY BLANKS OUT OF PATHNAME
 A703 ALLOW 64 CHARACTERS NEXT PARSE
 A709 PARSE NEXT OPERAND ON LINE <AA1F>
 A70D SAVE ITS LENGTH (BCBC)
 A712 FOUND A PATHNAME#1 (BE56)
 A715 COPY PARM KEYWORD TO \$280 (BCBC)
 A718 (ASSUMING PATHNAME1=PATHNAME2) (0280)
 A71F CHECK NEXT CHAR (OTHER THAN A BLANK) <AA3A>
 A722 NOT COMMA OR RETURN, BAD! >>A72C
 A724 RETURN? >>A798
 A726 NO, PATHNAME EXPECTED NOW? (BE54)
 A72A YES, ALL IS WELL >>A762
 A72C NO, "SYNTAX ERROR" >>A839
 A72F NON ALPHA FILE NAME, CHECK COMMAND NUMBER (BE53)
 A732 IS IT "RUN"
 A734 NO, ERROR >>A72C
 A736 YES, ITS OK THEN (MIGHT BE "RUN 100") >>A798
 A739 IN\$/PR\$, REPARSE COMMAND <AA1B>
 A73C RETURN FOUND - ERROR >>A72C
 A73E "A"? (ADDRESS KEYWORD)
 A740 IF SO, GO PARSE THAT KEYWORD ONLY >>A78C
 A742 ELSE, ZERO ACCUMULATOR <AB37>
 A745 CONVERTING ONE BYTE'S WORTH (BCAD)
 A74A PUT IT IN PR\$/IN# SLOT VALUE AREA (BCAE)
 A74F FOUND SLOT FOR PR\$/IN# (BE56)
 A752 CONVERT SLOT # <A960>
 A755 ERROR? >>A761
 A757 GET CONVERTED VALUE (BE6B)
 A75A >8?
 A75C NO, ITS OK >>A791
 A75E YES, "RANGE ERROR"
 A761 RETURN
 A762 SECOND PATHNAME EXPECTED?
 A763 NO >>A787
 A765 YES, FLUSH TO NON-BLANK <AA3A>
 A768 NOTHING ELSE ON LINE??? >>A72C
 A76B DON'T FLUSH ANY BLANKS OUT OF PATHNAME
 A772 COPY SECOND PATHNAME TO \$281 <AA00>

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A777
 ADDR DESCRIPTION/CONTENTS

A777 SAVE IT'S LENGTH (LESS 1) (0280)
 A77C FOUND PATHNAME1 AND PATHNAME2 (BE56)
 A780 GET LAST CHARACTER AGAIN <AA3A>
 A783 IF NOT COMMA OR RETURN, "SYNTAX ERROR" >>A72C
 A785 RETURN? >>A798
 A787 NO, COMMA, FLUSH TO NON-BLANK <AA3A>
 A78A SYNTAX ERROR IF TWO COMMAS IN A ROW >>A72C
 A78C LOOKUP KEYWORD CHAR AND PARSE ITS VALUE <ABE8>
 A78F EXIT NOW? >>A761
 A791 NO, FLUSH TO NON-BLANK <AA3A>
 A794 SYNTAX ERROR IF COMMA OR RETURN NOT FOUND >>A72C
 A796 COMMA? YES, GO GET NEXT KEYWORD >>A787
 A798 GET PARSED SLOT (BE61)
 A79B MUST BE NON-ZERO >>A75E
 A79D AND LESS THAN 8
 A79F OR ELSE - "RANGE ERROR" >>A75E
 A7A1 CHECK DRIVE TOO (BE62)
 A7A6 MUST BE EITHER 1 OR 2
 A7AD IS THIS A DEFERRED COMMAND?
 A7B0 NO... >>A7BB
 A7B2 YES, IS A PROGRAM RUNNING? (BE42)
 A7B5 YES >>A7BB
 A7B7 NO, "NOT DIRECT COMMAND"
 A7BA RETURN
 A7BB EXPECTING NO PATHNAMES? >>A7FD
 A7BD NO... (BE55)
 A7C0 ARE S AND D VALID FOR THIS CMD?
 A7C2 NO >>A7FD
 A7C4 YES, HAVE WE GOT PATHNAME1? (BE56)
 A7C8 YES >>A7D3
 A7CD IS PATHNAME REQUIRED?
 A7CF YES, "SYNTAX ERROR" >>A839
 A7D1 NO, OPTIONAL - NO PREFIX FETCH THEN >>A7FD
 A7D6 DOES PATHNAME1 START WITH A "/"?
 A7D8 YES, FULLY QUALIFIED >>A7DF
 A7DA NO, IS THERE A PREFIX ACTIVE? (BF9A)
 A7DD NO >>A7F8
 A7DF YES, (BE57)
 A7E2 SLOT/DRIVE GIVEN WITH THIS COMMAND?
 A7E4 NO, FORGET IT >>A7FD
 A7E6 YES, DO WE HAVE PATHNAME ALSO? >>A7F8
 A7E8 NO,
 A7EA NULL OUT PATHNAME1 (BCBC)
 A7F2 MARK THAT WE WILL HAVE ONE SOON (BE56)
 A7F8 ADD PREFIX TO FILENAMES <A83D>
 A7FB ERROR? >>A83B
 A7FD GET COMMAND NUMBER (BE53)
 A800 *2 AS INDEX INTO TABLE
 A802 GET ADDRESS OF COMMAND HANDLING ROUTINE (BBE9)
 A80B AND STORE IT FOR INDIRECT JMP (BCAC)

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A810

ADDR DESCRIPTION/CONTENTS

A810 EXTERNAL COMMAND? IF SO GO NOW! >>A836
 A812 MY OWN COMMAND, "PREFIX"?
 A814 YES, GO NOW >>A836
 A819 S OR D VALID KEYWORDS FOR THIS CMD?
 A81B NO, GO NOW >>A836
 A820 PATHNAME1 GIVEN WITH THIS COMMAND?
 A821 NO, GO NOW >>A836
 A823 YES, GET FILE INFO FOR PATHNAME1 <B7D0>
 A826 NO ERRORS I HOPE >>A836
 A828 ERROR WAS PATH NOT FOUND?
 A82A NO, REAL ERROR - SAY SO >>A83B
 A82F CAN WE CREATE PATHNAME1?
 A831 YES, OK THEN >>A836
 A833 ELSE, "PATH NOT FOUND"
 A835 RETURN
 A836 GO TO COMMAND HANDLING ROUTINE >>BCAB

A839 ***** SYNTAX ERROR *****

A839 LOAD BI CODE FOR "SYNTAX ERROR"
 A83B AND RETURN WITH ERROR CONDITION
 A83C RETURN

A83D ***** ADD PREFIX TO PATHNAMES *****

A83D GET SLOT NUMBER (BE61)
 A844 PUT SLOT IN HIGH 3 BITS
 A846 ADD DRIVE TO TOP BIT AND SHIFT SLOT DOWN (BE62)
 A84E ...TO FORM THE UNIT NUMBER (BEC7)
 A853 READ THE PATHNAME PREFIX TO \$201 (BEC8)
 A85D MLI: ONLINE <BE70>
 A860 ERROR? >>A83B
 A865 DEFAULT DRIVE = PARSED DRIVE (BE3D)
 A86B DEFAULT SLOT = PARSED SLOT (BE3C)
 A871 PATHNAME1 STARTS WITH "/"?
 A873 THEN ITS ALREADY GOT A PREFIX >>A8E6
 A878 ELSE, GET LENGTH OF PATHNAME
 A87A BUMP IT BY 2 (TO ALLOW FOR /'S)
 A882 WITH PREFIX WILL IT EXCEED 64 CHARS?
 A887 YES, "SYNTAX ERROR" >>A8E7
 A889 NO, UPDATE LENGTH TO INCLUDE PREFIX (BCBC)
 A88F ---
 A893 AND COPY PATHNAME1 FORWARD TO MAKE ROOM (BCBD)
 A89C PUT A "/" AT THE BEGINNING
 A8A1 AND AT THE END (BCBD)
 A8A4 COPY PREFIX JUST READ TO START OF PATHNAME1 (0200)
 A8A8 GET COMMAND NUMBER (BE53)
 A8AD "OPEN"?
 A8AF YES, DONE NOW! >>A8E6
 A8B1 "APPEND"?
 A8B3 YES, DONE NOW! >>A8E6

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A8B5

ADDR DESCRIPTION/CONTENTS

A8B5 "EXEC"?
 A8B7 YES, DONE NOW! >>A8E6
 A8B9 ELSE, GET LENGTH OF PATHNAME2 (0280)
 A8BE COMBINE THIS WITH PREFIX LENGTH (0201)
 A8C1 MORE THAN 64 CHARS?
 A8C6 IF SO, "SYNTAX ERROR" >>A8E7
 A8C8 UPDATE LENGTH (0280)
 A8CB ---
 A8CF COPY PATHNAME2 FORWARD TO MAKE ROOM (0281)
 A8D8 PUT A "/" IN FIRST
 A8DD THEN THE PREFIX AND ANOTHER SLASH (0281)
 A8E6 ---
 A8E7 DONE!

A8E8 ***** KEYWORD LOOKUP *****

A8E8 ZERO THE ACCUMULATOR <AB37>
 A8EB NINE POSSIBLE KEYWORDS IN TABLE
 A8ED COMPARE AGAINST EACH (B96B)
 A8F0 FOUND IT? >>A927
 A8F5 NO, IS IT "T"? (FILE TYPE)
 A8F7 YES, OK THEN >>A8FC
 A8F9 ELSE, BAD KEYWORD >>A839
 A8FC IT'S "T", IS IT PERMITTED ON THIS CMD?
 A901 NO, ERROR >>A923
 A906 ELSE, MARK WE HAVE "T" (BE56)
 A90B START WITH TYPE INDEX OF 0 (BCAD)
 A910 INDICATE WHERE T VALUE IS TO GO (BCAE)
 A913 AND GO PARSE ONE CHAR <A93A>
 A916 NOTHING THERE??? >>A8F9
 A918 IS IT A \$?
 A91A YES, HE GAVE TYPE IN HEX >>A976
 A91C IS IT ALPHABETIC?
 A91E NO, CONVERT DECIMAL TYPE >>A960
 A920 ELSE, GO LOOKUP TYPE NAME IN TABLE >>A9B6
 A923 ---
 A924 "INVALID PARAMETER"
 A926 RETURN
 A927 GET BIT POSITION OF THIS KEYWORD (B975)
 A92A IGNORE "V" >>A947
 A92C IS THIS KEYWORD PERMITTED? (BE55)
 A92F NO, NOT WITH THIS COMMAND ANYWAY >>A923
 A931 S OR D?
 A933 NO >>A941
 A935 YES, ALREADY FOUND IT ON THIS LINE? (BE57)
 A938 YES, DON'T CHANGE DRIVE DEFAULT >>A947
 A93A ELSE, ASSUME DRIVE = 1
 A941 MARK WE HAVE SLOT/DRIVE (BE57)
 A947 GET SIZE-1 IN BYTES OF VALUE (B97F)

BASIC Interpreter (BI) -- V1.1 --1B JUN B4 NEXT OBJECT ADDR: A954

 ADDR DESCRIPTION/CONTENTS

A954 AND OFFSET TO VALUE IN STORAGE AREA (BCAE)
 A957 FLUSH TO NON-BLANK <AA3A>
 A95A NOTHING ELSE THERE? >>A9B0
 A95C IS NEXT CHAR A "S"?
 A95E YES, GO CONVERT HEX - ELSE, FALL THRU >>A976

A960 ***** CONVERT DECIMAL NUMBER *****

A960 SAVE LINE INDEX (BE4B)
 A963 CONVERT/ADD ONE DECIMAL DIGIT TO ACCUM <AA5C>
 A966 OK.. >>A96C
 A968 OVERFLOW? THEN "RANGE ERROR" >>A9B3
 A96A BAD DIGIT? THEN "SYNTAX ERROR" >>A9B0
 A96C RESTORE LINE INDEX (BE4B)
 A96F FLUSH TO NEXT NON-BLANK <AA3A>
 A972 AND GO BACK TO CONVERT NEXT DIGIT >>A960
 A974 ALL DONE, END OF LINE OR COMMA >>A98F

A976 ***** CONVERT HEX NUMBER *****

A976 FLUSH TO NEXT NON-BLANK (SKIP "S") <AA3A>
 A979 NOTHING LEFT? >>A9B0
 A97B SAVE LINE INDEX (BE4B)
 A97E CONVERT HEX DIGIT <AAAE>
 A981 OK.. >>A987
 A983 OVERFLOW? THEN "RANGE ERROR" >>A9B3
 A985 BAD DIGIT? THEN "SYNTAX ERROR" >>A9B0
 A987 RESTORE LINE INDEX (BE4B)
 A98A FLUSH TO NEXT NON-BLANK <AA3A>
 A98D AND GO CONVERT NEXT DIGIT >>A97B

A98F ***** STORE KEYWORD VALUE *****

A98F HOW MANY BYTES TO CHECK?
 A994 ALL HAVE BEEN CHECKED? >>A99E
 A996 NO, INSURE MSB'S OF ACCUM ARE ZERO (BCAF)
 A999 IF NUMBER IS A SHORT INTEGER >>A9B3
 A9A1 COPY ACCUM TO PROPER FARM STORAGE CELL (BCAF)
 A9AB RESTORE LINE INDEX (BE4B)
 A9AF AND EXIT

A9B0 "SYNTAX ERROR" JUMP >>AB39
 A9B3 "RANGE ERROR" JUMP >>A75E

A9B6 ***** STORE KEYWORD VALUE *****

 A9B6 COPY 3 CHARACTER TYPE TO ACCUM (BCAF)
 A9B8 (COPIED ALL 3?) >>A9C7
 A9C0 (GET NEXT CHAR IGNORING BLANKS) <AA3A>
 A9C5 MUST HAVE 3 CHARACTERS! >>A9B0

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: A9C7

 ADDR DESCRIPTION/CONTENTS

A9C7 SAVE LINE INDEX (BE4B)
 A9CA INITIALIZE NAME INDEX TO ZERO
 A9CF HAVE ALL 13 BEEN CHECKED?
 A9D1 YES, NO MATCH >>A9B0
 A9D4 ELSE, INDEX*3 (BCAD)
 A9D8 COMPARE TYPE GIVEN (BCAF)
 A9DB TO TYPES IN TABLE (B997)
 A9DE (IGNORE MSB'S)
 A9DF NO MATCH ALREADY... >>A9E9
 A9E3 ELSE,
 A9E5 CHECK ALL THREE CHARS >>A9D8
 A9E7 THEY ALL MATCH! WE FOUND IT >>A9EE
 A9E9 NOT THE RIGHT ONE, (BCAD)
 A9EC GO TRY THE NEXT ONE >>A9CA
 A9EE REVERSE NAME INDEX
 A9F5 AND GET TYPE VALUE FROM TABLE (B9B9)
 A9F8 STORE IT IN TYPE VALUE STORAGE AREA (BE6A)
 A9FB RESTORE LINE INDEX (BE4B)
 A9FF AND EXIT

AA00 ***** COPY PATHNAME2 *****

AA00 GET NEXT CHARACTER <AA4A>
 AA03 AND STORE IT INDEXED OFF \$280 (0280)
 AA07 COMMA?
 AA09 YES, DONE >>AA37
 AA0B BLANK?
 AA0D YES, DONE >>AA37
 AA0F RETURN?
 AA11 YES, OUT NOW >>AA48
 AA13 PATHNAME TOO LONG? (BCAA)
 AA16 NO, CONTINUE COPYING >>AA00
 AA18 ELSE, SET NOT-EQUAL CONDITION
 AA1A AND EXIT

AA1B ***** COPY COMMAND NAME INTO TXTBUF *****

AA1B SET INDICIES
 AA1F GET NEXT NON-BLANK <AA4A>
 AA22 COPY TO TXTBUF (BCBD)
 AA26 COMMA?
 AA28 YES, DONE >>AA37
 AA2A BLANK?
 AA2C YES, DONE >>AA37
 AA2E RETURN?
 AA30 YES, DONE >>AA48
 AA32 AT MAX LENGTH (8)? (BCAA)
 AA35 NO, CONTINUE >>AA1F
 AA37 ELSE, SET NOT-EQUAL CONDITION
 AA39 AND EXIT

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: AA39

ADDR DESCRIPTION/CONTENTS

AA3A ***** FLUSH TO NON-BLANK *****
Z-FLAG SET IF COMMA OR RETURN FOUND
C-FLAG SET IF COMMA

AA3A IGNORE BLANKS
AA3F GET NEXT NON-BLANK <AA4A>
AA42 COMMA?
AA44 YES, OUT >>AA49
AA46 RETURN?
AA48 EXIT INDICATING WHAT WE FOUND
AA49 RETURN

AA4A ***** GET NEXT CHARACTER *****

AA4A GET NEXT CHAR IN INPUT LINE (0200)
AA4D FORCE OFF MSB
AA4F LOWER CASE?
AA51 NO >>AA55
AA53 YES, FORCE UPPER CASE
AA55 BUMP LINE INDEX
AA56 IS THIS A FLUSH CHARACTER (LIKE BLANK)? (BCA9)
AA59 YES, GO GET NEXT ONE >>AA4A
AA5B ELSE, RETURN WITH IT

AA5C ***** CONVERT DIGIT AND ADD TO ACCUM *****

AA5C NUMERIC?
AA5E NO >>AA64
AA62 YES >>AA68
AA64 NOT NUMERIC, EXIT WITH CARRY SET
AA65 AND Z-FLAG RESET
AA67 RETURN
AA68 ISOLATE DECIMAL PORTION OF DIGIT
AA6B CURRENT VALUE OF ACCUM... (BCB1)
AA6E >1,703,936?
AA70 YES, OVERFLOW >>AA94
AA74 PUSH ENTIRE ACCUM ONTO STACK (BCAF)
AA7B ACCUM*2 (ROL IT ONCE) <AAD7>
AA7E ACCUM*4 (AND AGAIN) <AAD7>
AA84 ---
AA85 ACCUM*4+ACCUM --> ACCUM*5 (BCAF)
AA91 FINALLY, ACCUM*5*2 --> ACCUM*10 <AAD7>
AA94 ---
AA95 ACCUM OVERFLOW? >>AAAA
AA97 NO, ADD NEW DIGIT TO ACCUM (BCAF)
AA9A AND STORE IT (BCAF)
AA9D NO CARRY? >>AAD
AAAB GOT CARRY, PROPAGATE IT THRU ACCUM (BCB0)
AAAA OVERFLOW ERROR
AAAD NORMAL EXIT

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: AAAD

ADDR DESCRIPTION/CONTENTS

AAAE ***** CONVERT HEX DIGIT AND ADD *****

AAAE NUMERIC?
AAB0 NO >>AABE
AAB4 YES >>AAC4
AAB6 NON-NUMERIC, HOW BOUT "A" THRU
AABA "F"
AABC YES! >>AAC2
AABE ---
AABF NO, GET OUT NOW
AAC1 RETURN
AAC2 "A" THRU "F", CONVERT TO \$BA-\$BF
AAC4 ISOLATE DIGIT
AAC8 SHIFT ACCUM 4 BITS LEFT TO MAKE ROOM <AAD7>
AACB (WATCH OUT FOR OVERFLOW) >>AAAA
AAD0 OR IN NEW NIBBLE (BCAF)
AAD3 AND REPLACE IN ACCUM LSB (BCAF)
AAD6 DONE

AA7 ***** SHIFT 3 BYTE ACCUM LEFT A BIT *****

AA7 SHIFT THE THREE BYTE WORK ACCUM (BCAF)
AAE0 RETURN

AAE1 ***** SCAN CMD TABLE FOR COMMAND *****

AAE1 START WITH LAST COMMAND IN TABLE
AAE6 IS IT A "-" COMMAND? (BCBD)
AAEB NOPE >>AAF5
AAED YES, SPECIAL COMMAND NUMBER (BE53)
AAE0 ZERO LENGTH COMMAND STRING (BE52)
AAE3 CONTINUE >>AB12
AAE5 FIRST COMMANDS IN TABLE ARE 8 CHARS
AAFA GET INDEX TO NEXT NAME (B850)
AAFD SAME LENGTH AS LAST NAME? >>AB05
AAFF NO,
AB02 NAMES ARE ONE BYTE SHORTER FROM NOW ON (BE52)
AB05 ---
AB06 COMPARE HIS NAME TO MY TABLE (BCBD)
AB0C NOT IT... >>AB25
AB10 COMPARE ENTIRE NAME >>AB06
AB12 FOUND IT! GET COMMAND INDEX (BE53)
AB15 *2 FOR MOST THINGS
AB17 PICK UP PERMITTED PARAMS BITS (B92A)
AB23 EXIT HAPPILY
AB24 RETURN

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: AB24

 ADDR DESCRIPTION/CONTENTS

AB25 NOT THE ONE, SKIP TO NEXT (BE52)
 AB2E IF THERE ARE ANY MORE >>A4FA
 AB30 ELSE, NO SUCH COMMAND (BE53)
 AB34 XRETURN THRU \$BE06 VECTOR >>BE06

AB37 ***** ZERO THREE BYTE ACCUM *****

AB37 ZERO THE THREE BYTE WORK
 AB39 ...ACCUMULATOR (BCAF)
 AB42 RETURN

AB43 ***** "-" COMMAND *****

AB43 CHECK FILE TYPE (BE88)
 AB46 APPLESOFT PROGRAM?
 AB48 YES, "RUN" IT >>ABB2
 AB4A BINARY FILE?
 AB4C YES, "BRUN" IT >>AB8D
 AB4E TEXT FILE?
 AB50 NO >>AB55
 AB52 YES, "EXEC" IT >>B221
 AB55 SYS FILE?
 AB57 YES, GO RUN IT >>AB5D
 AB59 ELSE, "FILE TYPE MISMATCH"
 AB5C RETURN

***** RUN "SYS" FILE *****

AB5D CLOSE ALL OPEN FILES <B4F2>
 AB60 CLOSE EXEC <B2FB>
 AB65 LSB OF A\$ IS 00 (BE58)
 AB68 FREE UP ALL OF BI'S MEMORY (BF6B)
 AB7B A\$2000 IS WHERE IT WILL LOAD (BE59)
 AB80 TYPE IS "SYS" (BE6A)
 AB8A FORCE, T, PATHNAME1, AD PARMS (BE56)
 AB8D GO DO A STANDARD BRUN >>AE16

AB90 ***** "CHAIN" COMMAND *****

AB90 SQUASH VARIABLES UP AGAINST HIMEM <A40D>
 AB95 SAVE HIMEM (BC7B)
 AB9C SET NEW HIMEM BELOW COMBINED VARS
 AB9E LOAD FILE (LEAVE OTHERS OPEN) <AC03>
 AB4A RESTORE OLD HIMEM
 AB46 ERROR? >>AC14
 AB48 NO, CLEAR VARIABLES <D665>
 ABAB REEXPAND VARIABLES DOWN AGAINST LOMEM <A472>
 AB80 THEN GO "RUN" PROGRAM >>ABC7

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: ABB0

 ADDR DESCRIPTION/CONTENTS

ABB2 ***** "RUN" COMMAND *****

ABB2 NO INPUT FILE ACTIVE NOW
 ABB7 NO APPLESOFT ERROR NUMBER
 ABB0 GOT PATHNAME1?
 ABBD NO, ERROR >>ABD5
 ABBF YES, LOAD PROGRAM <ABFE>
 ABC2 ERROR? >>AC14
 ABC4 NO, CLEAR VARIABLES <D665>

ABC7 CLEAR ERROR FLAG
 ABC9 POSITION TO LINE NUMBER IF GIVEN <AC97>
 ABCC RESTORE MY INTERCEPTS <9A8D>
 ABCF CLEAR COMMAND NUMBER ETC., MODE = 4 <ABD5>
 ABD2 JUMP INTO APPLESOFT TO RUN PROGRAM >>D7D2

ABD5 ***** CLEAR COMMAND NUMBER ETC. *****

ABD5 SET NORMAL (NON-INVERSE OR FLASH) <F273>
 ABDA SEARCH CHARACTER FOR TRACE IS "#" (9F61)
 ABDF NO COMMAND NUMBER NOW (BE53)
 ABE2 NO PROMPT
 ABE6 SET MODE=4 (DEFERRED) <9F76>
 ABE9 "SYNTAX ERROR" IF THINGS GO WRONG >>A839

ABEC ***** "LOAD" COMMAND *****

ABEC LOAD PROGRAM <ABFE>
 ABEF ERROR? IF NOT, FALL THRU TO WARMSTART >>AC14

ABF1 ***** WARMDS: WARMSTART BI *****

ABF1 CLEAR APPLESOFT, RESET POINTERS <D665>
 ABF4 RESET MODE/SET INTERCEPTS <9A17>
 ABF9 CURSOR HORIZ. = 0 (START OF LINE)
 ABFB GO WARMSTART APPLESOFT >>D43F

ABFE ***** LOAD A PROGRAM *****

ABFE CLOSE ALL OPEN FILES <B4F2>
 AC01 ERROR? >>AC14
 AC03 GO LOAD FILE <AC15>
 AC06 ERROR? >>AC14
 AC08 SET LOMEM = ARRAYS = FREESTART
 AC0A ALL TO END OF PROGRAM LOADED
 AC14 RETURN

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84      NEXT OBJECT ADDR: AC14
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

AC15 ***** READ A PROGRAM FROM A FILE *****

```

```

AC15 READ REQUESTED
AC17 TYPE = BAS ASSUMED
AC19 OPEN THE FILE <B194>
AC1C ERROR? >>AC14
AC20 MLI: GET EOF <BE70>
AC23 ERROR? >>AC14
AC27 APPLESOFT PROGRAM START --> READ DATA (BED7)
AC2A ADD TO THAT THE EOF MARK TO ... (BEC8)
AC2D SET AD PARM --> END OF PROGRAM IMAGE (BE58)
AC3B OVERFLOW? >>AC3F
AC3D NO, WOULD PROGRAM EXCEED HIMEM?
AC3F IF SO...
AC41 "PROGRAM TOO LARGE" >>AC14
AC43 ELSE, PICK UP LENGTH AGAIN (BEC8)
AC49 AND GO READ IT IN <AF98>
AC4C ERROR? >>AC14
AC4E CLOSE FILE <AF94>
AC51 ERROR? >>AC14
AC53 RELOCATE PROGRAM IF NECESSARY <AC61>
AC5C COPY AD PARM TO APPLESOFT PGM END PTR
AC60 RETURN

```

```

AC61 ***** RELOCATE APPLESOFT PROGRAM *****

```

```

---
AC61 WAS APPLESOFT PROGRAM SAVED FROM SAME
AC64 MEMORY LOCATION? (BEB9)
AC73 YES, NOTHING TO DO THEN >>ACBA
AC79 ELSE, LOOP THROUGH PROGRAM
AC7B ADJUSTING ALL ADDRESSES TO
AC7D THE NEW LOAD LOCATION

```

```

AC97 ***** POSITION TO LINE NUMBER *****

```

```

AC97 WAS A LINE NUMBER PARM GIVEN? (BE57)
AC9D NO, NEVER MIND >>ACBA
AC9F COPY L KEYWORD VALUE TO APPLESOFT'S LINE # (BE68)
ACA9 THEN CALL APPLESOFT TO FIND THE LINE <D61A>
ACAF SUBTRACT ONE FROM THE ADDRESS
ACB1 AND POINT APPLESOFT'S GETCHR SUBROUTINE
ACB3 AT IT (SO NEXT CHAR READ WILL BE FIRST
ACB5 CHARACTER ON THE LINE).
ACBA RETURN

```

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84      NEXT OBJECT ADDR: ACBA
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

ACBB ***** "SAVE" COMMAND *****

```

```

ACBB DOES FILE EXIST ALREADY? >>ACDF
ACBD NO, TYPE = BAS
ACBF IN T KEYWORD VALUE (BE6A)
ACC2 AND MLI LIST (BEB8)
ACC7 ALLOW ALL ACCESSES (READ/WRITE/ETC.) (BEB7)
ACCC SAVE PROGRAM START ADDRESS IN (BEA5)
ACCF AUXID'S (BEB9)
ACDA GO CREATE A NEW FILE <AD46>
ACDD ERROR? >>AD28

ACDF WRITE ACCESS REQUESTED
ACE1 BAS TYPE FILE
ACE3 OPEN IT <B194>
ACE6 ERROR? >>AD28
ACEB SUBTRACT APPLESOFT PTRS TO COMPUTE
ACED LENGTH OF PROGRAM.
ACEE STORE THIS IN EOF MARK LIST (BEC8)
ACFB MSB OF EOF MARK IS 00 (<64K PGM) (BECA)
AD00 POINT LIST TO PROGRAM AS DATA TO WRITE (BED7)
AD08 WRITE A RANGE TO DISK FILE <AF9C>
AD0B ERROR? >>AD28
AD0F MLI: SET EOF (TO TRUNCATE OLD LONGER FILE) <BE70>
AD12 ERROR? >>AD28
AD14 CLOSE THE FILE <AF94>
AD17 ERROR? >>AD28
AD1B DOES PROGRAM START MATCH AUXID IN FILE INFO?
AD20 NO, CHANGE IT >>AD29
AD28 ELSE, EXIT

AD29 TO CHANGE IT, (BEB9)
AD2F EXIT THRU SET FILE INFO ROUTINE >>B7D9

```

```

AD32 ***** "CREATE" COMMAND *****

```

```

AD32 AUXID = 0 (A$ OR RECLN)
AD3D TYPE KEYWORD GIVEN?
AD3F YES >>AD46
AD43 NO, ASSUME TYPE = DIR (BE6A)

AD46 *** CREATE FILE ENTRY *** (BE43)
AD49 EXEC FILE ACTIVE?
AD4C HOW MANY FILES ARE OPEN INCLUDING EXEC? (BE4D)
AD4F 8 OR MORE?
AD51 YES, ERROR >>AD6E
AD56 ELSE, SET TYPE IN MLI LIST (BEA4)
AD59 FULL ACCESS (READ/WRITE/ETC.)
AD5B KIND = STANDARD FILE
AD5D DIR FILE WANTED?

```

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84      NEXT OBJECT ADDR: AD5F
-----
ADDR  DESCRIPTION/CONTENTS
-----
AD5F NO >>AD63
AD61 YES, KIND = DIR FILE
AD63 SET ACCESS (BEA3)
AD66 AND KIND (BEA7)
AD6B MLI: CREATE (DON'T COME BACK HERE) >>BE70
AD6E "RAM TOO LARGE" ERROR
AD70 RETURN
AD71 ***** "RENAME" COMMAND *****
AD71 ----
AD75 SECOND PATHNAME GIVEN?
AD78 IF SO, GO MLI: RENAME >>AD7F
AD7A "SYNTAX ERROR" OTHERWISE >>A839
AD7D ***** "DELETE" COMMAND *****
AD7D SETUP MLI: DELETE CALL TYPE
AD7F EXIT THRU MLI CALL >>BE70
AD82 ***** "LOCK" COMMAND *****
AD82 GET FILE INFO FOR PATHNAME1 <B7D0>
AD85 GET ACCESS CODES (BEB7)
AD88 TURN OFF ALL...
AD8A BUT READ
AD8F THEN GO SET UPDATED FILE INFO >>B7E7
AD92 ***** "UNLOCK" COMMAND *****
AD92 GET FILE INFO FOR PATHNAME1 <B7D0>
AD95 TURN ON ALL FILE ACCESSES
AD9D THEN GO SET UPDATED FILE INFO >>B7E7
ADA0 ***** "PREFIX" COMMAND *****
ADA0 SLOT/DRIVE GIVEN ON COMMAND? (BE57)
ADA6 IF SO, GOT OPERAND ALREADY >>ADAC
ADA8 ELSE, (BE56)
ADAB CHECK FOR PATHNAME1
ADAC AND GO DO MLI: SET PREFIX ...
ADAE IF IT'S THERE >>AD7F
ADB0 ELSE, IS BASIC PROGRAM RUNNING?
ADB2 IF SO, SET PREFIX ACTIVE FLAG >>ADD1
ADB4 NO, NEW LINE <9FAB>
ADBC END OF NAME YET? >>ADC9
ADBE NO, COPY NAME IN PATHNAME1 BUFFER (BCBD)
ADC3 TO OUTPUT DEVICE <9FAD>
ADC9 AND SKIP A BLANK LINE <9FAB>
ADD0 DONE

```

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84      NEXT OBJECT ADDR: ADD0
-----
ADDR  DESCRIPTION/CONTENTS
-----
ADD1 SET PREFIX ACTIVE FLAG
ADD3 SO BASIC CAN READ THE PREFIX (BE46)
ADD7 RETURN
ADD8 ***** "BSAVE" COMMAND *****
ADD8 PATHNAME1 FOUND? >>AE0E
ADD8 NO, NEW FILE (BE57)
ADD8 AD, L, AND E POSSIBLE
ADD8 AD AND EITHER L OR E REQUIRED
ADE1 OR ELSE ERROR >>AE12
ADE6 PUT AD IN CREATE PARAMETER LIST (BEA5)
ADE9 AND IN GET FILE INFO LIST (BEB9)
ADF7 TYPE = BIN ASSUMED (BE6A)
AE00 T KEYWORD GIVEN?
AE02 IF SO, ERROR >>AE12
AE04 GO CREATE THE FILE <AD46>
AE07 ERROR? >>AE14
AE09 GET FILE INFO <B7D0>
AE0C ERROR? >>AE14
AE0E WRITING...
AE10 GO PROCESS LIKE A BLOAD OTHERWISE >>AE25
AE12 "PATH NOT FOUND" ERROR
AE14 ---
AE15 RETURN
AE16 ***** "BRUN" COMMAND *****
      (DOES NOT SET MODE=4 SO DOS COMMANDS MAY
      NOT BE ISSUED AS WITH A BASIC PROGRAM)
AE16 BLOAD IT FIRST <AE23>
AE19 ERROR? >>AE14
AE1B THEN CALL IT <AE20>
AE1E THEN EXIT
AE1F RETURN
AE20 INDIRECT JMP TO BINARY PROGRAM >>BED7
AE23 ***** "BLOAD" COMMAND *****
AE23 READING...
AE25 TYPE = BIN
AE27 OPEN THE FILE <B194>
AE2A ERROR? >>AE14
AE2C ASSUME USER SPECIFIED AD KEYWORD (BE58)
AE35 IF SO, USE HIS ADDRESS >>AE47
AE37 ELSE, USE AD IN FILE INFO AUXID (BEB9)
AE40 WAS T KEYWORD GIVEN?
AE42 YES, INVALID PARAM (ONLY BIN IS LEGAL) >>AE78
AE47 POINT READ/WRITE PARAMS TO DATA (BED7)

```

BASIC Interpreter (BI) -- v1.1 --1B JUN B4 NEXT OBJECT ADDR: AE4D

ADDR DESCRIPTION/CONTENTS

```

AE4D PICK UP LENGTH FROM L KEYWORD VALUE (BE5F)
AE53 WAS L OR E GIVEN?
AE55 NEITHER >>AE7C
AE57 BOTH?
AE59 YES...NAUGHTY! >>AE7B
AE5B E GIVEN?
AE5D NO, MUST BE L >>AE92
AE5F YES... (BE5D)
AE63 COMPUTE L = (E - AD) (BE58)
AE6F PLUS ONE FOR INCLUSIVE RANGE >>AE72
AE72 MAKE SURE NO BORROW OCCURED >>AE92

AE74 OR ELSE, "RANGE ERROR"
AE77 RETURN

AE7B "INVALID PARAM" ERROR
AE7B RETURN

AE7C ---
AE7E MLI: GET EOF <BE70>
AE81 ERROR? >>AE90
AE83 GET L (EOF MARK) (BEC8)
AE89 BETTER NOT EXCEED 64K (BECA)
AE8C NO.. >>AE92

AE8E YES, "PROGRAM TOO LARGE"
AE90 ---
AE91 RETURN

AE92 STORE LENGTH TO READ OR WRITE (BED9)
AE9B B KEYWORD GIVEN?
AE9D NO >>AEC4
AEA1 YES, COPY B VALUE TO SET MARK LIST (BE5A)
AEAA ---
AEB0 MLI: SET MARK <BE70>
AEB2 NO ERROR? >>AEC4
AEB4 ERROR, RANGE ERROR?
AEB6 NO >>AE90
AEB8 BSAVING (NOT BLOAD/BRUNING)?
AEBE NO >>AE90
AEBE MLI: FORCE EOF FORWARD TO MARK <BE70>
AEC1 AND TRY SET MARK AGAIN >>AEAA
AEC3 RETURN
AEC4 GET COMMAND NUMBER (BE53)
AEC7 ASSUME READ
AEC9 BSAVE?
AECB NO, READ IS CORRECT >>AECF
AECF WRITING
AECF MLI: READ OR WRITE <BE70>
AED2 ERROR? >>AE90
AED4 THEN EXIT THRU CLOSE >>AF94

```

BASIC Interpreter (BI) -- v1.1 --18 JUN 84 NEXT OBJECT ADDR: AED4

ADDR DESCRIPTION/CONTENTS

```

AED7 ***** "STORE" COMMAND *****
AED7 PATHNAME1 EXISTS? >>AEEB
AED9 NO, T = VAR BY DEFAULT
AEE1 FULL ACCESS (READ/WRITE/ETC.)
AEE6 CREATE THE FILE <AD46>
AEE9 ERROR? >>AF39
AEEB COMPRESS APPLESOFT VARS AGAINST HIMEM <A40D>
AEF4 OPEN "VAR" FILE FOR WRITE <B194>
AEF7 ERROR? >>AF32
AEF9 POINT TO INTERNAL 5 BYTE HEADER BUFFER <AF3A>
AEFC AND WRITE OUT LENGTHS OF VARS <AF9C>
AEFF ERROR? >>AF32
AF01 STORE ADDRESS OF VARS (BCBE)
AF04 IN READ/WRITE PARAM LIST (BED7)
AF07 AND FILE INFO AUXID (BEB9)
AF13 GET LENGTH OF VARS (BC91)
AF19 AND WRITE THEM OUT <AF9C>
AF1C ERROR? >>AF32
AF20 MLI: GET MARK <BE70>
AF25 MLI: SET NEW EOF (TRUNCATE IF NECESSARY) <BE70>
AF28 ERROR? >>AF32
AF2A SET FILE INFO WITH AD OF VARS <B7D9>
AF2D ERROR? >>AF32
AF2F CLOSE FILE <AF94>
AF32 ---
AF34 REEXPAND VARS BACK AGAIN <A472>
AF39 RETURN

AF3A ***** SETUP TO READ/WRITE VAR HDR *****
      APPLESOFT VARIABLES HEADER CONSISTS OF:
      2 BYTE LENGTH OF SIMPLE+ARRAY VARIABLES
      2 BYTE LENGTH OF SIMPLE VARIABLES ONLY
      1 BYTE MSB OF HIMEM FOR THESE VARIABLES

AF3A STORE ADDRESS OF 5 BYTE INFO
AF3C IN READ/WRITE PARAM LIST (BED7)
AF46 LENGTH = 5
AF48 RETURN

AF49 ***** "RESTORE" COMMAND *****
AF49 TYPE = VAR
AF4B READING
AF4D OPEN THE FILE <B194>
AF50 ERROR? >>AF39
AF52 SET UP TO READ THE HEADER <AF3A>
AF55 READ 5 BYTE HEADER <AF98>
AF58 ERROR? >>AF39
AF5A PICK UP WHERE TO READ IN COMPRESSED VARS (BEB9)

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: AF5D

ADDR DESCRIPTION/CONTENTS

AF5D FROM AUXID (BC8E)
 AF63 ADJUST MSB OF THIS BY THE DIFFERENCE
 AF66 BETWEEN HIMEM'S (NOW AND WHEN STORED) (BC8D)
 AF73 MAKE SURE VARS WON'T OVERLAY PROGRAM
 AF75 IF SO, ERROR >>AF90
 AF7F COMPUTE LENGTH OF ALL VARS/STRINGS
 AF81 (HIMEM-START) (BC8F)
 AF85 GO READ COMBINED VARS INTO MEMORY <AF98>
 AF88 ERROR? >>AF39
 AF8A CLOSE THE FILE <AF94>
 AF8D EXIT BY REEXPANDING THE VARS DOWN >>AF32
 AF90 "PROGRAM TOO LARGE" ERROR
 AF93 RETURN

AF94 ***** CLOSE FILE *****

AF94 SET MLI CLOSE OPCODE
 AF96 AND GO TO MLI >>AFA4

AF98 ***** READ/WRITE A RANGE *****

AF98 READ MLI OPCODE
 AF9A JUMP IN >>AF9E
 AF9C WRITE MLI OPCODE
 AF9E STORE LENGTH (BEDA)
 AFA4 EXIT THRU MLI:READ OR WRITE >>BE70

AFA7 ***** "PR#" COMMAND *****

AFA7 USE CSWL AND OUTVEC
 AFAC JUMP TO COMMON CODE >>AFB5

AFAE ***** "IN#" COMMAND *****

AFAE USE KSWL
 AFB3 AND INVEC
 AFB5 OR IN SLOT GIVEN BY USER (BE6B)
 AFB8 *2 FOR USE AS INDEX INTO TABLE
 AFBF WAS SLOT PARAMETER GIVEN?
 AFBF NO... >>AFD2
 AFBF YES, (BE57)
 AFC4 AD GIVEN? >>AFE7
 AFC6 NO, GET INVEC OR OUTVEC FOR THIS SLOT (BE10)
 AFC9 AND STORE ON AD KEYWORD VALUE (BE58)
 AFD2 VALIDITY CHECK I/O DRIVER <AFF9>
 AFD5 NO GOOD? >>AFE6
 AFD7 GET INDEX TO CSWL OR KSWL (BCA9)
 AFD0 AND REPLACE ONE OR THE OTHER WITH (0036)
 AFE0 HIS ADDRESS (BE59)

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: AFE6

ADDR DESCRIPTION/CONTENTS

AFE6 RETURN
 AFE7 VALIDITY CHECK AD KEYWORD VALUE <AFF9>
 AFEA NO GOOD? >>AFF8
 AFEC GOOD, COPY VALUE TO INVEC OR OUTVEC (BE59)
 AFF8 EXIT BUT DON'T REDIRECT I/O NOW
 AFF9 ***** VALIDITY CHECK I/O DRIVER *****
 AFF9 \$3A/3B --> NEW HANDLER (FROM AD PARM) (BE58)
 B005 IS DRIVER IN MAIN RAM (BELOW \$C000)?
 B007 YES >>B01E
 B009 NO, RESET I/O CARD ROMS (CFFF)
 B00C USE \$3C TO COUNT ITERATIONS
 B00E TEST ROM AT USER'S ADDRESS
 B014 FOR STABILITY
 B018 256 TIMES
 B01C MUST BE OK
 B01D RETURN
 B01E MAIN RAM I/O DRIVER
 B020 MUST START WITH A "CLD" INSTRUCTION
 B022 OK... >>B01C
 B024 ELSE, "NO DEVICE CONNECTED"
 B027 RETURN
 B028 ***** "BYE" COMMAND *****
 B028 CLOSE ANY OPEN FILES <B4F2>
 B02B CLOSE EXEC FILE, IF ANY <B2FB>
 B030 MLI CALL: <BF00>
 B033 QUIT
 B034 USE READ PARMLIST BECAUSE QUIT DOESN'T NEED PARMS.

B036 ***** "CAT" COMMAND *****

B036 39 CHARACTERS PER LINE
 B038 THEN PROCESS LIKE "CATALOG" >>B03C

B03A ***** "CATALOG" COMMAND *****

B03A 79 CHARACTERS PER LINE
 B03C STORE LINE LENGTH (BCB6)
 B042 TEST FOR T AND
 B044 ...PATHNAME1 GIVEN
 B045 GOT T >>B04A
 B047 NO T, T=0 (ANY TYPE WILL DO) (BE6A)
 B04A GOT PATHNAME1 >>B051
 B04C NO PATHNAME1, GET FILE INFO FOR PREFIX <B7D0>
 B04F ERROR? >>B0B7
 B051 OPEN/READ DIRECTORY HEADER <B14A>

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B054

ADDR DESCRIPTION/CONTENTS

```

B054 ERROR? >>B0B7
B056 SKIP TO A NEW LINE <9FAB>
B059 FORMAT DIRECTORY'S NAME TO $201 <B0B8>
B05C PRINT $201 <9F9D>
B05F SKIP TO A NEW LINE <9FAB>
B062 BLANK $201 BUFFER <A66C>
B067 UNPACK HEADING MESSAGE LINE <9FB0>
B06A PRINT IT (40 OR 80 COLUMNS) <9F9D>
B06D SKIP TO A NEW LINE <9FAB>
B073 ANY FILES IN THIS DIRECTORY? (BCBA)
B076 NO >>B0A3
B078 YES, READ NEXT ENTRY <B1D1>
B07B ERROR? >>B0B7
B07D GET TYPE REQUESTED FOR SEARCH (BE6A)
B080 ANY TYPE WILL DO? >>B0B7
B082 NO, CHECK TYPE AGAINST THIS ENTRY (0269)
B085 NOT IT, SKIP IT >>B0B8D
B087 ELSE, FORMAT ENTRY TO $201 <A4C4>
B08A AND PRINT $201 <9F9D>
B08D CHECK KEYBOARD (C000)
B090 FOR A CONTROLL-C
B092 IGNORE ANYTHING ELSE >>B09E

B094 CONTROL-C, WHAT STATE ARE WE IN? (BE42)
B097 DEFERRED >>B0A3
B099 NO, IMMEDIATE, RESET KEYBOARD STROBE (C010)
B09C AND EXIT RIGHT NOW >>B0A3

B09E ELSE, ANY FILES LEFT IN COUNT? (BCBA)
B0A1 YES, CONTINUE >>B078
B0A3 ELSE, CLOSE DIRECTORY <AF94>
B0A6 ERROR? >>B0B7
B0A8 SKIP TO A NEW LINE <9FAB>
B0AB FORMAT BLOCKS FREE AND IN USE TO $201 <B0E7>
B0AE ERROR? >>B0B7
B0B0 PRINT $201 <9F9D>
B0B3 SKIP A LINE <9FAB>
B0B7 DONE

```

B0B8 ***** FORMAT NAME OF DIRECTORY *****

```

B0B8 BLANK $201 BUFFER <A66C>
B0BB FILE NAME IS AT +1 INTO DIR ENTRY
B0BD GET NAME LENGTH/TYPE (025D)
B0C2 VOLUME DIRECTORY HEADER?
B0C4 NO >>B0CA
B0C6 YES, START NAME WITH "/" (0200)
B0CA ---
B0CB ISOLATE NAME LENGTH FROM TYPE
B0CD AND SET UP LENGTH TO COPY (0200)
B0D2 COPY DIRECTORY NAME TO (0259)

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B0D7

ADDR DESCRIPTION/CONTENTS

```

B0D7 ...LINE (0200)
B0E1 SET $200 TO MAXIMUM LENGTH
B0E6 RETURN

B0E7 ***** FORMAT BLOCKS FREE/INUSE *****
POINT MLI:ONLINE PARMLIST
B0E7 TO TXTBUF (PATHNAME1) (BEC8)
B0E9 COPY DEVICE NUMBER (UNIT) (BF30)
B0F1 MLI: ONLINE <BE70>
B0F9 ERROR? >>B0B7
B0FC ISOLATE NAME LENGTH FROM BUFFER
B101 BUMP BY ONE TO INCLUDE "/"
B104 AND STORE IT AS A PREFIX (BCBC)
B105 STORE "/" AS FIRST CHARACTER (BCBD)
B10A GET FILE INFO FOR PREFIX <B7D0>
B110 ERROR? >>B0B7
B112 UNPACK $201 BUFFER <A66C>
B117 UNPACK "BLOCKS FREE: BLOCKS USED.." <9FB0>
B11A ZERO THE THREE BYTE ACCUM <AB37>
B125 CONVERT AUXID (TOTAL BLOCKS) <A62F>
B130 CONVERT BLOCKS USED <A62F>
B137 BLOCKS FREE = TOTAL BLOCKS (BEBE)
B13E ... - BLOCKS USED (BEDD)
B145 CONVERT BLOCKS FREE <A62F>
B149 DONE!

```

B14A ***** OPEN/READ DIRECTORY HDR *****

```

B14A READ ONLY
B14E CHECK FILE KIND (BEBB)
B151 VOLUME DIRECTORY?
B153 NO >>B158
B155 YES, TYPE = DIR (BEB8)
B158 OPEN THE FILE <B1A0>
B15B ERROR? IF NOT, FALL THRU >>B193

```

B15D ***** READ DIRECTORY HDR *****

```

B15D BUFFER IS $259
B169 LENGTH IS $2B (ONE ENTRY) (BED9)
B173 MLI: READ <BE70>
B176 ERROR? >>B193
B17A COPY ENTRY LENGTH, ENTRIES PER BLOCK, (027C)
B17D AND FILE COUNT FROM DIR HDR (BCB7)
B183 STORE ENTRY LENGTH IN READ LENGTH NOW (BED9)
B188 SET COUNTER TO FIRST ENTRY IN BLOCK (BCBB)
B18D MARK = 0 (START OF FILE) (BEC9)
B193 RETURN

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B193

 ADDR DESCRIPTION/CONTENTS

B194 ***** OPEN FILE *****
 A REGISTER = ACCESS BITS
 X REGISTER = DEFAULT TYPE

 B194 T KEYWORD GIVEN?
 B19A NO >>B19F
 B19C YES, USE KEYWORD VALUE INSTEAD (BE6A)
 B19F

 B1A0 EXISTING FILE OF THIS TYPE? (BEB8)
 B1A3 NO, ERROR >>B1C9
 B1A5 CHECK ACCESS REQUESTED (BEB7)
 B1A8 REQUESTED ACCESS NOT PERMITTED >>B1CD
 B1AA SET SYSTEM BUFFER IN OPEN PARM LIST (BC88)
 B1B2 LEVEL = \$0F (BF94)
 B1B7 MLI: OPEN <BE70>
 B1BA ERROR? >>B1C8
 B1BF SAVE REFNUM IN READ/WRITE PARMLIST (BED6)
 B1C2 AND CLOSE PARMLIST (BEDE)
 B1C5 AND GET/SET EOF/MARK LIST (BEC7)
 B1C8 AND EXIT

B1C9 "FILE TYPE MISMATCH"
 B1CC RETURN
 B1CD "FILE LOCKED"
 B1D0 RETURN

B1D1 ***** READ NEXT DIRECTORY ENTRY *****

B1D1 FORCE MARK TO START OF THIS BLOCK (BEC9)
 B1D9 CHECK ENTRY NUMBER (BCBB)
 B1DE LAST ENTRY IN THIS BLOCK? (BCB8)
 B1E1 NO >>B1ED
 B1E4 YES, ENTRY 0 NEXT TIME (BCBB)
 B1E7 BUMP MARK TO NEXT BLOCK (BEC9)
 B1ED

 B1EF MARK POSITIONED TO PROPER ENTRY YET? >>B1F8
 B1F1 NO, BUMP POINTER TO NEXT ENTRY (BCB7)
 B1F4 AND CONTINUE IF STILL FIRST PAGE >>B1ED
 B1F6 JUST ENTERED SECOND PAGE >>B1EA
 B1F8 ADD 4 TO PTR TO ADJUST FOR BLOCK PREFIX
 B1FF MLI: SET MARK <BE70>
 B202 ERROR? >>B21D
 B206 MLI: READ <BE70>
 B209 ERROR? >>B21D
 B20B BUMP ENTRY COUNTER (BCBB)
 B211 IS THIS ENTRY VALID?
 B213 NO, SKIP OVER IT >>B1D1
 B215 DECREMENT FILE COUNT (BCB9)
 B21D AND RETURN TO CALLER

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B21D

 ADDR DESCRIPTION/CONTENTS

B21E ***** EXTERNAL COMMAND HANDLER *****

B21E INDIRECT JMP TO XTRNAD VECTOR >>BE50

B221 ***** "EXEC" COMMAND *****

B221 IS THIS FILE OPEN ALREADY? <B41F>
 B224 NO >>B250
 B226 YES, EXEC CLOSING? (BE4E)
 B229 NO >>B24C
 B22B SAVE REFNUM (BEC7)
 B230 RESET MARK TO ZERO (BEC8)
 B23B MLI: SET MARK <BE70>
 B23E ERROR? >>B245
 B240 GET REFNUM AGAIN (BEC7)
 B243 GO RESTART THIS EXEC FILE FROM ITS START >>B2C3

***** CLOSE EXEC FILE *****

B245 PRESERVE CALLER'S AREG
 B246 AND CLOSE THE FILE <B2FB>
 B24B THEN RETURN WITH ERROR

B24C "FILE BUSY" ERROR
 B24F RETURN

***** CONTINUE EXEC SETUP *****

B250 EXEC ACTIVE? (BE43)
 B253 NO >>B25A
 B255 YES, CLOSE IT <B2FB>
 B258 ERROR? >>B263
 B25A GET FILE TYPE (BEB8)
 B25D SHOULD BE TXT
 B25F IT IS >>B265
 B261 ELSE, "FILE TYPE MISMATCH"
 B263 RETURN WITH ERROR
 B264 RETURN
 B265 MOVE STRINGS TO MAKE ROOM FOR A BUFFER <A1F5>
 B268 NO ROOM? >>B263
 B26C STORE NEW BUFFER ADDRESS IN PARM LIST (BEC8)
 B275 GET COUNT OF OPEN FILES (BE4D)
 B278 NO OTHERS CURRENTLY OPEN? >>B29E

BASIC Interpreter (BI) --- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B278

ADDR DESCRIPTION/CONTENTS

***** MAKE EXEC TOPMOST BUFFER *****

B27A OTHERS ARE OPEN...
 B27C OPENCOUNT*4 (4 PAGES PER BUFFER)
 B27E ADD THIS TO MY BUFFER TO FIND TOP BUFFER (BC88)
 B282 SEARCH OPEN FILES TO FIND THE FILE WHICH (BC93)
 B285 IS USING THIS BUFFER... >>B28B
 B28A IF IT IS NOT FOUND, BREAK!
 B28B ---

B28C MOVE THAT FILE TO THE NEW BUFFER INSTEAD (BC93)
 B28F GET THAT FILE'S REFNUM ALSO (BC9B)
 B297 MLI: SET BUFF <BE70>
 B29A NO ERRORS? >>B29D
 B29C IF ERROR, BREAK!
 B29D ---

***** OPEN NEW EXEC FILE *****

B29E SET NEW BUFFER ALLOCATION PAGE (BC88)
 B2A1 SET UP OPEN LIST FOR EXEC TOO (BECF)
 B2A6 LEVEL = 0 (BF94)
 B2AB MLI: OPEN (EXEC FILE) <BE70>
 B2AE NO ERROR? >>B2B7

 IF ERROR, FREE BUFFER FIRST <A24C>
 THEN EXIT WITH ERROR

B2B7 SAVE BUFFNO FOR EXEC (BECF)
 B2BD AND REFNUM TOO (BED0)

***** COMPLETE EXEC COMMAND *****

B2C3 SAVE READ REFNUM (BED6)
 B2C6 AND GET/SET REFNUM (BEC7)
 B2C9 AND NEWLINE REFNUM (BED2)
 B2CF SET "L" VALUE FROM AUXID (BE5F)
 B2D8 SAVE PATHNAME/AUXID IN OPEN FILE TABLE <B3EB>
 B2DD IGNORE MSB FOR END OF LINE CHARS (BED3)
 B2E2 MLI: SET NEWLINE <BE70>
 B2E8 WAS "F" OR "R" GIVEN ON COMMAND LINE?
 B2EA NO >>B2F4
 B2EC YES, POSITION TO SPECIFIED STARTING PT <B522>
 B2EF NO ERRORS? >>B2F4
 B2F1 IF ERROR, GO CLOSE EXEC >>B245
 B2F4 MARK EXEC ACTIVE
 B2FA AND RETURN TO CALLER

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B2FA

ADDR DESCRIPTION/CONTENTS

B2FB ***** CLOSE EXEC FILE *****

B2FB EXEC ACTIVE? (BE43)
 B2FE NO, SKIP IT >>B30B
 B300 INDICATE EXEC FILE CLOSING (BE4E)
 B305 PICK UP REFNUM FOR EXEC (BC9B)
 B308 AND GO CLOSE IT <B4A5>
 B30B RETURN

B30C ***** "VERIFY" COMMAND *****

B30C FILE NOT FOUND? >>B347
 B311 FILE FOUND, WAS A PATHNAME1 GIVEN?
 B313 YES >>B31D
 B315 NO,
 B317 PRINT "(C) APPLE COMPUTER..." <9F8C>
 B31A AND A NEW LINE <9FAB>
 B31D THEN EXIT
 B31E RETURN

B31F ***** FLUSH ALL OPEN FILES *****

B31F REFNUM = 0 (ALL FILES)
 B321 JUMP INTO FLUSH >>B32F

B323 ***** "FLUSH" COMMAND *****

 B323 WAS PATHNAME1 GIVEN?
 B326 NO, FLUSH ALL FILES >>B32F
 B32A ELSE, LOOK UP NAME IN OPEN FILE LISTS <B41F>
 B32D NOT AN OPEN FILE >>B337
 B32F SAVE REFNUM IN PARM LIST (BEDE)
 B334 MLI: FLUSH <BE70>
 B337 EXIT

B338 ***** "OPEN" COMMAND *****

 B338 LOOK UP NAME IN OPEN FILE LIST <B41F>
 B339 NOT CURRENTLY OPEN? >>B34B

 B33E IT IS OPEN, "FILE BUSY" ERROR
 B33F
 B342 RETURN

BASIC Interpreter (BI) -- V1.1 --1B JUN B4 NEXT OBJECT ADDR: B342

ADDR DESCRIPTION/CONTENTS

```

B343 "FILE TYPE MISMATCH" ERROR
B346 RETURN

B347 "PATH NOT FOUND" ERROR
B349 ---
B34A RETURN

B34B ---
B34C ASSUME "L" IS ZERO
B353 WAS "L" KEYWORD GIVEN?
B355 YES, USE HIS VALUE >>B35D
B357 NO, SET "L" TO ZERO (BE60)
B360 WAS "T" GIVEN?
B364 YES, USE HIS TYPE >>B36B
B366 ELSE, DEFAULT TO "TXT"
B36B DOES THE FILE ALREADY EXIST? >>B3BE
B36D NO, "T" GIVEN? IF SO, ERROR >>B347
B36F FORCE TYPE = "TXT" (BEBB)
B374 FULL ACCESS (BEB7)
B37A COPY "L" KEYWORD VALUE (BE5F)
B37D TO CREATE (BEA6)
B380 AND SET FILE INFO LISTS (BEBA)
B389 GO CREATE THE FILE <AD46>
B38C ERROR? >>B349
B38E CHECK FILE TYPE (BEBd)
B391 AGAINST HIS "T" VALUE (BE6A)
B394 MISMATCH? >>B343
B396 NO, TYPE = TXT?
B39B NO >>B3AD
B39A YES, GET RECORD LENGTH FROM AUXID (BEBA)
B3A3 WAS "L" KEYWORD VALUE GIVEN?
B3A5 YES, USE THAT INSTEAD >>B3AD
B3A7 OTHERWISE, SAVE AUXID RECORD LEN (BE60)
B3AD ALLOCATE A NEW FILE BUFFER <A1F5>
B3B0 ERROR? >>B349
B3B2 GET BUFFER PAGE NO. (BCB8)
B3B5 AND STORE IN OPEN LIST (BE6F)
B3BA LEVEL = 7 (BF94)
B3BF MLI: OPEN <BE70>
B3C2 NO ERRORS? >>B3CB

B3C4 ---
B3C5 ERROR, FREE BUFFER FIRST <A24C>
B3CA THEN EXIT WITH ERROR CODE

B3CB CHECK FILE TYPE AGAIN (BEB8)
B3CE "DIR" FILE?
B3D0 YES >>B3D3
B3D2 NO
B3D3 ---

```

BASIC Interpreter (BI) -- V1.1 --18 JUN B4 NEXT OBJECT ADDR: B3D6

ADDR DESCRIPTION/CONTENTS

```

B3D6 SET DIR FLAG ACCORDINGLY (BE47)
B3D9 USING OPEN COUNT AS AN INDEX (BE4D)
B3DF STORE BUFFER LOCATION IN OPEN FILE LIST (BC94)
B3E5 ALSO, THE REFNUM (BC9C)
B3E8 AND BUMP OPEN FILE COUNT AND FALL THRU (BE4D)

B3EB ***** SAVE FILE NAME/RECLN IN TABLE *****

B3EB MAKE INDEX FROM REFNUM*32 BYTES
B3F1 GET NAME LENGTH (02B0)
B3F4 OR IN DIR FLAG (BE47)
B3F7 AND STORE IN OPEN FILE NAME LIST (BCFE)
B3FD NAME > OR = TO 30 BYTES?
B3FF NO... >>B403
B401 YES, USE 29
B403 STORE THAT AS A LOOP COUNTER
B408 COPY "L" KEYWORD VALUE TO NAME LIST TOO (BCFF)
B411 ---
B412 COPY FILE NAME TO NAME LIST (0280)
B41B COPY ALL OF NAME, THEN FALL THRU TO EXIT >>B411

B41D ***** "MON" AND "NOMON" COMMANDS *****

B41D IGNORE THESE COMMANDS AND
B41E RETURN TO CALLER

B41F ***** LOOKUP OPEN FILENAME *****
      (RETURNS REFNUM OF OPEN FILE)

B41F ---
B422 WAS PATHNAME1 GIVEN?
B424 YES >>B42A

B426 NO, "SYNTAX ERROR"
B429 EXIT WITH ERROR

B42A ANY FILES CURRENTLY OPEN? (BE4D)
B42D NO, CAN'T FIND IT THEN >>B44B
B42F YES, CLEAR EXEC FILE CLOSING FLAG (BE4E)
B432 STORE FILE COUNT AS LOOP COUNTER
B434 GET NEXT REFNUM (BC9B)
B437 COMPARE FILENAMES <B462>
B43A NOT THE ONE? >>B443
B43C ELSE, WE'VE GOT IT!
B43E PICK UP APPROPRIATE REFNUM (BC9B)
B441 ---
B442 AND RETURN WITH IT
B443 ELSE, NOT IT, TRY NEXT ONE
B446 AND CONTINUE LOOPING >>B432

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B446

ADDR DESCRIPTION/CONTENTS

B448 CAN'T FIND IT, IS EXEC ACTIVE? (BE43)
 B44B NO, THEN WE MUST GIVE UP >>B45E
 B450 IS HE LOOKING FOR EXEC FILE? <B462>
 B453 NO, GIVE UP >>B45E
 B457 YES, EXEC FILE CLOSING (BE4E)
 B45C AND RETURN WITH EXEC'S REFNUM >>B43E

B45E "FILE NOT OPEN" ERROR
 B461 RETURN WITH ERROR CODE

B462 ***** COMPARE FILENAMES *****

B462 REFNUM*32 FOR FILENAME INDEX
 B468 PICK UP DIR FLAG FROM THIS ENTRY (BCFE)
 B470 SAME LENGTH AS HIS FILENAME? (0280)
 B473 NO, CAN'T BE IT THEN >>B498
 B476 MAKE SURE LENGTH DOES NOT EXCEED 29
 B47A IF IT DOES, ONLY LOOK AT FIRST 29
 B47C USE \$3A AS LOOP COUNTER
 B481 COPY "L" OF THIS FILE TO KEYWORD (BCA4)
 B48A ---
 B48B COMPARE NAMES (0280)
 B491 NO MATCH? EXIT WITH Z FLAG CLEAR >>B498
 B498 MATCH, EXIT WITH Z FLAG SET

B499 ***** "CLOSE" COMMAND *****

 B499 PATHNAME1 GIVEN?
 B49C NO, CLOSE ALL FILES >>B4F2
 B4A0 YES, LOOK IT UP IN OPEN FILE TABLES <B4IF>
 B4A3 NOT FOUND? >>B441
 B4A5 FOUND IT, STORE REFNUM IN CLOSE LIST (BEDE)
 B4AB MARK BUFFER PAGE FREE (BC88)
 B4AE EXEC CLOSING? (BE4E)
 B4B1 YES...NO NEED TO COMPRESS LISTS >>B4CF
 B4B3 GET OPEN COUNT (LAST OPENED FILE NO.) (BE4D)
 B4B7 SWAP BUFFERS (BC93)
 B4C5 AND REFNUMS WITH THE LAST OPENED FILE (BC9B)
 B4CF ---
 B4D1 LEVEL = 0 (BF94)
 B4D6 MLI: CLOSE <BE70>
 B4D9 ERROR? >>B502
 B4DB RELEASE THE BUFFER <A24C>
 B4DE EXEC FILE CLOSING? (BE4E)
 B4E1 NO >>B4EE
 B4E6 YES, EXEC NO LONGER ACTIVE (BE43)
 B4E9 AND NO LONGER CLOSING (BE4E)
 B4ED RETURN TO CALLER

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B4ED

ADDR DESCRIPTION/CONTENTS

B4EE DROP OPEN FILE COUNT (BE4D)
 B4F1 AND EXIT

B4F2 ***** CLOSE ALL OPEN FILES *****

B4F2 ANY FILES OPEN? (BE4D)
 B4F5 NO >>B503
 B4F7 YES, EXEC NOT CLOSING (BE4E)
 B4FD CLOSE LAST FILE OPENED <B4A5>
 B500 IF THAT WORKS, START ALL OVER AGAIN >>B4F2
 B502 EXIT WHEN ALL ARE CLOSED

 B503 SET CLOSE REFNUM TO ZERO (ALL FILES) (BEDE)
 B50A LEVEL = 7 (LEVEL 0 FILES ALREADY CLOSED) (BF94)
 B50F EXIT THRU MLI: CLOSE >>BE70

B512 ***** "POSITION" COMMAND *****

B512 LOOKUP NAME OF FILE <B4IF>
 B515 NOT OPEN? >>B57F
 B517 SET REFNUM IN READ/WRITE PARMLIST (BED6)
 B51A AND SET NEWLINE LIST (BED2)
 B51D DIR FILE? (BE47)
 B520 YES, GET OUT RIGHT NOW! >>B580

"F" OR "R" GIVEN? (BE57)
 B527 NO, INVALID PARM >>B57D
 B529 BOTH GIVEN?
 B52B YES, INVALID PARM >>B57D
 B52D JUST "R" GIVEN?
 B52F NO, JUST "F" >>B53D
 B531 JUST "R", COPY "R" VALUE TO "F" (BE65)
 B534 ("R" AND "F" ARE ALIASES) (BEG3)
 B53D SET COUNT TO 239. (MAXIMUM LINE LEN)
 B54C BUFFER IS AT \$200 (BED8)
 B54F ---
 B551 NEW LINE CHAR IS EITHER \$0D OR \$3D (BED3)
 B556 MLI: SET NEWLINE <BE70>
 B559 ERROR? >>B57F

***** SKIP LINES BY READING THEM *****

 B55B "F" = 0? (BE64)
 B55E YES, DONE >>B580
 B562 ELSE...
 B564 MLI: READ NEXT FIELD (LINE) <BE70>
 B566 ERROR? >>B57F
 B569 DECREMENT "F" VALUE BY ONE

```

BASIC Interpreter (BI) -- VI.1 --I8 JUN 84      NEXT OBJECT ADDR: B57B
-----
ADDR  DESCRIPTION/CONTENTS
-----
B57B AND GO CHECK IT AGAIN >>B55B
B57D "INVALID PARAMETER" ERROR
B57F ---
B580 EXIT TO CALLER

B581 ***** COMPUTE NEW FILE POSITION *****
      (COMPUTES ABSOLUTE FILE POSITION MARK)

B581 ACCUM = CURRENT RECORD LENGTH (BCA4)
B595 MARK = 0 (BEC8)

      ***** MARK = "R" * RECLEN *****

B59E SHIFT "R" VALUE RIGHT (BE66)
B5A6 IF LOW BIT OFF, NO ADD >>B5BF
B5A9 ADD ONE INSTANCE OF RECLEN TO MARK (BCAF)
B5B8 OVERFLOW? >>B5D2
B5BD ACCUM OVERFLOW? >>B5D2
B5BF SCALE ACCUM (MULTIPLIER) UP BY 2 (BCAF)
B5C8 IF "R" NON ZERO... (BE65)
B5CE CONTINUE LOOPING >>B59E
B5D1 ELSE, EXIT TO CALLER

B5D2 "RANGE ERROR"
B5D5 RETURN

B5D6 ***** "READ" COMMAND *****
B5D6 LOOK UP FILE NAME <B41F>
B5D9 NOT OPEN? >>B62B
B5DB ITS OPEN, STORE REFNUM IN READ/WRITE... (BED6)
B5DE GET/SET... (BEC7)
B5E1 AND SET NEWLINE PARMLISTS (BED2)
B5E4 DIR FILE? (BE47)
B5E7 YES, SPECIAL HANDLING REQUIRED >>B62C
B5E9 NO, PRE-POSITION FOR "B", "F", OR "R" <B666>
B5EC ERROR POSITIONING? >>B62B
B5EE ASSUME "L" = 239.
B5F5 "L" GIVEN?
B5F7 NO >>B60C
B5F9 YES, USE HIS "L" VALUE (BE5F)
B5FF UNLESS ITS >256 >>B661
B603 OR >239. >>B661
B607 DOUBLE QUOTE IT SO COMMAS COME THRU (0200)
B60A READ INTO $201
B60C IF NO "L", READ TO $200 (BED7)
B612 NL CHAR = $0D/$0D (OR NONE IF "L") (BED3)
B621 MLI: SET NEWLINE <BE70>
B624 ERROR? >>B62B
B626 ---

B628 MARK INPUT "READ" FILE ACTIVE (BE44)
B62B AND RETURN

      ***** READ DIR FILE *****

B62C SET READ/WRITE LIST REFNUM (BED6)
B62F AND GET/SET LIST REFNUM (BEC7)
B634 READING TO $259 (BED7)
B63E INIT CAT FLAG TO FIRST LINE VALUE (BE4F)
B644 "R" GIVEN?
B647 NO, DONE >>B626
B64B YES, ZERO OUT MARK (BEC8)
B656 MLI: REWIND FILE <BE70>
B659 ERROR? >>B660
B65D MARK INPUT FILE ACTIVE (BE44)
B660 AND EXIT

B661 ***** "RANGE ERROR" *****

B661 "RANGE ERROR" CODE
B665 EXIT TO CALLER

B666 ***** PRE-POSITION FOR I/O *****

      ---
B666 "B", "F", OR "R" GIVEN?
B66B NO, EXIT >>B6AF
B66D "R"?
B66F NO >>B67B
B671 YES, COMPUTE ABSOLUTE POSITION <B581>
B674 ERROR? >>B661
B676 NO, SET MARK TO NEW POSITION <B6A8>
B679 ERROR? >>B6B0
B67B "F" GIVEN? (BE57)
B680 NO >>B687
B682 SKIP LINES UNTIL "F" = 0 <B53D>
B685 ERROR? >>B6B0
B687 "B" GIVEN? (BE57)
B68C NO >>B6AF
B690 MLI: GET MARK <BE70>
B693 ERROR? >>B6B0
B699 ADD "B" VALUE TO CURRENT MARK (BE5A)
B69C (3 BYTE ADD) (BEC8)
B6A6 OVERFLOW? >>B661
B6A8 ---
B6AA MLI: SET MARK <BE70>
B6AD ERROR? >>B6B0
B6AF ---
B6B0 ---
B6B2 EXIT TO CALLER

```

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B6B2

 ADDR DESCRIPTION/CONTENTS

B6B3 ***** "WRITE" COMMAND *****

B6B3 LOOKUP OPEN FILE NAME <B41F>
 B6B6 NOT AN OPEN FILE? >>B6C8
 B6B8 STORE READ/WRITE REFNUM (BED6)
 B6BB AND GET/SET REFNUM (BEC7)
 B6BE AND NEWLINE REFNUM IN PARM LISTS (BED2)
 B6C1 DIR FILE? (BE47)
 B6C4 NO, OK >>B6CA

B6C6 YES, "FILE LOCKED" ERROR
 B6C8 ---
 B6C9 EXIT TO CALLER

B6CA DATA BUFFER AT \$200
 B6D4 PRE-POSITION FOR "B", "F", AND "R" <B666>
 B6D7 NO ERRORS? >>B6ED
 B6D9 WAS ERROR A RANGE ERROR?
 B6DB NO, REAL ERROR >>B6C8
 B6DD YES, MY RANGE ERROR OR MLI'S?
 B6DF MINE... >>B6C8
 B6E1 MLI'S...SET EOF FARTHER INTO FILE
 B6E3 MLI: SET EOF <BE70>
 B6E6 ERROR? >>B6C8

B6E8 AND THEN TRY AGAIN TO SET MARK <B676>
 B6EB ERROR? THEN I GIVE UP >>B6C8
 B6ED BUFFER IS AT HIMEM
 B6F9 INDICATE OUTPUT "WRITE" FILE ACTIVE (BE45)
 B6FD RETURN TO CALLER

B6FE ***** "APPEND" COMMAND *****

B6FE ---
 B6FF LOOK UP NAME IN OPEN FILE LIST <B41F>
 B702 FOUND IT? >>B710
 B705 NO, OPEN IT FIRST <8338>
 B708 ERROR? >>B71E
 B70A NO, REFNUM NON-ZERO? (BED0)
 B70D YES, OK >>B711
 B70F ELSE, BREAK!!!
 B710 ---

B711 REFNUM TO READ/WRITE PARM LIST (BED6)
 B714 AND GET/SET LIST (BEC7)
 B717 DIR FILE? (BE47)
 B71A NO >>B720

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B71A

 ADDR DESCRIPTION/CONTENTS

B71C YES, "FILE LOCKED"
 B71E ---
 B71F EXIT TO CALLER

B720 PICK UP "L" VALUE (BE5F)
 B729 DID USER SPECIFY ONE?
 B72B YES... >>B733
 B72D NO, USE FILE'S CURRENT "L" VALUE (BEB9)
 B733 ---

B738 COMPUTE REFNUM*32 FOR INDEX INTO
 B739 FILE NAME TABLE
 B73E SAVE CURRENT "L" VALUE IN OPEN FILE (BCFF)
 B741 NAME TABLE AND IN CURRENT RECLEN (BCA4)
 B74D MLI: GET EOF <BE70>

B750 ERROR? >>B71E
 B752 IS "L" VALUE < 2? (NO SPECIFIC "L") (BCA5)
 B755 NO >>B75E

B75C YES >>B763
 B75E NO, FORCE TO RECORD BOUNDARY <B766>
 B761 ERROR? >>B71E
 B763 ELSE, GO SET EOF=MARK/OUTPUT FILE ACTIVE >>B6E1

B766 ***** FORCE TO EVEN RECORD BOUNDARY *****
 (FIND RECORD NUMBER OF THIS POSITION)

B766 ---
 B768 COPY EOF TO ACCUM (BEC7)
 B771 CLEAR MSB'S (BCB2)
 B777 GET READY FOR A 24 BIT DIVIDE
 B779 DIVIDE EOF BY... <AAD7>
 B786 RECORD LENGTH (BCA4)
 B79B ---

B7A1 WAS THERE A REMAINDER? (8CB3)
 B7A5 NO, OK... >>B7CF
 B7AB YES, CURRENT RECORD LEN LESS REMAINDER (BCB2)
 B7B8 PLUS OLD EOF MARK (BEC8)
 B7C2 GIVES NEW EOF ON AN EVEN RECORD BOUNDARY (BEC9)
 B7CD "RANGE ERROR" POSSIBLE IF OVERFLOW OCCURS
 B7CF RETURN TO CALLER

B7D0 ***** GET FILE INFO *****

B7D0 SET NUMBER OF PARMS (10)
 B7D5 MLI CODE FOR GET FILE INFO
 B7D7 GO DO IT >>B7EE

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B7D7

 ADDR DESCRIPTION/CONTENTS

B7D9 ***** SET FILE INFO *****

B7D9 MODIFIED TIME/DATE = 0
 B7E7 SET NUMBER OF PARMS (7)
 B7EC MLI CODE FOR SET FILE INFO
 B7EE EXIT THRU MLI: GET/SET FILE INFO >>B7F0

B7F1 ***** BI I/O INDIRECTION VECTORS *****

B7F1 DOSOUT VECTOR >>B838
 87F4 DOSIN VECTOR >>B83A

B7F7 ***** STATE I/O VECTORS TABLE *****

B7F7 IMMEDIATE MODE (STATE=0) CSWL/KSWL
 B7FB DEFERRED MODE (STATE=4) CSWL/KSWL
 B7FF (STATE=8) CSWL/KSWL
 B803 (STATE=C) CSWL

B805 ***** SYST8L *****
 LSB'S OF MLI CALL PARAMETER LISTS IN THE
 BI GLOBAL PAGE (\$BEXX)

B805 CREATE: \$A0 DESTROY: \$AC RENAME: \$AF
 B808 SFI: \$B4 GFI: \$B4 ONLINE: \$C6
 B80B SPFX: \$AC GPFX: \$AC OPEN: \$C8
 B80E NEWLINE:\$D1 READ: \$D5 WRITE: \$D5
 B811 CLOSE: \$DD FLUSH: \$DD SMARK: \$C6
 B814 GMARK: \$C6 SEOF: \$C6 GEOF: \$C6
 B817 SBUF: \$C6 GBUF: \$C6

B819 ***** APPLESOFT TOKENS *****
 TOKENS REQUIRING SPECIAL ATTENTION HAVE
 THEIR MSB OFF AND ARE AN OFFSET FROM A
 JMP IN THE TRACE HANDLER IN THE BI

8819 FIRST IS \$80 (END)
 B823 CALL
 B833 TRACE, NOTRACE, NORMAL
 B837 INVERSE, FLASH
 B83F RESUME
 B843 LET, IF
 B853 PRINT, LIST

8859 ***** COMMAND NAME TABLES *****
 OFFSETS TO LAST CHARACTER OF EACH COMMAND
 NAME IN THE COMMAND NAME TABLE BELOW.
 COMMANDS ARE ARRANGED ACCORDING TO LENGTH
 WITH THREE BYTE NAMES FIRST. IF THE MSB
 OF AN INDEX IS ON, THEN THIS IS THE LAST

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: 8859

 ADDR DESCRIPTION/CONTENTS

NAME OF THE GIVEN LENGTH (NEXT WILL BE
 ONE BYTE LONGER).

B859 01 IN# 02 PR# 03 CAT
 B85C 04 FRE 05 BYE 06 RUN
 B85F 07 BRUN 08 EXEC 09 LOAD
 B862 0A LOCK 0B OPEN 0C READ
 B865 0D SAVE 0E BLOAD 0F BSAVE
 B868 10 CHAIN 11 CLOSE 12 FLUSH
 B86B 13 NOMON 14 STORE 15 WRITE
 B86E 16 APPEND 17 CREATE 18 DELETE
 B871 19 PREFIX 1A RENAME 1B UNLOCK
 B874 1C VERIFY 1D CATALOG 1E RESTORE
 B877 1F POSITION

B878 'BSAVERIFYBLOADDELETEBECATALOGOPE'
 B898 'NWRITECREATEFRESTORENAMEBRUNLO'
 B8B8 'CKCHAIN#FLUSHREADPOSITIONMONPR#'
 B8D8 'PREFIXCLOSEAPPEND'

88E9 ***** COMMAND HANDLER ADDRESS TABLE *****
 ADDRESSES OF THE COMMAND HANDLER ROUTINES
 FOR EACH COMMAND IN THE ORDER GIVEN ABOVE.

(EXTERNAL)

B8E9 IN#
 B8EB IN#
 B8ED PR#
 B8EF CAT
 B8F1 FRE
 B8F3 BYE
 B8F5 RUN
 B8F7 BRUN
 B8F9 EXEC
 B8FB LOAD
 B8FD LOCK
 B8FF OPEN
 B901 READ
 B903 SAVE
 B905 BLOAD
 B907 BSAVE
 B909 CHAIN
 B90B CLOSE
 B90D FLUSH
 B90F NOMON
 B911 STORE
 B913 WRITE
 B915 APPEND
 B917 CREATE
 B919 DELETE
 B91B PREFIX
 B91D RENAME

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B91F

ADDR DESCRIPTION/CONTENTS

B91F UNLOCK
B921 VERIFY
B923 CATALOG
B925 *RESTORE
B927 POSITION
B929 "-" COMMAND

B92B ***** PERMITTED KEYWORDS FOR CMDS *****
TWO BYTES PER COMMAND IN THE ORDER ABOVE.
EACH ENTRY HAS 16 BIT SETTINGS FOR THE
PARAMETERS PERMITTED ON THAT COMMAND.
8000 = FETCH PREFIX, PATHNAME OPTIONAL
4000 = SLOT (FOR PR# OR IN#)
2000 = DEFERRED COMMAND ONLY
1000 = FILENAME IS OPTIONAL
0800 = IF FILE NOT FOUND, CREATE IT
0400 = "T" (FILE TYPE) PERMITTED
0200 = PATHNAME2 (RENAME) PERMITTED
0100 = PATHNAME1 EXPECTED
0080 = "A" (ADDRESS) PERMITTED
0040 = "B" (BYTE) PERMITTED
0020 = "E" (END ADDRESS) PERMITTED
0010 = "L" (LENGTH) PERMITTED
0008 = "Q" (LINE NO.) PERMITTED
0004 = "S" AND/OR "D" (SLOT/DRIVE)
0002 = "F" (FIELD) PERMITTED
0001 = "R" (RECORD) PERMITTED
("V" IS IGNORED)

C P S D F N T P P A B E L @ S F R
O F L E N E | A | | | | | | | |
M X O F F O W | T | | | | | | |
M | T E P F | H H | | | | | | |
N | | R T I | 2 1 | | | | | | |
D | | | | L | | | | | | | |

B92B IN#
B92D PR#
B92F CAT
B931 FRE
B933 BYE
B935 RUN
B937 BRUN
B939 EXEC
B93B LOAD
B93D LOCK
B93F OPEN
B941 READ
B943 SAVE
B945 BLOAD
B947 BSAVE

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B949

ADDR DESCRIPTION/CONTENTS

B949 CHAIN
B94B CLOSE
B94D FLUSH
B94F NONON
B951 STORE
B953 WRITE
B955 APPEND
B957 *CREATE
B959 DELETE
B95B PREFIX
B95D RENAME
B95F UNLOCK
B961 VERIFY
B963 CATALOG
B965 RESTORE
B967 POSITION
B969 "-"

B96B ***** KEYWORD NAME TABLE *****

B96B 'ABELSDFRV@'

B975 ***** KEYWORD BIT POSITION TABLE *****
BIT POSITIONS IN PERMITTED PARMS TABLE
FOR EACH KEYWORD IN THE ORDER GIVEN IN
NAME TABLE. "V" IS 00 (NOT USED)

B975 ---

B97F ***** KEYWORD SIZE/OFFSET TABLE *****
LOW 2 BITS - SIZE-1 OF VALUE IN BYTES
HIGH 6 BITS- OFFSET TO LAST BYTE OF VALUE
FROM \$BE58

B97F A: 2 BYTES AT +1
B980 B: 3 BYTES AT +4
B981 E: 2 BYTES AT +6
B982 L: 2 BYTES AT +8
B983 S: 1 BYTE AT +9
B984 D: 1 BYTE AT +A
B985 F: 2 BYTES AT +C
B986 R: 2 BYTES AT +E
B987 V: 1 BYTE AT +10 (IGNORED)
B988 @: 2 BYTES AT +11

B989 ***** FILE TYPES TABLES *****
FILE TYPE CODES, GIVEN IN INVERSE ORDER
TO FILE TYPE NAMES WHICH FOLLOW.

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: B989
 ADDR DESCRIPTION/CONTENTS

B989 \$FF = "SYS"
 B98A \$FE = "REL"
 B98B \$FD = "VAR"
 B98C \$FC = "BAS"
 B98D \$FB = "IVR"
 B98E \$FA = "INT"
 B98F \$F0 = "CMD"
 B990 \$0F = "DIR"
 B991 \$06 = "BIN"
 B992 \$04 = "TXT"
 B993 \$EF = "PAS"
 B994 \$1A = "AWP"
 B995 \$1B = "ASP"
 B996 \$19 = "ADB"

B997 ---
 B997 'ADBASPWPASTXTBINDIRCMDINTIVRBASVARRELSYS'

B9C1 ***** MONTH TABLE *****

B9C1 'JANFEBMARAPR MAYJUNJUL AUGSEP OCTNOVDEC'
 B9E5 '<NO DATE>'

B9EE ***** /MLIERTBL *****
 MLI ERROR CODES WHICH HAVE BI EQUIVALENTS

B9EE ---

BA01 ***** BIERTBL *****
 BI EQUIVALENTS TO MLI ERROR CODES ABOVE
 (IF MLI CODE NOT FOUND, MAPS TO LAST CODE
 IN THIS TABLE, \$08 "I/O ERROR")

BA01 ---

BA15 ***** INDEXES TO PACKED MESSAGES *****
 BY BI ERROR NUMBER

BA15 ---

BA29 ***** COMMON LETTERS IN MESSAGES *****

BA29 ---
 BA29 'ACDEFILMNORTU '

BASIC Interpreter (BI) -- V1.1 --18 JUN 84 NEXT OBJECT ADDR: BA38
 ADDR DESCRIPTION/CONTENTS

BA38 ***** LESS COMMON LETTERS *****

BA38 ---
 BA39 'BGHKPSVMXY/().:.'

BA48 ***** PACKED MESSAGES *****

BA48 "COPYRIGHT APPLE COMPUTER"

BA58 " NAME "
 BA5B TAB(\$10)
 BA5D "TYPE BLOCKS "
 BA66 TAB(\$1E)
 BA68 "MODIFIED"
 BA6C TAB(\$2F)
 BA6E "CREATED "
 BA72 TAB(\$40)
 BA74 "ENDFILE SUBTYPE"

BA7E "BLOCKS FREE:"
 BA86 TAB(\$16)
 BA88 "BLOCKS USED:"
 BA91 TAB(\$2C)
 BA93 "TOTAL BLOCKS:"

BA9C "RANGE ERROR" ERROR=\$2

BAA3 "NO DEVICE CONNECTED" ERROR=\$3

BAAE "WRITE PROTECTED" ERROR=\$4

BAB7 "END OF DATA" ERROR=\$5

BABD "PATH NOT FOUND" ERROR=\$6,\$7
 BACU

BAC6 "I/O ERROR" ERROR=\$8

BACC "DISK FULL" ERROR=\$9

BAD2 "FILE LOCKED" ERROR=\$A

BAD9 "INVALID PARAMETER" ERROR=\$B

BAE3 "RAM TOO LARGE" ERROR=\$C

BAF0 "FILE TYPE MISMATCH" ERROR=\$D

BASIC Interpreter (BI) -- VI.1 --18 JUN 84 NEXT OBJECT ADDR: BAF8

ADDR DESCRIPTION/CONTENTS

BAFC "PROGRAM TOO LARGE" ERROR=\$E
 BB07 "NOT DIRECT COMMAND" ERROR=\$F
 BB11 "SYNTAX ERROR" ERROR=\$I0
 BB19 "DIRECTORY FULL" ERROR=\$I1
 BB21 "FILE NOT OPEN" ERROR=\$I2
 BB29 "DUPLICATE FILE NAME" ERROR=\$I3
 BB34 "FILE BUSY" ERROR=\$I4
 BB3B "FILE(S) STILL OPEN" ERROR=\$I5
 BB40

BB47 ***** VARIABLES *****

BB47 NUMBER OF PAGES TO ALLOCATE/FREE
 BB4B NOT USED
 BB49 TOP OF BUFFERS FOR GARBAGE COLLECTION
 BB4A BOTTOM OF BUFFERS

BB4B ***** \$BB4B-\$BC7A NOT USED *****

BB4B NOT USED

BC7B ***** VARIABLES *****

BC7B SAVED HIMEM VALUE DURING CHAIN LOAD
 ***** GARBAGE COLLECT MARKED GC: *****
 BC7C GC: HIRANGE - WORKSAREASIZE
 BC7D GC: WORKAREA MSB
 BC7E GC: NUMBER OF PAGES IN WORKAREA
 BC7F GC: LORANGE (START OF STRINGS TO COPY)
 BC80 GC: HIRANGE (END OF STRINGS TO COPY)
 BC81 ARRAYS START LSB
 BC82 ARRAYS ENDING MSB+1
 BC83 GC: START OF STRING AREA (ALSO PGM START)
 BC85 GC: END OF STRING AREA
 BC87 MSB ADJUST FACTOR FOR STRING POINTERS
 BC88 PAGE FOLLOWING BLOCK BUFFER
 ***** STORED VARIABLES FILE HEADER ***
 BC89 COMBINED LEN OF SIMPLE/ARRAY VARS
 BC8B LEN OF SIMPLE VARS ONLY
 BC8D HIMEM WHEN VARS WERE COMBINED

 BC8E POINTER TO COMBINED VARIABLES/STRINGS
 BC90 LENGTH OF COMBINED VARIABLES/STRINGS

BASIC Interpreter (BI) -- VI.1 --18 JUN 84 NEXT OBJECT ADDR: BC92

ADDR DESCRIPTION/CONTENTS

BC92 LENGTH OF STRINGS ONLY
 BC94 OPEN FILES' BUFFER MSBS
 BC98 OPEN EXEC FILE BUFFER MSB
 BC9C OPEN FILES' REFERENCE NUMBERS
 BCA3 OPEN EXEC FILE REFNUM
 BCA4 CURRENT RECORD LENGTH
 BCA6 NOT USED
 BCA9 CHARACTER TO FLUSH WHEN PARSING (BLANK)
 BCAB MAXIMUM LENGTH TO PARSE
 BCAB ADDRESS OF COMMAND HANDLING ROUTINE
 BCAD SIZE OF KEYWORD VALUE -1 IN BYTES
 BCAF OFFSET INTO KEYWORD PARMS TO LAST BYTE
 BCAF GENERAL PURPOSE 4 BYTE ACCUMULATOR
 BCB3 MONTH
 BCB4 DAY
 BCB5 YEAR
 BCB6 ERROR MSG LEN OR LINE LEN FOR CAT/CATALOG
 BCB7 ENTRY LENGTH IN DIRECTORY FILE
 BCB8 ENTRIES PER BLOCK IN DIRECTORY FILE
 BCB9 FILE COUNT FROM DIRECTORY FILE
 BCB8 DIRECTORY ENTRY NUMBER COUNTER

BCBC ***** PATHNAME 1 BUFFER *****

BCBC COMMAND OR PATH LENGTH
 BCBD TXBUF (COMMAND OR PATHNAME STRING)
 BCFD NOT USED

BCFE ***** OPEN FILE NAME TABLE *****
 (EACH ENTRY IS 32 BYTES LONG)
 (THERE ARE 8 ENTRIES)

BCFE FILE 0: LENGTH OF NAME
 BCFF FILE 0: L VALUE LSB
 BD00 FILE 0: L VALUE MSB
 BD01 FILE 0: START OF NAME STRING
 (FILE NAME IS STORED BACKWARDS)
 BD0E LAST 2 BYTES NOT USED

BASIC INTERPRETER GLOBAL PAGE

This page of memory is rigidly defined by the ProDOS BI. Fields given here will not move in later versions of ProDOS and may be referenced by external, user-written programs. Future additions to the global page may be made in areas which are marked "Not used".

PRODOS BI Global Page		NEXT OBJECT ADDRESS: BE00	
ADDR	LABEL	CONTENTS	
BE00-BE02	BI.ENTRY	JMP to WARMDS (BI warmstart vector).	
BE03-BE05	DOSCMD	JMP to SYNTAX (BI command line parse and execute).	
BE06-BE08	EXTRNCMD	JMP to user-installed external command parser.	
BE09-BE0B	ERROUT	JMP to BI error handler.	
BE0C-BE0E	PRINTERR	JMP to BI error message print routine.	
BE0F	ERRCODE	Place error number in A-register.	
		PRODOS error code (also at \$DE, AppleSoft ONERR code).	
BE10-BE1F	OUTVEC	Default output vector in monitor and for each slot (1-7).	
BE20-BE2F	INVEC	Default input vector in monitor for each slot (1-7).	
BE30-BE31	VECTOUT	Current output vector.	
BE32-BE33	VECTIN	Current input vector.	
BE34-BE35	VDOSIO	BI's output intercept address.	
BE36-BE37		BI's input intercept address.	
BE38-BE3B	VYSIO	BI's internal redirection by STATE.	
BE3C	DEFSLT	Default slot.	
BE3D	DEFDRV	Default drive.	
BE3E	PREGA	A-register savearea.	
BE3F	PREGX	X-register savearea.	
BE40	PREGY	Y-register savearea.	
BE41	DTRACE	Applesoft TRACE is enabled flag (MSB on).	
BE42	STATE	Current intercept state. 0 = immediate command mode. >0 = deferred.	
BE43	EXACTV	EXEC file active flag (MSB on).	
BE44	IFILACTV	READ file active flag (MSB on).	
BE45	OFILACTV	WRITE file active flag (MSB on).	
BE46	PFIXACTV	PREFIX read active flag (MSB on).	
BE47	DIRFLG	File being READ is a DIR file (MSB on).	
BE48	EDIRFLG	End of directory flag (no longer used).	
BE49	STRINGS	String space count used to determine when to garbage collect.	
BE4A	TBUFPTR	Buffered WRITE data length.	
BE4B	INPTR	Command line assembly length.	
BE4C	CHRLAST	Previous output character (for recursion check).	
BE4D	OPENCNT	Number of files open (not counting EXEC).	
BE4E	YXFILE	EXEC file being closed flag (MSB on).	
BE4F	CATFLAG	Line type to format next in DIR file READ.	
BE50-BE51	XTRNADDR	External command handler address.	
BE52	XLEN	Length of command name (less one).	

ProDOS BI Global Page			NEXT OBJECT ADDRESS: BE53		
ADDR	LABEL	CONTENTS	ADDR	LABEL	CONTENTS
BE53	XCNUM	<p>Number of command:</p> <p>\$00 = external \$0B = OPEN \$15 = WRITE</p> <p>\$01 = IN# \$0C = READ \$16 = APPEND</p> <p>\$02 = PR# \$0D = SAVE \$17 = CREATE</p> <p>\$03 = CAT \$0E = BLOAD \$18 = DELETE</p> <p>\$04 = FRE \$0F = BSAVE \$19 = PREFIX</p> <p>\$05 = BYE \$10 = CHAIN \$1A = RENAME</p> <p>\$06 = RUN \$11 = CLOSE \$1B = UNLOCK</p> <p>\$07 = BRUN \$12 = FLUSH \$1C = VERIFY</p> <p>\$08 = EXEC \$13 = NOMON \$1D = CATALOG</p> <p>\$09 = LOAD \$14 = STORE \$1E = RESTORE</p> <p>\$0A = LOCK</p>	BE53	VPATH1	Primary pathname buffer (address of length byte).
			BE54-BE55	VPATH2	Secondary pathname buffer (address of length byte).
				GOSYSTEM	Call the MLI using the parameter tables which follow.
				SYSCALL	MLI call number for this call.
				SYS Parm	Address of MLI parameter list for this call.
				BADCALL	Return from MLI call.
				BE9F	MLI error return: translate error code to BI error number.
				BISPARE1	Not used.
				BEA0-BEAB	CREATE parameter list.
				BEAC-BEAE	GET_PREFIX, SET_PREFIX, DESTROY parameter list.
				BEAF-BEB3	RENAME parameter list.
				BEBA-BEC5	GET_FILE_INFO, SET_FILE_INFO parameter list.
				BEC6-BECA	ONLINE, SET MARK, GET MARK, SET EOF, GET_EOF, SET_BUF, GET_BUF, QUIT_parameter list.
				BECB-BED0	OPEN parameter list.
				BED1-BED4	SET_NEWLINE parameter list.
				BED5-BEDC	READ, WRITE parameter list.
				BEDD-BEDE	CLOSE, FLUSH parameter list.
				BEDF-BEF4	"COPYRIGHT APPLE, 1983"
				BEF5-BEF7	GETBUFR buffer allocation subroutine vector.
				BEF8-BEFA	FREEBUFR buffer free subroutine vector.
				BEFB	Original HIMEM MSB.
				BEFC-BEFF	Not used.
BE54-BE55	PBITS	<p>Permitted command operands bits:</p> <p>\$8000 Prefix needed. Pathname optional.</p> <p>\$4000 Slot number only (PR# or IN#).</p> <p>\$2000 Deferred command.</p> <p>\$1000 File name optional.</p> <p>\$0800 If file does not exist, create it.</p> <p>\$0400 T: file type permitted.</p> <p>\$0200 Second file name required.</p> <p>\$0100 First file name required.</p> <p>\$0080 AB: address keyword permitted.</p> <p>\$0040 B: byte offset permitted.</p> <p>\$0020 E: ending address permitted.</p> <p>\$0010 L: length permitted.</p> <p>\$0008 @: line number permitted.</p> <p>\$0004 S or D: slot/drive permitted.</p> <p>\$0002 F: field permitted.</p> <p>\$0001 R: record permitted.</p> <p>(V always permitted but ignored.)</p>	BE56-BE57	FBITS	Operands found on command line. Same bit assignments as above.
			BE58-BE59	VADDR	A keyword value.
			BE5A-BE5C	VBYTE	B keyword value.
			BE5D-BE5E	VENDA	E keyword value.
			BE5F-BE60	VINTH	L keyword value.
			BE61	VSLOT	S keyword value.
			BE62	VDRIV	D keyword value.
			BE63-BE64	VFELD	F keyword value.
			BE65-BE66	VRECD	R keyword value.
			BE67	VVOLM	V keyword value (ignored).
			BE68-BE69	VLINE	@ keyword value.
			BE6A	VTYPE	T keyword value (in hex).
			BE6B	VIOSLT	PR# or IN# slot number value.

```

Disk Controller Boot ROM -- Apple II/II+/IIE  NEXT OBJECT ADDR: C600
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

C600 MODULE STARTING ADDRESS

```

*****
*
* BOOT ROM - APPLE DISK CONTROLLER
* FOR APPLE II, II+, AND IIE.
* THIS CODE RESIDES FROM $C600
* TO $C6FF. IT LOADS TRACK 0
* SECTOR 0 INTO RAM AT $800 AND
* JUMPS TO IT
*
*****
***** ZERO PAGE ADDRESSES *****

```

```

0026 SECTOR BUFFER POINTER
002B SLOT NUMBER * 16 FOR INDEX
003C WORKBYTE
003D SECTOR WANTED
0040 TRACK FOUND
0041 TRACK WANTED

```

***** EXTERNAL ADDRESSES *****

```

0100 SYSTEM STACK
0300 AUXILIARY BUFFER
0356 TRANSLATE TABLE
0800 SECTORS TO LOAD
0801 ENTRY POINT
0808 PHASE0 OFF
0811 PHASE0 ON
0899 MOTOR ON
089A DRIVE SELECT
089C READ DATA REGISTER
089E SET READ MODE
FCAB MONITOR WAIT ROUTINE
FF58 RTS

```

C600 ***** BUILD READ TRANSLATE TABLE *****

```

C600 SIGNATURE
C602 INITIALIZE TABLE VALUE INDICATOR
C606 STORE BIT PATTERN
C609 SHIFT PATTERN LEFT ONE BIT
C60A ARE THERE ANY TWO ADJACENT BITS ON?
C60C NO, TRY ANOTHER PATTERN >>C61E
C60E YES, TURN OFF RIGHTMOST OF EACH GROUP OF ZEROES
C610 FLIP BITS, PAIR OF ZERO BITS NOW SINGLE ONE BIT
C612 HIGH BIT ALWAYS ON/TURN OFF BIT WE MISSED BEFORE
C614 --- >>C61E
C616 SHIFT PATTERN RIGHT, MUST HAVE ONLY ONE BIT ON

```

```

Disk Controller Boot ROM -- Apple II/II+/IIE  NEXT OBJECT ADDR: C617
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

C617 IF MORE THAN ONE BIT ON, TRY ANOTHER PATTERN >>C614
C619 FOUND ONE, GET TABLE VALUE
C61A AND STORE IT IN TABLE (0356)
C61D INCREMENT TABLE VALUE INDICATOR
C61E GET NEXT BIT PATTERN, DONE YET
C61F NO, GO CHECK IT OUT >>C606

```

C621 ***** DETERMINE SLOT, TURN DRIVE ON *****

```

C621 CALL A KNOWN RTS <FF58>
C624 GET STACK POINTER
C625 GET HIGH BYTE OF WHERE WE ARE (0100)
C628 TIMES 16 TO GET SLOT
C62C SAVE SLOT
C62E PUT IN X REG FOR INDEX
C62F INSURE READ MODE (C08E)
C635 SELECT DRIVE 1 (C08A)
C638 TURN THE MOTOR ON (C089)

```

C63B ***** RECALIBRATE DISK ARM *****

```

C63B PREPARE TO STEP THE ARM 80 PHASES
C63D TURN A PHASE OFF (C080)
C640 PUT COUNTER IN ACCUMULATOR
C641 CREATE A PHASE NUMBER (0-3)
C643 DOUBLE IT FOR PROPER INDEX
C644 COMBINE WITH SLOT FOR FINAL INDEX
C646 PUT INDEX IN X REGISTER
C647 TURN A PHASE ON (C081)
C64A DELAY ABOUT 20 MICROSECONDS
C64F DECREMENT COUNTER
C650 LOOP UNTIL ALL 80 ARE DONE >>C63D

```

C652 ***** INITIALIZATION *****

```

---
C652 SECTOR TO FIND -> $00
C654 TRACK TO FIND -> $00
C656 MAIN BUFFER POINTER ($26) -> $0800
C65A CLEAR THE CARRY
C65D PUSH STATUS ON STACK

```

C65E ***** SEARCH FOR A VALID HEADER *****

```

C65E CHECK DATA REGISTER (C08C)
C661 LOOP UNTIL DATA IS VALID >>C65E
C663 IS IT A $D5?
C665 NO, TRY AGAIN >>C65E
C667 YES, CHECK REGISTER AGAIN (C08C)
C66A LOOP UNTIL VALID >>C667
C66C IS IT AN $AA

```

Disk Controller Boot ROM -- Apple II/II+/IIfx NEXT OBJECT ADDR: C66E

ADDR DESCRIPTION/CONTENTS

```
C66E NO, SEE IF ITS A $D5 >>C663
C670 YES, DELAY FOR REGISTER TO CLEAR
C671 CHECK REGISTER (C08C)
C674 LOOP UNTIL VALID >>C671
C676 IS IT A $96
C678 YES, WE FOUND AN ADDRESS HEADER >>C683
C67A NO, HAVE WE FOUND ONE PREVIOUSLY?
C67B IF NOT, START OVER >>C65C
C67D WAS IT AN $AD?
C67F YES, WE FOUND A DATA HEADER >>C6A6
C681 NO, START OVER >>C65C
```

C683 ***** DECODE ADDRESS FIELD *****

```
C683 INITIALIZE COUNTER
C685 SAVE VALUE DECODED, WILL BE TRACK ON LAST PASS
C687 READ DATA REGISTER (C08C)
C68A LOOP UNTIL DATA VALID >>C687
C68C SHIFT BITS INTO POSITION XIXIXIXI
C68D SAVE FOR LATER
C68F READ REGISTER FOR NEXT BYTE (C08C)
C692 LOOP UNTIL VALID >>C68F
C694 COMBINE WITH PREVIOUS IXIXIXIX AND XIXIXIXI
C696 DECREMENT COUNTER, DONE YET?
C697 NO, DO ANOTHER >>C685
C699 KEEP THE STACK CLEAN
C69A IS THIS SECTOR WE WANT?
C69C NO, START OVER >>C65C
C69E GET TRACK FOUND
C6A0 IS IT TRACK WE WANT?
C6A2 NO, START OVER >>C65C
C6A4 YES, INDICATE ADDRESS FOUND, GO LOOK FOR DATA FIELD >>C65D
```

C6A6 ***** READ DATA FIELD *****

```
C6A6 INITIALIZE OFFSET (AUXILIARY BUFFER)
C6A8 ---
C6AA READ DATA REGISTER (C08C)
C6AD LOOP UNTIL VALID >>C6AA
C6AF EXCLUSIVE-OR WITH TRANSLATE TABLE (02D6)
C6B4 DECREMENT OFFSET
C6B5 STORE BYTE IN AUXILIARY BUFFER (0300)
C6B8 LOOP UNTIL BUFFER FULL >>C6A8
C6BA INITIALIZE OFFSET (MAIN BUFFER)
C6BC READ DATA REGISTER (C08C)
C6BF LOOP UNTIL VALID >>C6BC
C6C1 EXCLUSIVE-OR WITH TRANSLATE TABLE (02D6)
C6C6 STORE BYTE IN MAIN BUFFER
C6C8 INCREMENT OFFSET
C6C9 LOOP UNTIL BUFFER FULL >>C6BA
C6CB READ DATA REGISTER (C08C)
```

Disk Controller Boot ROM -- Apple II/II+/IIfx NEXT OBJECT ADDR: C6CE

ADDR DESCRIPTION/CONTENTS

```
C6CE LOOP UNTIL VALID >>C6CB
C6D0 IS CHECKSUM OKAY? (02D6)
C6D3 NO, START OVER >>C65C
```

C6D5 ***** MERGE MAIN AND AUXILIARY BUFFERS *****

```
C6D5 INITIALIZE OFFSET (MAIN BUFFER)
C6D7 INITIALIZE OFFSET (AUXILIARY BUFFER)
C6D9 DECREMENT OFFSET (AUX BUFFER)
C6DA IF LESS THAN ZERO RESET IT >>C6D7
C6DC GET BYTE FROM MAIN BUFFER
C6E1 ROLL IN TWO BITS FROM AUXILIARY BUFFER
C6E6 SAVE COMPLETED DATA BYTE
C6E8 INCREMENT OFFSET (MAIN BUFFER)
C6E9 LOOP UNTIL WHOLE BUFFER IS DONE >>C6D9
```

C6EB ***** DETERMINE IF THERE IS MORE TO DO *****

```
C6EB INCREMENT MAIN BUFFER POINTER
C6ED INCREMENT SECTOR NUMBER
C6F1 IS THERE ANOTHER SECTOR TO LOAD? (0800)
C6F6 YES, GO DO IT >>C6D3
C6F8 NO, ENTER CODE WE JUST LOADED >>0801
```

C6FB ***** UNUSED *****

C6FB 5 BYTES AT END OF PAGE ARE UNUSED

Disk Controller Boot ROM -- Apple IIC NEXT OBJECT ADDR: C552
 ADDR DESCRIPTION/CONTENTS

C552 MODULE STARTING ADDRESS

```
*****
*
* BOOT ROM - APPLE //c CONTROLLER ROM
* THIS CODE RESIDES FROM $C552
* TO $C6FF. IT LOADS TRACK 0
* SECTOR 0 INTO RAM AT $800 AND
* JUMPS TO IT. IF BOOT FAILS IT
* THEN TRIES TO BOOT SLOT 5,
* THE PROTOCOL CONVERTER.
*
* THIS IS THE VERSION OF THE IIC ROM
* THAT SUPPORTS THE UNIDISK 3.5,
* 26 JULY 85.
*****
```

***** ZERO PAGE ADDRESSES *****

```
0001    SLOT PAGE PUT HERE DURING AUTOBOOT
0003    RETRY COUNT (HIGH BYTE)
0026    SECTOR BUFFER POINTER
002B    SLOT NUMBER * 16 FOR INDEX
003C    WORKBYTE
003D    SECTOR WANTED
0040    TRACK FOUND
0041    TRACK WANTED
004F    DRIVE TO BOOT FROM
```

***** EXTERNAL ADDRESSES *****

```
0300    AUXILIARY BUFFER
0356    TRANSLATE TABLE
07DB    SCREEN LOCATION
0800    SECTORS TO LOAD
0801    ENTRY POINT
0808    PHASE0 OFF
0811    PHASE0 ON
C088    MOTOR OFF
C089    MOTOR ON
C08C    READ DATA REGISTER
C08E    SET READ MODE
C09A    DRIVE SELECT
FCAB    MONITOR WAIT ROUTINE
```

Disk Controller Boot ROM -- Apple IIC NEXT OBJECT ADDR: C552
 ADDR DESCRIPTION/CONTENTS

C552 ***** SLOT5 CODE *****

THE FOLLOWING TWO ROUTINES ARE IN THE \$C500
 AREA BUT ARE USED BY THE \$C600 LOGIC.

```
C552    ***** BOOTFAIL *****
COME HERE IF BOOT FAILS. PUT MESSAGE ON
SCREEN AND GO TO SLEEP FOREVER.
```

```
C552    17 CHARACTERS IN MESSAGE
C557    PUT AT BOTTOM OF SCREEN (07DB)
C55D    THEN GO TO SLEEP >>C55D
```

C55F 'Check Disk Drive'

C56F ***** SKIP OVER MISCELLANEOUS CODE *****

C56F SLOT 5 LOGIC IN HERE

C58E ***** BUILD READ TRANSLATE TABLE *****

```
C58E    INITIALIZE BIT PATTERN
C590    INITIALIZE TABLE VALUE INDICATOR
C592    STORE BIT PATTERN
C595    SHIFT PATTERN LEFT ONE BIT
C596    ARE THERE ANY TWO ADJACENT BITS ON?
C598    NO, TRY ANOTHER PATTERN >>C5AA
C59A    YES, TURN OFF RIGHTMOST OF EACH GROUP OF ZEROES
C59C    FLIP BITS, PAIR OF ZERO BITS NOW SINGLE BIT, ETC
C59E    HIGH BIT ALWAYS ON/TURN OFF BIT WE MISSED BEFORE
C5A0    --- >>C5AA
```

```
C5A2    SHIFT PATTERN RIGHT, MUST HAVE ONLY ONE BIT ON
C5A3    IF MORE THAN ONE BIT ON, TRY ANOTHER PATTERN >>C5A0
C5A5    FOUND ONE, GET TABLE VALUE
C5A6    AND STORE IT IN TABLE (0356)
C5A9    INCREMENT TABLE VALUE INDICATOR
C5AA    GET NEXT BIT PATTERN, DONE YET?
C5AB    NO, GO CHECK IT OUT >>C592
C5AD    MAIN BUFFER POINTER ($26) -> $0800
C5B1    INITIALIZE RETRY COUNT (LOW BYTE)
C5B3    RETURN TO CALLER
```

C5B4 ***** SKIP OVER MISCELLANEOUS CODE *****

C5B4 SLOT 5 LOGIC IN HERE

Disk Controller Boot ROM -- Apple IIc NEXT OBJECT ADDR: C644

ADDR	DESCRIPTION/CONTENTS
C644	DECREMENT RETRY COUNT, TRY AGAIN?
C646	YES, GO DO IT >>C656
C648	NO, TURN DRIVE OFF (C088)
C64B	AUTO BOOT FROM SLOT6?
C64F	NO, FAIL NOW >>C5F5
C651	MAYBE SLOT 5 WILL TALK TO US >>C500
C654	TWO BYTES NOT USED >>0002
C656	---
C657	DECREMENT RETRY COUNT (LOW BYTE)
C658	IF NOT ZERO, TRY AGAIN >>C65E
C65A	IF SO, GO DECREMENT RETRY COUNT (HIGH BYTE) >>C641
C65C	SPACE FILLER TO POSITION CODE BELOW >>C63D
C65E	***** SEARCH FOR A VALID HEADER *****
C65E	CHECK DATA REGISTER (C08C)
C661	LOOP UNTIL DATA IS VALID >>C65E
C663	IS IT A \$D5?
C665	NO, TRY AGAIN >>C657
C667	YES, CHECK REGISTER AGAIN (C08C)
C66A	LOOP UNTIL VALID >>C667
C66C	IS IT AN \$AA
C66E	NO, SEE IF ITS A \$D5 >>C663
C670	YES, DELAY FOR REGISTER TO CLEAR
C671	CHECK REGISTER (C08C)
C674	LOOP UNTIL VALID >>C671
C676	IS IT A \$96
C678	YES, WE FOUND AN ADDRESS HEADER >>C683
C67A	NO, HAVE WE FOUND ONE PREVIOUSLY?
C67B	IF NOT, START OVER >>C63F
C67D	WAS IT AN \$AD?
C67F	YES, WE FOUND A DATA HEADER >>C6A6
C681	NO, START OVER >>C63F
C683	***** DECODE ADDRESS FIELD *****
C683	INITIALIZE COUNTER
C685	SAVE VALUE DECODED, WILL BE TRACK ON LAST PASS
C687	READ DATA REGISTER (C08C)
C68A	LOOP UNTIL DATA VALID >>C687
C68C	SHIFT BITS INTO POSITION X1X1X1X1
C68D	SAVE FOR LATER
C68F	READ REGISTER FOR NEXT BYTE (C08C)
C692	LOOP UNTIL VALID >>C68F
C694	COMBINE WITH PREVIOUS IXLXIX AND X1X1X1X1
C696	DECREMENT COUNTER, DONE YET?
C697	NO, DO ANOTHER >>C685
C699	KEEP THE STACK CLEAN
C69A	IS THIS SECTOR WE WANT?
C69C	NO, START OVER >>C63F
C69E	GET TRACK FOUND

Disk Controller Boot ROM -- Apple IIc NEXT OBJECT ADDR: C5F5

ADDR	DESCRIPTION/CONTENTS
C5F5	***** JUMP TO BOOTFAIL *****
C5F5	BRANCH TO BOOTFAIL >>C552
C5F8	REMAINING 8 BYTES NOT USED BY DISK II >>C576
C600	***** INITIALIZATION *****
C600	SIGNATURE
C602	SET DRIVE -> 1
C604	INITIALIZE RETRY COUNT (HIGH BYTE)
C608	***** SELECT DRIVE AND TURN IT ON *****
C608	---
C60B	INITIALIZE SLOT (6)
C60D	INITIALIZE DEVICE (1 OR 2)
C60F	SAVE DRIVE NUMBER ON STACK
C610	INSURE READ MODE (C08E)
C616	GET DRIVE NUMBER BACK
C617	SELECT APPROPRIATE DRIVE (C0EA)
C61A	TURN MOTOR ON (C089)
C61D	***** RECALIBRATE DISK ARM *****
C61D	PREPARE TO STEP THE ARM 80 PHASES
C61F	TURN A PHASE OFF (C080)
C622	POT COUNTER IN A REGISTER
C623	CREATE A PHASE NUMBER (0-3)
C625	DOUBLE IT FOR PROPER INDEX
C626	COMBINE WITH SLOT FOR FINAL INDEX
C628	POT INDEX IN X REGISTER
C629	TURN A PHASE ON (C081)
C62C	DELAY ABOUT 20 MICROSECONDS
C631	DECREMENT COUNTER
C632	LOOP UNTIL ALL 80 ARE DONE >>C61F
C634	***** INITIALIZATION *****
C634	---
C636	SECTOR TO FIND -> \$00
C638	TRACK TO FIND -> \$00
C63A	BUILD THE TRANSLATE TABLE <C58E>
C63D	***** COUNT RETRIES AND INDICATE ERROR IF BOOT FAILS*****
C63D	INITIALIZE RETRY COUNT
C63F	CLEAR THE CARRY
C640	PUSH STATUS ON STACK
C641	KEEP STACK CLEAN
C642	GET SLOT

```

Disk Controller Boot ROM -- Apple IIc          NEXT OBJECT ADDR: C6A0
-----
ADDR  DESCRIPTION/CONTENTS
-----

```

```

C6A0  IS IT TRACK WE WANT?
C6A2  NO, START OVER >>C63F
C6A4  YES, INDICATE ADDRESS FOUND, GO LOOK FOR DATA FIELD >>C642
C6A6  ***** READ DATA FIELD *****

```

```

C6A6  INITIALIZE OFFSET (AUXILIARY BUFFER)
C6A8  ---
C6AA  READ DATA REGISTER (C08C)
C6AD  LOOP UNTIL VALID >>C6AA
C6AF  EXCLUSIVE-OR WITH TRANSLATE TABLE (02D6)
C6B4  DECREMENT OFFSET
C6B5  STORE BYTE IN AUXILIARY BUFFER (0300)
C6B8  LOOP UNTIL BUFFER FULL >>C6A8
C6BA  INITIALIZE OFFSET (MAIN BUFFER)
C6BC  READ DATA REGISTER (C08C)
C6BF  LOOP UNTIL VALID >>C6BC
C6C1  EXCLUSIVE-OR WITH TRANSLATE TABLE (02D6)
C6C6  STORE BYTE IN MAIN BUFFER
C6C8  INCREMENT OFFSET
C6C9  LOOP UNTIL BUFFER FULL >>C6BA
C6CB  READ DATA REGISTER (C08C)
C6CE  LOOP UNTIL VALID >>C6CB
C6D0  IS CHECKSUM OKAY? (02D6)
C6D3  NO, START OVER >>C6A2

```

```

C6D5  ***** MERGE MAIN AND AUXILIARY BUFFERS*****
C6D5  INITIALIZE OFFSET (MAIN BUFFER)
C6D7  INITIALIZE OFFSET (AUXILIARY BUFFER)
C6D9  DECREMENT OFFSET (AUX BUFFER)
C6DA  IF LESS THAN ZERO RESET IT >>C6D7
C6DC  GET BYTE FROM MAIN BUFFER
C6E1  ROLL IN TWO BITS FROM AUXILIARY BUFFER
C6E6  SAVE COMPLETED DATA BYTE
C6E8  INCREMENT OFFSET (MAIN BUFFER)
C6E9  LOOP UNTIL WHOLE BUFFER IS DONE >>C6D9

```

```

C6EB  ***** DETERMINE IF THERE IS MORE TO DO*****
C6EB  INCREMENT MAIN BUFFER POINTER
C6ED  INCREMENT SECTOR NUMBER
C6F1  IS THERE ANOTHER SECTOR TO LOAD? (0800)
C6F6  YES, GO DO IT >>C6D3
C6F8  NO, ENTER CODE WE JUST LOADED >>0801
C6FB  5 ZERO BYTES AT END OF PAGE

```

Disk II Boot ROM -- Apple II GS NEXT OBJECT ADDR: C600

ADDR DESCRIPTION/CONTENTS

C600 MODULE STARTING ADDRESS

```
*****
*
* C600 ROM - APPLE II GS
*   If an Apple II GS has slot 6
*   configured for Disk Port,
*   then this code is executed
*   when a boot is attempted
*   from slot 6.
*
* IIGS ROM VERSION 0
*
*****
```

C600 ***** ZERO PAGE ADDRESSES *****

```
1  SLOT PAGE PUT HERE DURING AUTOBOOT
3  RETRY COUNT (HIGH BYTE)
26 SECTOR BUFFER POINTER
2B SLOT NUMBER * 16
3C WORKBYTE
3D SECTOR WANTED
40 TRACK FOUND
41 TRACK WANTED
4F DRIVE TO BOOT FROM
```

C600 ***** EXTERNAL ADDRESSES *****

```
0300 AUXILIARY BUFFER
0356 TRANSLATE TABLE
07F8 SLOT THAT OWNS C800-CFFF
07FE UTILITY BYTE FOR SLOT 6
0800 SECTORS TO LOAD
0801 ENTRY POINT
C080 PHASE0 OFF
C081 PHASE0 ON
C088 MOTOR OFF
C089 MOTOR ON
C08C READ DATA REGISTER
C08E SET READ MODE
C0EA DRIVE SELECT
E000 APPLESOFT BASIC ENTRY POINT
FABA MONITOR DISK CONTROLLER SEARCH LOOP
FCAB MONITOR WAIT ROUTINE
```

Disk II Boot ROM -- Apple IIGS

NEXT OBJECT ADDR: C600

ADDR DESCRIPTION/CONTENTS

C600 ***** IIGS SOFT SWITCHES *****

```
C02D SLTROMSEL. SLOT ROM CONFIGURATION BYTE
C035 SHADOW. ENABLES/DISABLES SHADOWING
C068 STATEREG. ONE BYTE SETS 8 SOFT SWITCHES
```

C600 ***** C600 ENTRY POINT *****

```
---
C600 SIGNATURE
C602 SET DRIVE TO DRIVE 1
C604 INITIALIZE RETRY COUNT (HIGH BYTE)
C608 PUSH 0 ON STACK
C60A SET NORMAL ZERO PAGE
C60C SET DATA BANK SAME AS PROGRAM BANK
C60F MAKE SLOT 6 CURRENT (07F8)
C612 8-BIT MEMORY AND INDEX OPERATIONS
C616 STORE P-REGISTER IN SCREEN HOLE (07FE)
C619 DISABLE INTERRUPTS
C61A GO DO SOME TASKS ELSEWHERE IN ROM <FF5909>
C61E RESTORE SLOT*16 TO X-REGISTER
C620 IF CARRY SET, I/O ERROR >>C62E
```

```
C622 ***** COUNT RETRIES AND INDICATE ERROR *****
      IF BOOT FAILS
```

```
C622 INITIALIZE RETRY COUNT
C624 DISABLE INTERRUPTS (AGAIN)
C625 CLEAR CARRY AND
C626 PUT IT ON THE STACK.
C627 KEEP STACK EVEN
C628 GET SLOT*16 IN X-REGISTER
C62A DECREMENT RETRY COUNT. TRY AGAIN?
C62C YES, GO DO IT >>C636
C62E NO, TURN DRIVE OFF (C088)
C631 CALL BOOT ERROR HANDLER <FF5971>
C635 ENABLE INTERRUPTS IF OK TO <C648>
C638 AUTOBOOT FROM SLOT 6?
C63D NO, GO TO BASIC >>C642
C63F YES, RETURN TO SLOT SEARCH LOOP >>FABA
C642 JUMP TO BASIC >>E000
```

C645 ***** SUBROUTINE TO ENABLE INTERRUPTS *****

```
C645 ALLOW SHADOWING AND I/O (C035)
C648 CHECK ORIGINAL P-REGISTER (07FE)
C64B INTERRUPT HIT HIGH?
C64D YES, LEAVE INTERRUPTS DISABLED >>C650
C64F NO, ENABLE INTERRUPTS
C650 RESTORE SECTOR TO ACCUMULATOR
C652 RETURN
```

Disk II Boot ROM -- Apple IIGS
 ADDR DESCRIPTION/CONTENTS

Disk II Boot ROM -- Apple IIGS
 ADDR DESCRIPTION/CONTENTS

Disk II Boot ROM -- Apple IIGS
 ADDR DESCRIPTION/CONTENTS

Disk II Boot ROM -- Apple IIGS
 ADDR DESCRIPTION/CONTENTS

C653 ***** THREE BYTES NOT USED *****
 C653 NOT USED

C6A0 IS IT TRACK WE WANT?
 C6A2 NO, START OVER >>C625
 C6A4 YES, INDICATE ADDR FOUND, GO LOOK FOR DATA FIELD >>C628

C656 ***** INCREMENT RETRIES *****

C6A6 ***** READ DATA FIELD *****

 C656 DECREMENT RETRY COUNT (LOW BYTE)
 C65B IF NOT ZERO, TRY AGAIN >>C65E
 C65A ZERO, SO GO DECREMENT HIGH BYTE >>C627
 C65C SPACE FILLER TO POSITION CODE BELOW >>C622

 C6A6 INITIALIZE OFFSET (AUXILIARY BUFFER)

C65E ***** SEARCH FOR A VALID HEADER *****

 C6A6 INITIALIZE OFFSET (AUXILIARY BUFFER)

C65E CHECK DATA REGISTER (C08C)
 C661 LOOP UNTIL DATA IS VALID >>C65E
 C663 IS IT A \$D5?
 C665 NO, TRY AGAIN >>C657
 C667 YES, CHECK REGISTER AGAIN (C0BC)
 C66A LOOP UNTIL VALID >>C667
 C66C IS IT AN \$AA?
 C66E NO, SEE IF IT'S A \$D5 >>C663
 C670 YES, DELAY FOR REGISTER TO CLEAR
 C671 CHECK REGISTER (C08C)
 C674 LOOP UNTIL VALID >>C671
 C676 IS IT A \$96?

 C6A6 INITIALIZE OFFSET (AUXILIARY BUFFER)

C67B YES, WE FOUND AN ADDRESS HEADER >>C683
 C67A NO. ARE WE LOOKING FOR DATA HEADER?
 C67B NO, SO START OVER >>C625
 C67D YES, WAS IT AN \$AD?
 C67F YES, WE FOUND A DATA HEADER >>C6A6
 C681 NO, START OVER >>C625

C6D5 ***** MERGE MAIN AND AUXILIARY BUFFERS *****

C6B3 ***** DECODE ADDRESS FIELD *****

C6D5 ***** MERGE MAIN AND AUXILIARY BUFFERS *****

C683 INITIALIZE COUNTER
 C685 SAVE VALUE DECODED, WILL BE TRACK ON LAST PASS
 C687 READ DATA REGISTER (C08C)
 C68A LOOP UNTIL DATA VALID >>C687
 C68C SHIFT BITS INTO POSITION XIX1X1X1
 C68D SAVE FOR LATER
 C68F READ REGISTER FOR NEXT BYTE (C0BC)
 C692 LOOP UNTIL VALID >>C6BF
 C694 COMBINE WITH PREVIOUS IX1X1X1X AND XIX1X1X1
 C696 DECREMENT COUNTER. DONE YET?
 C697 NO, DO ANOTHER >>C685
 C699 KEEP STACK CLEAN
 C69A IS THIS SECTOR WE WANT?
 C69C NO, START OVER >>C625
 C69E GET TRACK FOUND

C6E1 ROLL IN TWO BITS FROM AUXILIARY BUFFER
 C6E6 SAVE COMPLETED DATA BYTE
 C6E8 INCREMENT OFFSET (MAIN BUFFER)
 C6E9 LOOP UNTIL WHOLE BUFFER IS DONE >>C6D9

C6EB ***** DETERMINE IF THERE IS MORE TO DO *****

C6EB INCREMENT MAIN BUFFER POINTER
 C6ED INCREMENT SECTOR NUMBER
 C6F1 IS THERE ANOTHER SECTOR TO LOAD? (0800)
 C6F6 YES, GO DO IT >>C6D3
 C6FB NO. ENABLE INTERRUPTS <C645>
 C6FB AND JUMP TO CODE WE JUST LOADED. >>0801

Disk II Boot ROM -- Apple II GS NEXT OBJECT ADDR: C6FB

ADDR DESCRIPTION/CONTENTS

C6FE LAST TWO BYTES ARE ZERO

```
*****
*
*    SUBROUTINES ELSEWHERE IN ROM    *
*    (BANK $FF -- II GS ROM)       *
*    *****
```

5909 ***** SELECT DRIVE AND TURN IT ON *****

```
---
590C INITIALIZE SLOT TO 6
590E INITIALIZE DEVICE (1 OR 2)
5910 INSURE READ MODE (C08E)
5916 SELECT APPROPRIATE DRIVE (C0EA)
5919 TURN MOTOR ON (C089)
```

591C ***** RECALIBRATE DISK ARM *****

```
591C PREPARE TO STEP THE ARM 80 PHASES
591E TURN A PHASE OFF (C080)
5921 PUT COUNTER IN A-REG
5922 CREATE A PHASE NUMBER (0-3)
5924 DOUBLE IT FOR PROPER INDEX
5925 COMBINE WITH SLOT FOR FINAL INDEX
5927 PUT INDEX IN X REGISTER
5928 TURN A PHASE OFF (C081)
592B DELAY ABOUT 20 MICROSECONDS
592D SAVE P-REGISTER
592E AND DISABLE INTERRUPTS
592F WHILE WAITING. <FCAB>
5932 RESTORE P-REGISTER
5933 DECREMENT COUNTER
5934 LOOP UNTIL ALL 80 ARE DONE >>591E
```

5936 ***** SET VARIABLES TO ZERO *****

```
5936 ZERO LOW BYTE, BUFFER ADDRESS
5938 SECTOR = 0
593A TRACK = 0
593C CLEAR CARRY, INDICATING READABLE DISK
593D TRY 50 READS
593F READ DATA REGISTER (C08C)
5942 FOUND SOMETHING! >>5948
5944 DECREMENT COUNTER
5945 AND TRY AGAIN. >>593F
5947 CAN'T FIND ANY DATA. SET ERROR INDICATOR.
```

Disk II Boot ROM -- Apple II GS NEXT OBJECT ADDR: 5947

ADDR DESCRIPTION/CONTENTS

5948 ***** BUILD READ TRANSLATE TABLE *****

```
5948 SAVE P-REGISTER
5949 INITIALIZE BIT PATTERN
594B INITIALIZE TABLE VALUE INDICATOR
594D STORE BIT PATTERN
5950 SHIFT PATTERN LEFT ONE BIT
5951 ARE THERE ANY TWO ADJACENT BITS ON?
5953 NO, TRY ANOTHER PATTERN >>5966
5955 YES, TURN OFF RIGHTMOST OF EACH GROUP OF ZEROS.
5957 FLIP BITS, PAIR OF ZERO BITS NOW SINGLE BIT, ETC.
5959 HIGH BIT ALWAYS ON/TURN OFF BIT WE MISSED BEFORE
595B --- >>5966
595D SHIFT PATTERN RIGHT, MUST HAVE ONLY ONE BIT ON
595E IF MORE THAN ONE BIT ON, TRY ANOTHER PATTERN >>595B
5960 FOUND ONE, GET TABLE VALUE
5961 AND STORE IT IN TABLE. (000356)
5965 INCREMENT TABLE VALUE INDICATOR
5966 GET NEXT BIT PATTERN. DONE YET?
5967 NO, GO CHECK IT OUT >>594D
5969 MAIN BUFFER POINTER ($26) -> $800
596D INITIALIZE RETRY COUNT
596F RESTORE P-REGISTER
5970 BACK TO $C600 CODE
```

5971 ***** HANDLE BOOT ERROR *****

```
5971 SET "NOT A STARTUP DISK" ERROR
5977 JUMP INTO BOOT ERROR LOGIC >>63D6
```

63D6 ***** BOOT ERROR LOGIC *****

```
63D6 GET INTO NATIVE MODE
63D8 SAVE P-REGISTER ON STACK
63D9 8-BIT MEMORY AND INDEX OPERATION
63DB AUTO BOOT FROM THIS SLOT?
63E1 YES, DON'T PRINT ERROR MESSAGE >>6423
63E3 SET DATA BANK REGISTER TO BANK 0 <6307>
63E6 SAVE SLOTTROM STATUS (C02D)
63EA ENABLE SMARTPORT/DISKPORT FOR SLOTS 5 AND 6
63EF SAVE STATERE (C068)
63F3 READ ROM
63F8 GET INTO EMULATION MODE
63FB SET AND CLEAR NORMAL SCREEN IN PREPARATION <00C593>
      TO PRINT SYSTEM ERROR MESSAGE ON ROW 10.
6400 RESTORE EMULATION MODE
6402 RESTORE SOFT SWITCHES (C068)
6406 RESTORE SLOTTROM STATUS (C02D)
```

```

6409 SET MSG CODE=0 ("I/O ERROR")
640B IS ERROR CODE ZERO? (E10Fb1)
640F NO, KEEP CHECKING >>6413
6411 YES, SET MSG CODE=1 ("NOT A STARTUP DISK")
6413 IS IT "NO DEVICE CONNECTED"?
6415 NO. >>6419
6417 YES, SET MSG CODE=2
6419 IS IT "CHECK STARTUP DEVICE"?
641B NO, CALL IT "I/O ERROR" >>641F
641D YES, SET MSG CODE=3
641F PUT MSG CODE IN ACCUM
6420 AND PRINT IT OUT <C080>
6423 INDICATE I/O ERROR
6425 GET P-REGISTER BACK
6426 RESTORE MODE BASED ON CARRY
6427 INDICATE ERROR
6428 RETURN TO $C600 LOGIC

```

APPENDIX A

DIFFERENCES BETWEEN THE PRODOS 8 VERSIONS

This Appendix identifies the changes to ProDOS 8 that were introduced with the 1.2 and 1.3 versions. Although we believe this to be a fairly thorough list, there may have been a few changes (especially deletions) that we didn't catch. Quite a few changes that were apparently made only to save space are not listed here.

CHANGES INTRODUCED IN THE 1.2 VERSION

The changes that were made to the 1.1.1 version of ProDOS to produce ProDOS 8, Version 1.2, are listed below. Addresses given here are Version 1.2 addresses.

Relocator

1. When running on a IIGS with ProDOS 16 installed, ProDOS 8 is entered from PQUIT (the ProDOS 16 Quit Handler). In this case the Relocator is entered at \$2003 instead of \$2000. [2000-2005, page 11].
2. The ProDOS 8 version number is now stored in the MLI subdirectory header data area [2048-204C, page 11].
3. Always checks to see if running on a IIGS, and if so sets a flag (2278). Also sets E100BD=0 if ProDOS 8 is the initial boot on a IIGS. [2079-208D, page 11].
4. Sets aux stack pointer to \$FF [20E6-20F5, 2111-2115, page 12].
5. If operating on a IIGS, skips logic that searches for slot 3 80-column card [212A-2139, page 12].
6. If operating on a IIGS, installs the IIGS Clock Code [21AD-21D0, 22D3-22DA, pages 12 and 14].
7. Now checks for an AppleTalk Initialization File (ATINIT file) before looking for a .SYSTEM file. If the ATINIT file is found, it is loaded and executed, then the search for a .SYSTEM file commences. [22DB-2381, page 14].
8. The list of devices is now ordered differently. It recognizes the SmartPort and allows four Slot 5 SmartPort units to be accessed as Slot 5, Drives 1 and 2 and Slot 2, Drives 1 and 2. If Slot 2 is being used by a storage device, however, only the first two devices on the Slot 5 SmartPort can be accessed. It also changes the search order, making sure that Disk II devices are searched last when a device scan takes place (such as during an MLI ON_LINE call). [2668-271B, 275D-2767, 2814-28AA, pages 17-19].

9. A bug in the /RAM driver (which we pointed out in the 1.1.1 supplement) that allowed a block read of block 7 (which doesn't exist) has been corrected [2D4B, page 23].
10. The /RAM caller, which operates in high RAM, now contains a \$60 (RTS instruction) at address \$FF58. Peripheral cards sometimes call that address to figure out which slot they are in, and in case they forget to set ROM for reading, the call will still work. [2E56-2E58, page 24].
11. A subroutine that sets high RAM for reading/writing was created to save space in the code [2518-251E, page 16].

MLI and MLI Global Page

1. The Global Page now pushes the P-Register and disables interrupts before calling the actual MLI [DE01-DE04, DE1C-DE21, BF4B-BF4F, pages 34 and 75].
2. Setting the MLIACTIVE flag a little differently now allows nested calls to the MLI by interrupt routines [DE8F-DE91, page 35].
3. A new MLI command was introduced (command=\$82), that allows the user to install a routine to handle unclaimed interrupts [DEFF-DF0B, FD23-FD2C, pages 35 and 63].
4. If there is no unclaimed interrupt handler, ProDOS 8 now counts unclaimed interrupts, and will allow 255 of them to occur before finally issuing a fatal error. This allows a brief time for the unknown interrupt to stop interrupting. [DFB3-DFB7, page 36].
5. If operating on a IIGS and system death occurs, the NEWVIDEO softswitch is set to 0, reinitializing the IIGS video [E013-E016, page 36].
6. Processing for the ON_LINE command now frees the VCB entry for a device that was previously on-line but has been taken off-line [E28A-E2A4, page 39].
7. A subroutine that reads a block where the block number is in the A and X registers was added to save space in the code [EBC9-EBD0, page 47].
8. The error message that results when a file being opened has an illegal storage type has been changed from "incompatible directory format" to "unsupported storage type" [EEC7-EECA, page 50].
9. An error type \$C is now indicated when truncating or deleting a file and the file's storage type is illegal [FA4D-FA4E, page 60].
10. To save space in the QuitCode Caller, some in-line code was changed to a loop [FCAF-FCB7, FCD8-FCE0, page 62].

Quit Code

1. Uses standard character set instead of alternate character set [1006-1008, page 77].
2. Sets normal 40-column screen in a safer way, such that screen hole values are preserved [100C-1011, page 77].
3. Message display routine is modified [1033-1034, 11D6-11D1, etc., pages 77 and 79].
4. The method of displaying the current prefix is changed so that it is always written to the same screen location [104D-105C, page 77].
5. User can now backspace with the DELETE key as well as left arrow [107C-107F, 10FC-10FF, page 78].
6. The method of inputting the Application name was modified [10E7-10E9, page 78].

Clock Code

1. The code for the ThunderClock includes a lookup table to determine the year based on the day of the year and the day of the week. This table is only good for a span of five or six years. The table released with Version 1.1.1 was good for the years 1982-1987. The table released with Version 1.2 covers the years 1986-1991. [D7B8-D7BE, page 91].
2. A completely separate clock routine is provided in Version 1.2 in case ProDOS 8 is operating on a IIGS. If so, the IIGS Clock Code is always enabled. It is written in 65816 and calls the ReadTimeHex tool in the tool kit to read the clock. [D742-D790, page 92].

CHANGES INTRODUCED IN THE 1.3 VERSION

The changes that were made to the 1.2 version of ProDOS 8 to produce ProDOS 8, Version 1.3, are listed below. Addresses given here are Version 1.3 addresses.

Relocator

1. The boot message now includes a line that says "ALL RIGHTS RESERVED." Chalk up one for the legal department! [25F6-2671, page 26].
2. A ProDOS Status call now immediately precedes the SmartPort Status Call. This is because the SmartPort interface does not set up its device list until it receives a ProDOS Status call. Earlier versions of ProDOS 8 may not always find all SmartPort devices. [286E-2894, page 28].

MLI

1. When files are deleted, previous versions of ProDOS zero out all but the first block of discarded index blocks. Now such index blocks will not be zeroed, but the pages of these blocks will be flipped. That is, the high byte of the block numbers will be exchanged with the low byte of the block numbers. [F992-F99A, FBC7-FBDC, pages 67 and 69].
2. Previous versions of ProDOS forgot, in certain cases, to rewrite index blocks that were being discarded when shortening or deleting files. Now such blocks will always be rewritten to disk in a zeroed (shortened file) or flipped (deleted file) form. [FAB8-FABC, FB91-FB93, pages 68 and 69].
3. A poorly-written loop in the QuitCode Caller that was added for Version 1.2 was rewritten for Version 1.3. The Version 1.2 code might cause problems on a IIGS. [FD05-FD0C, page 70].

Disk II Device Driver

1. There is a routine in the Disk II Device Driver that clears phases in case the Disk II device is sharing transmission lines with SmartPort devices. This routine was patched in Version 1.3 so that phases are now cleared with LDA instructions instead of STA instructions. This eliminates bus fights that can, in some situations, cause unwanted writing to the floppy disk. [D6C3-D6CE, page 88].

BUGS IN VERSIONS 1.2 AND 1.3

It is fair to say that both Versions 1.2 and 1.3 of ProDOS 8 are relatively bug free. Perhaps a few escaped our notice, but we know of only three minor bugs, which are as follows:

MLI, Versions 1.2 and 1.3, at EC64 (see p. 47). This bug has been in ProDOS since day 1. Although there is no easy way to correct the problem (because a three-byte instruction is needed where there are only two bytes), any serious problems can be avoided by putting NOP's at EC64 and EC65 (3D64 and 3D65 in load location). This bug can only take effect when a storage type 0 is found (not likely unless disk swapping) and a lot of files are open simultaneously.

MLI, Version 1.2 only, at FCD8 (see p. 62). A loop that indexes around the 64K boundary may cause problems on a IIGS. Use version 1.3 or recode the loop so that the boundary crossover is eliminated.

MLI, Version 1.3 only, at FBCD (see p. 69). A 65C02 instruction snuck into the code, which will be disastrous when Version 1.3 is run on a computer with a 6502 processor (Apple II+, unenhanced IIe). It is easily patched, as we explain on page 69.

APPENDIX B

ERRATA TO BENEATH APPLE PRODOS

ERRATA TO BENEATH APPLE PRODOS (1st Printing, 1984)

You can identify which printing of Beneath Apple ProDOS you have by looking at the space between the title of the book and the author's names on the first page of the book (the title page). If this space is blank, you have the first printing. The second printing has "Second Printing, March 1985" in this space. If you have the second printing, skip to page 120. If you have the first printing, all of the following errata apply.

Page 3-16:

In the first paragraph starting on the page, the sentence should read "The data is dealt with in larger pieces (512 bytes vs. 256 bytes)..." , not 512K vs. 256K.

Page 6-63:

The code for "HOW MUCH MEMORY IS IN THIS MACHINE?" is incorrect. Replace it with:

```

LDA    $BF98      GET MACHID FROM GLOBAL PAGE
ASL    A          MOVE BITS TO TEST POSITION
ASL    A
BPL    SMLMEM      48K
ASL    A
BVS    MEM128      128K
...      OTHERWISE 64K

```

Page 6-64:

The code for "GIVEN A PAGE NUMBER, SEE IF IT IS FREE" is incorrect. Replace it with:

```

BITMAP EQU    $BF58      SEE PAGE 8-6
LDA    #PAGE      GET PAGE NUMBER (MSB OF ADDR)
JSR    LOCATE     LOCATE ITS BIT IN BITMAP
AND    BITMAP,Y   IS IT ALLOCATED?
BNE    INUSE      YES, CAN'T TOUCH IT
TXA
PUT BIT PATTERN IN ACCUM
ORA    BITMAP,Y   MARK THIS PAGE AS IN USE
STA    BITMAP,Y   UPDATE MAP
...      WE'VE GOT IT NOW

```

```

LOCATE  PHA          SAVE PAGE NUMBER
        AND    #07    ISOLATE BIT POSITION
        TAY          THIS IS INDEX INTO MASK TABLE
        LDX    BITMASK,Y  PUT PROPER BIT PATTERN IN X
        PLA          RESTORE PAGE NUMBER
        LSR     A      DIVIDE PAGE BY 8
        LSR     A
        LSR     A
        TAY          Y-REG IS OFFSET INTO BITMAP
        TXA          PUT BIT PATTERN IN ACCUM
        RTS          DONE

BITMASK DFB    $80,$40,$20,$10  BIT MASK PATTERNS
        DFB    $08,$04,$02,$01

```

Page 7-9

The code on page 7-9 is incorrect and should be replaced with the following:

```

*      SQUISH OUT DEVICE NUMBER FROM DEVLST
      SKP 1
      LDX    $BF31      GET DEVCNT
DEVL   LDA    $BF32,X    PICK UP LAST DEVICE NUM
      AND    #$70      ISOLATE SLOT
      CMP    #$30      SLOT = 3?
      BEQ    GOTSLT     YES, CONTINUE
      DEX
      BPL    DEVL       CONTINUE SEARCH BACKWARDS
      BMI    NORAM      CAN'T FIND IT IN DEVLST
GOTSLT LDA    $BF32+1,X  GET NEXT NUMBER
      STA    $BF32,X    AND MOVE THEM FORWARD
      INX
      CPX    $BF31      REACHED LAST ENTRY?
      BNE    GOTSLT     NO, LOOP
      DEC    $BF31      REDUCE DEVCNT BY 1
      LDA    #0         ZERO LAST ENTRY IN TABLE
      STA    $BF32,X
      CLC
      BCC    OKXIT      BRANCH ALWAYS TAKEN
      SKP    1
OLDVEC DW     0         OLD VECTOR SAVEAREA

```

To reinstall the /RAM driver, execute this subroutine:

```

*          SKP      1
          SEE IF SLOT 3 HAS A DRIVER ALREADY
          SKP      1
HIMEM      EQU      $73          PTR TO BI'S GENERAL PURPOSE BUFFER
          SKP      1
INSTALL    LDX      $BF31        GET DEVCNT
INSLP      LDA      $BF32,X      GET A DEVNUM
          AND      #$70          ISOLATE SLOT
          CMP      #$30          SLOT 3?
          BEQ      INSOUT        YES, SKIP IT
          DEX
          BPL      INSLP         KEEP UP THE SEARCH
          SKP      1
*          RESTORE THE DEVNUM TO THE LST
          SKP      1
          LDX      $BF31        GET DEVCNT AGAIN
          CPX      #$0D          DEVICE TABLE FULL?
          BNE      INSLP2
ERROR      ...                YOUR ERROR ROUTINE

INSLP2     LDA      $BF32-1,X    MOVE ALL ENTRIES DOWN
          STA      $BF32,X      TO MAKE ROOM AT FRONT
          DEX                  FOR A NEW ENTRY
          BNE      INSLP2
          LDA      #$B0
          STA      $BF32        SLOT 3, DRIVE 2 AT TOP OF LIST
          INC      $BF31        UPDATE DEVCNT
          SKP      1

```

Page 7-26:

Modifying the ProDOS Disk II Device Driver to allow 320 blocks instead of the normal 280. The fourth command line should read:

520D:40

Modifying FILER to format 40 tracks instead of 35. The fourth command line should read:

4244:40

[See Second printing errata for information about versions other than 1.0.1]

Page 8-6:

Under "Device Information", make the following changes:

BF10-BF11	DEVADR01	Slot 0 reserved.
...		
BF26-BF27	DEVADR32	/RAM device driver address (need extra 64K).

Page 8-7:

The wrong bit is indicated as the "expansion bit" in the MACHID byte. The first eight rows of that description should read:

00.. 0...	II
01.. 0...	II+
10.. 0...	IIE
11.. 0...	III emulation
00.. 1...	Future expansion
01.. 1...	Future expansion
10.. 1...	IIC
11.. 1...	Future expansion

Page B-8:

In the last paragraph, the sentence should read "A second way to use **an interpreted** language..." (not **a compiled** language).

Page D-1:

In the second paragraph, the sentence should read "Versions of the Disk Drive Controller Unit are now **used...**" (not **based**).

Reference Card, Panel 4

Under "SYSTEM GLOBAL PAGE FORMAT", replace the lines beginning BF05 and BF06 with the following two lines:

BF06	Jump to Date/Time Address (or RTS if no clock)
------	---

The description of BF10-11 should be changed to:

BF10-11 Slot 0 reserved

The description of BF26-27 should be changed to:

BF26-27 /RAM

Under the "MACHINE IDENTIFICATION BYTE", the second column of numbers should read:

0...
0...
0...
0...
1...
1...
1...
1...

Reference Card, Panel 9

The last entry for "MLI ERROR CODES" should be:

\$5A Bad vol. bit map

(not \$58).

ERRATA TO BENEATH APPLE PRODOS (2nd Printing, 1985)

Page 4-30:

The definitions of PARENT POINTER and PARENT ENTRY are incorrect. Replace them with:

\$27-\$28 PARENT_POINTER: The block number (within the volume directory or a subdirectory) which contains the file entry for this subdirectory.

\$29 PARENT_ENTRY: The number of the file entry within the block number pointed to by the PARENT_POINTER. Given that "ENTRIES_PER_BLOCK" is \$0D, then the PARENT_ENTRY number ranges from \$01 to \$0D.

Page 6-62:

The paragraph immediately preceding Table 6.6 should read as follows:

If an error occurs, the BI error code will be placed in the accumulator. Possible codes are listed in Table 6.6.

In Table 6.6, the message for error code \$0C is wrong. It should read:

\$0C NO BUFFERS AVAILABLE

Page 7-26:

Expand the 40-track drive patch to show how to patch all of the versions of ProDOS 8 released to date.

This patch modifies the Disk II Driver, which is a part of the "PRODOS" file (or "P8" file), so that it allows 320 blocks per volume instead of 280 blocks per volume. First set the prefix to the directory that contains the file you want to modify. This file will normally be called "PRODOS" on an 8-bit Apple II and "P8" on a 16-bit Apple IIGS. If the file name is not "PRODOS," substitute the correct filename wherever "PRODOS" appears.

```
UNLOCK PRODOS
BLOAD PRODOS,TSYS,A$2000
CALL -151
address*:40
3D0G
BSAVE PRODOS,TSYS,A$2000
LOCK PRODOS
```


*"address" varies with the version of ProDOS, as follows:

ProDOS Version	address
1.0.1	520D
1.0.2	52CD
1.1.1	56E3
1.2	58E3
1.3	58E3

The following patch modifies the program FILER to format 40 tracks instead of 35. After this modification is made, only 40-track drives may be formatted with FILER.

```
UNLOCK FILER
BLOAD FILER,TSYS,A$2000
CALL -151
addr**:40
79F4:28
3D0G
BSAVE FILER,TSYS,A$2000
LOCK FILER
```

**"addr" depends on the release date of FILER. Here are the values of "addr" for two different release dates:

Release date	addr
1 JAN 84	4244
18 JUN 84	426A

Page A-34:

In the listing of the "TYPE" program, change the value 4 to 5 in line 207 as follows:

```
2115:C0 05          207          CPY    #5
```



Quality Software Products For the Apple

BOOKS

Beneath Apple ProDOS by Don Worth & Pieter Lechner

Describes the ProDOS Operating System clearly and in detail, going beyond Apple's manuals. Many programming examples are included. 288 pages. **\$19.95**

Supplements to Beneath Apple ProDOS:

Versions 1.0.1 and 1.0.2 (combined)	\$10.00
Version 1.1.1	\$12.50
Versions 1.2 and 1.3 (combined)	\$12.50

Beneath Apple DOS by Don Worth & Pieter Lechner

The popular best seller that covers all facets of DOS 3.3 and previous Apple disk operating systems. 176 pages. **\$19.95**

Understanding the Apple II by Jim Sather

Foreword by Steve Wozniak. A definitive source of information, covers Apple II and Apple II Plus hardware, including the disk controller and logic state sequencer. 352 pages. **\$22.95**

Understanding the Apple IIe by Jim Sather

The companion to **Understanding the Apple II**, this book covers Apple IIe hardware, including video graphics and the 1985 firmware upgrade (65C02). 368 pages. **\$24.95**

UTILITIES

Bag of Tricks 2 by Don Worth & Pieter Lechner

Quality Software's popular set of Apple II disk utility programs, **Bag of Tricks**, has been thoroughly revised and updated for the ProDOS operating system. TRAX, INIT, ZAP, and FIXCAT are the four comprehensive utility programs, all with improved user interfaces to make them easier to use than the original **Bag of Tricks**.* Unprotected diskette and 200-page manual. 64K. **\$49.95**

*Special offer to **Bag of Tricks** owners--save \$20 by ordering directly from Quality Software. To order, send in your **Bag of Tricks** diskette and \$29.95, plus shipping, handling, and sales tax. We will return your diskette along with the new product.

Universal File Conversion by Gary Charpentier

Moves programs and data among the five operating systems used on the Apple II family of computers: DOS, ProDOS, CP/M, Pascal, and SOS. Unprotected 5 1/4" diskette and 48-page manual. 64K. **\$34.95**

Ordering directly from Quality Software

To order our products directly, mail this order form to Quality Software (at the address below) with your payment--the price of the software (plus sales tax if shipped to California) plus shipping and handling charges. Your payment can be a check or bank draft made payable to Quality Software in US dollars, or your VISA or MASTERCARD number and expiration date (VISA and MASTERCARD holders may phone in their orders). California residents must add the appropriate sales tax (6%, 6.5%, or 7%).

Shipping charges:

48 Continental United States (UPS).....\$2.50
Alaska, Hawaii, Canada, and Mexico (air mail).....\$5.00
All other countries (insured air mail).....\$10.00

Send your order to:

QUALITY SOFTWARE
21610 Lassen Street #7
Chatsworth CA 91311
(818) 709-1721

QUANTITY	DESCRIPTION	AMOUNT
----------	-------------	--------

_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____

SUBTOTAL _____

(CA RESIDENTS) SALES TAX _____

SHIPPING _____

TOTAL _____

Check # _____

OR VISA/MasterCard # _____ EXPIRES _____

Name _____

Street Address _____

City, State, Postal Code _____

Country _____

SUPPLEMENT TO

Beneath Apple ProDOS

For ProDOS 8, Versions 1.2 and 1.3



by Don Worth and Pieter Lechner

QS QUALITY
SOFTWARE